



Saurashtra University

Re – Accredited Grade 'B' by NAAC
(CGPA 2.93)

Nanavati, Maulin C., 2007, “The development of Advance Experiments useful to the students of Electronics field”, thesis PhD, Saurashtra University

<http://etheses.saurashtrauniversity.edu/id/912>

Copyright and moral rights for this thesis are retained by the author

A copy can be downloaded for personal non-commercial research or study, without prior permission or charge.

This thesis cannot be reproduced or quoted extensively from without first obtaining permission in writing from the Author.

The content must not be changed in any way or sold commercially in any format or medium without the formal permission of the Author

When referring to this work, full bibliographic details including the author, title, awarding institution and date of the thesis must be given.

Saurashtra University Theses Service
<http://etheses.saurashtrauniversity.edu>
repository@sauuni.ernet.in

© The Author

**THE DEVELOPMENT OF ADVANCE EXPERIMENTS
USEFUL TO THE STUDENTS OF ELECTRONICS FIELD**

Thesis

Submitted to the Saurashtra University, Rajkot

For

The Degree of Doctor of Philosophy

(Science)

(Electronics)

By

Maulin Chandrakant Nanavati

Department Of Electronics

Saurashtra University

Rajkot 360 005

Gujarat, India

Research Supervisor

Dr. H. N. Pandya

Head

Department Of Electronics

Saurashtra University

Rajkot 360 005

Gujarat, India

MAY 2007

***Erudition can only be got in one way, the way of experience;
there is no other way.***

- Sri Swami vivekanand

Affectionately fanatical
To
My Adored Grandparents
Mr. J. N. Nanavati and Mrs. H. J. Nanavati
And
My Parents
Dr. C. J. Nanavati and Dr. B. C. Nanavati

Statement under O. Ph.D. of Saurashtra University

The content of this thesis is my own work carried out under the supervision of Dr. H. N. Pandya and leads to some contribution in Electronics supported by necessary references.

(Mr. M. C. Nanavati)
Department Of Electronics
Saurashtra University,
Rajkot 360 005
Gujarat, India

This is to certify that the present work submitted by Mr. M. C. Nanavati for the Ph.D. degree of Saurashtra University, Rajkot has been the result of about 5 years of work under my supervision and is a valuable contribution in the field of electronics.

Dr. H. N. Pandya
Head, Department Of Electronics
Saurashtra University,
Rajkot 360 005
Gujarat, India.

Acknowledgement

I am thankful to *my GOD LORD SHIVA* for give me opportunity to gain a higher level education.

I am thankful to **Saurashtra University** for register me as a research student and permit me to use laboratory and other available resources of Department and University.

I am thankful to my *GURU, Research advisor* **Dr. H. N. Pandya**, Head Department Of Electronics, Saurashtra University, Rajkot, Gujarat, India for his keen interest in my research work and keep me morally boost in my difficulties and work-out to perform my research work easily. I am thankful to him for use his scientific and innovative idea for my research work.

In deep sense of gratitude for my parent **Dr. Basanti Chandrakant Nanavati** and **Dr. Chandrakant J. Nanavati**, without there blessing and moral support I could not perform this task easily. I am especially thankful to my parents for there help in all regards and give me opportunity to gain a higher level education. Also I am thankful to **Miss. Priti J. Joshi, Mr. J. B. Joshi, Mrs. S. J. Joshi, Mr. P. J. Joshi** and **Miss. B. J. Joshi** for their moral support during my completion period of my Ph. D. work.

I thankful to my colleagues **Mr. Anand Bhaskar** for plan out research problem and discuss on research problems. I am thankful to him for his helping hand on my research work. I am thankful to **Dr. Kapil K. Bhatt** lecturer, Department of Physics, Wilson College, Mumbai, **Dr. Urmiben M. Joshi**, and **Dr. K. P. Thummer** for their useful tips in research problems.

I am thankful to **my sister Mrs. Kruti Buch**, my brother-in-law **Mr. Harshal Buch** for their love and help me in moral boost in my research work. I am thankful to my little nephew **Mr. N. H. Buch** whose smiling face makes my work easy and boost me for to cheer up me in my hard work.

I am thankful to **Mr. Udaybhai J. Khachar** for his kind help during discussing on various problems. I am thankful to **Mr. Jatin Kamdar, Dr. Bimal H. Vyas, Dr. Chetan M. Thakar, Mr. Jatin Joshi, Mr. Rajendrakumar Khar, Mr. Jaipalsinh Zala**, and **Mr. Hemanshu Vachhani** for there moral support during my breakdowns and discussion on different topics.

I am thankful to **Mr. Manishbhai R. Pandya, Mr. Taresh P. Bhatt** for their help to cheer up me in my tense and problematic days. I am thankful to **Mr. Manishbhai** for help me at Department of Electronics for providing me help at laboratory work.

Last but not list I am thankful to **Mrs. Kirenben H. Pandya (madam)** and **Miss S. H. Pandya** for their help and moral boosting in tense matter.

At the last I am again thankful to my *GOD LORD SHIVA* who gives me Power and strength to gain this higher degree of education and to fight against those problems to come over. I am thankful to Lord Shiva for his blessings.

Thank you all of you, who help me during this period of education.

Contents

Title
Quote
Dedicated to
Certificate
Acknowledgement

Section 1

AIMS AND TOOLS

Chapter 1	Introduction.....	1
	Objective of the present work.....	2
	Literature survey.....	2
Chapter 2	Basics of microprocessor 8085A.....	6
	Introduction.....	7
	Major blocks of microprocessor 8085.....	7
	General features.....	7
	Description.....	8
	Pin description.....	10
	Input / Output devices of microprocessor 8085.....	13
	82C55A Programmable Peripheral Interface... ..	13
	Functional description.....	13
	Operational description.....	17
	Operating modes.....	20
	8251A Universal Synchronous /	
	Asynchronous Receiver and Transmitter.....	29
	Functional description.....	29
	Operational description.....	35
	Programming the 8251A.....	36
	Memory organization of 8085A.....	44
Chapter 3	Basics of microcontroller 89C51.....	48
	Introduction.....	49
	Pin description.....	50
	Major blocks of microcontroller 89C51.....	52
	Special Function register.....	53
	Input / Output devices of microcontroller 89C51.....	56
	P1- P3 structure and operation.....	57
	Reading the input pin.....	57
	Writing “0” to the port.....	58
	Avoid damaging the port.....	58
	Instructions reading the status of input port... ..	58
	Reading latch.....	59
	Read modify write instructions.....	59
	Output port.....	60
	Memory organization of 89C51.....	60
	Program memory.....	60

	Data memory.....	60
	Direct and Indirect address area.....	61
 Section 2		
EXPERIMENTS ON MICROPROCESSOR		
Chapter 4	Advance experiments on 8251.....	62
	Roll of 8251 with microprocessor 8085.....	63
	Continuous transmission of data over T _x D pin.....	71
	8251 as receiver and transmitter in the same kit.....	73
	Serial communication between two kits.....	75
 Chapter 5	 Advance experiments on 8255.....	 81
	Roll of 8255 with microprocessor 8085.....	82
	Mode 1 experiment.....	87
	Port A as output port and port B as input	
	Port in mode 1.....	87
	Mode 2 experiment.....	92
	Port A as output port and port B as input	
	Port.....	92
	Port A as input port and port B as output	
	Port.....	95
 Chapter 6	 Advance experiments on interrupt.....	 98
	Roll of hardware and software interrupts with	
	Microprocessor 8085.....	99
	To generate the interrupts as per user's choice and	
	execute its service routine.....	106
	To verify the priorities of interrupts.....	109
	To understand the masking of interrupts.....	110
 Section 3		
EXPERIMENTS ON MICROCONTROLLER		
89C51		
Chapter 7	Advance experiments on Keyboard interface.....	111
	Basics of keyboard used.....	112
	Interfacing of keyboard with 89C51 Microcontroller... ..	113
 Chapter 8	 Advance experiments on matrix display.....	 126
	Basics of display used.....	127
	Basic knowledge of 5X7 matrix LED display.....	128
	Running character display interface using 89C51.....	128
 Chapter 9	 Advance experiments on LCD display.....	 139
	Introduction.....	140
	Basics of LCD display.....	140
	Interfacing of LCD module with microcontroller	
	89C51.....	144

Section 4

DEVELOPMENT TOOLS

Chapter 10	Advance experiments on logic state analyzer.....	154
	Introduction.....	155
	Debugging of microprocessor kit using logic state analyzer: a simple laboratory experiment.....	160
Chapter 11	Advance experiments on pcice.....	168
	Introduction.....	169
	Using In-circuit emulator in the laboratory.....	169
Chapter 12	Advance experiments on Pspice.....	186
	Introduction.....	187
	Commands of Pspice.....	204
	Experiments.....	205
	Analog experiments.....	206
	AC circuit.....	206
	DC circuit.....	217
	Digital experiments.....	223
Chapter 13	Conclusion.....	241
Appendix A	Datasheet.....	243
	MC1488 Quadruple line drivers.....	
	MC1489 Quadruple line receivers.....	
Appendix B	References.....	244

Figures

Figure 2.1.....	8
Figure 2.2.....	14
Figure 2.3.....	16
Figure 2.4.....	17
Figure 2.5.....	18
Figure 2.6.....	19
Figure 2.7.....	21
Figure 2.8(A).....	22
Figure 2.8(B).....	22
Figure 2.9(A).....	23
Figure 2.9(B).....	24
Figure 2.10(A).....	26
Figure 2.10(B).....	26
Figure 2.11.....	29
Figure 2.12.....	30
Figure 2.13.....	37
Figure 2.14.....	38
Figure 2.15.....	39
Figure 2.16.....	40
Figure 2.17.....	41
Figure 2.18.....	42
Figure 2.19.....	43
Figure 2.20.....	44
Figure 2.21.....	45
Figure 2.22.....	46
Figure 2.23.....	46
Figure 3.1.....	50
Figure 3.2.....	53
Figure 3.3.....	55
Figure 3.4.....	57
Figure 3.5.....	60
Figure 3.6.....	61
Figure 4.1.....	64
Figure 4.2.....	65
Figure 4.3.....	65
Figure 4.4.....	66
Figure 4.5.....	67
Figure 4.6.....	68

Figures

Figure 4.7.....	69
Figure 4.8.....	70
Figure 4.9.....	70
Figure 4.10.....	76
Figure 5.1(A).....	83
Figure 5.1(B).....	84
Figure 5.2.....	85
Figure 5.3.....	86
Figure 5.4.....	87
Figure 5.5(A).....	88
Figure 5.5(B).....	88
Figure 5.5(C).....	89
Figure 5.6.....	93
Figure 5.7.....	95
Figure 6.1.....	102
Figure 6.2.....	104
Figure 7.1.....	112
Figure 7.2.....	113
Figure 7.3.....	114
Figure 7.4.....	115
Figure 7.5.....	117
Figure 8.1.....	127
Figure 8.2.....	127
Figure 8.3.....	128
Figure 8.4.....	129
Figure 8.5.....	131
Figure 8.6.....	132
Figure 8.7.....	133
Figure 8.8.....	134
Figure 9.1.....	141
Figure 9.2.....	143
Figure 9.3.....	144
Figure 10.1.....	156
Figure 10.2.....	162
Figure 10.3.....	163
Figure 10.4.....	160
Figure 11.1.....	181
Figure 12.1.....	189
Figure 12.2.....	190
Figure 12.3.....	192
Figure 12.4.....	193
Figure 12.5.....	194
Figure 12.6.....	199
Figure 12.7.....	201
Figure 12.8.....	206
Figure 12.9.....	208
Figure 12.10.....	209
Figure 12.11.....	209
Figure 12.12.....	210
Figure 12.13.....	210


Figures

Figure 12.14.....	216
Figure 12.15.....	217
Figure 12.16.....	218
Figure 12.17.....	220
Figure 12.18.....	221
Figure 12.19.....	221
Figure 12.20.....	222
Figure 12.21.....	223
Figure 12.22.....	224
Figure 12.23.....	225
Figure 12.24.....	230
Figure 12.25.....	231
Figure 12.26(A).....	232
Figure 12.26(B).....	232

Tables

Table 2.1	16
Table 2.2	20
Table 2.3	27
Table 2.4	47
Table 3.1	52
Table 3.2	54
Table 4.1	73
Table 6.1	100
Table 6.2	100
Table 6.3	103
Table 6.4	104
Table 6.5	105
Table 6.6	105
Table 6.7	106
Table 6.8	109
Table 7.1(A)	115
Table 7.2(B)	116
Table 8.1	130
Table 8.2	131
Table 8.3	132
Table 9.1	139
Table 9.2	140
Table 9.3	142
Table 10.1	157
Table 10.2	167
Table 11.1	170
Table 11.2	172
Table 12.1	224
Table 12.2	231

SECTION 1
AIMS AND TOOLS





CHAPTER 1

INTRODUCTION



1.1 Objective of the present work:-

In the last few years of this century the technology has spelled the society with miracles. The fast growth of electronics has opened a variety of advance topics to be learned by the students. The training to the newer topic in the electronics needs a structured easy to understand methodology. The in-flow of the newer and newer topics has surmounted the slow pace of learning. Students are desirous of learning many new things in electronics but the latest electronics topics have not been chewed by the faculties to feed the young ones, that is, students.

It is our basic objective in the present work to convert such complex conceptual aspects to a level that can be easily understood by the student. We have developed the experiments which can train students to easily understand and verify the concepts themselves by performing experiment on there own. We also planed to prepare material regarding experiments which is included in the concerned experiments.

Thus, the objectives of the present work is to design and develop experiments on advance topics like microprocessor, microcontroller, circuit simulation and on the development tool to help the students learn this topic with ease along with the study material.

1.2 Literature Survey:-

In the first attempt to gather information about the experiments in the field of electronics the books on such topic were searched. The well known books written by ZBAR PAUL B “*Basic Electronics: A Text-Lab Manual*”, 4th and 7th edition, Tata McGraw hill Publishing company Limited and listed below were studied. But, the content of the books were of basic electronics type. We tried to refer the various books on 8085 which may give some idea on the interfacing experiments on 8085. Some of the books we found useful are listed below^[B-1 TO B-25].

- 1) A. W. Moore, K. E. Fronheisher, Vinay Khanna, John DeLaune, G. G. Sawyer, M. E. Edison, T. C. Daly, J. F. Vittera “Motorola semiconductor product Inc. Microprocessor¹ applications manual” McGraw hill publishing inc. N Y.

¹ Motorola microprocessor 68C00 applications

- 2) Ahson S. L. "Microprocessor with application in process control" Tata McGraw hill Publishing Company Limited New Delhi, 1992
- 3) Baker R. Jacob, Li Harry W, Boyce David E "CMOS Circuit design, layout and simulation", Prentice hall of India.
- 4) Bose Sanjay "Digital System: From Gates to Microprocessor" 2nd edition, New Age International (P) ltd. 1992.
- 5) Dr. H. N. Pandya² "Printed Circuit Board" Gujarat Granth Nirman Board Ahmedabad India.
- 6) Dr. H. N. Pandya "Understanding P.C.B. Designing software" 1st edition, Saurashtra University Rajkot 2006.
- 7) Electronics concepts handbook vol. 1 to 3 McGraw hill publishing inc. N. Y.,
- 8) Giacoletto "Electronics Designers' handbook" 2nd edition, McGraw hill publishing inc.
- 9) Hall Douglas "Microprocessor and Digital system" 2nd edition, Tata McGraw hill Publishing Company Limited.
- 10) J. C. Whitaker "The Electronics Handbook" IEEE Press.
- 11) John Markus "Guidebook of Electronics Circuit", McGraw hill publishing inc..
- 12) Kenneth J. Ayala "The 8051 microcontroller Architecture, Programming and Applications" 2nd edition, Penram International Mumbai.
- 13) Microprocessor Data handbook, Revised Edition, BPB Publication New Delhi
- 14) Osborne, Adam, "An Introduction to Microcomputers Volume 0 to 3" Adam Osborne and Associates, Inc. 1977.
- 15) P. K. Ghosh and P. R. Sridhar "0000 to 8085 Introduction to Microprocessor for Engineers and scientists" 2nd edition, Prentice hall of India EEE edition New Delhi.
- 16) Padmanbhan K. "Learn to use Microprocessor" 4th edition, EFY Enterprises (P) ltd. New Delhi, 1999.
- 17) R. S. Gaonkar "Microprocessor architecture, programming and application with the 8085" 3rd edition, Penram International Mumbai.

² Head, Department Of Electronics, Saurashtra University, Rajkot, Gujarat, India

- 18) Rashid Mohammad "Spice for circuits and electronics using PSPICE" 2nd and 3rd edition, Prentice hall of India, Eastern Economy Edition New Delhi.
- 19) Singh Renu "Microprocessor Interfacing and Application" 2nd edition, New Age Publication (P) ltd., 2006.
- 20) Stan Gibilisco and Neil Sclater³ "Encyclopedia Of Electronics" 1st and 2nd edition, McGraw hill publishing inc. N Y.
- 21) Taub Herbert "Digital circuits and microprocessor", Tata McGraw hill Publishing company Limited England, 1982.
- 22) Theagarajan R and Dhanasekaran S. "Microprocessor and its Applications" New Age international (P) ltd. New Delhi, 1997.
- 23) Titus Christopher A., Larsen David G., Titus Jonathan A. "8085A Cookbook" Howard W. Sams & Co., Inc. 1980.
- 24) Walter Bosshart "Printed Circuit Board: Design and Technology" Tata McGraw hill Publishing company Limited New Delhi, 1993.

Apart from the above books book on SDK-85 microprocessor trainer kit was found useful. The details of the book are as follow.

- 25) Borivaje Furht, Himansu Parikh "Microprocessor interfacing and communication using the Intel SDK-85" Prentice Hall, January 1986.

We also used the internet facility to find out best useful in this work. This suggested us to following useful web-site^[W-1 TO W-28].

- <http://docs.hp.com/en/B6057-96002/ch04.html>
- <http://groups.google.co.in/groups/dir?hl=en&sel=0,16823622,16823610>
- <http://groups.google.co.in/sci.electronics.design?lnk=hppg&hl=en>
- <http://linuxassembly.org/>
- <http://tech.groups.yahoo.com/group/emu8086/>
- <http://tech.groups.yahoo.com/group/win32-nasm-users/>
- <http://www.2cpu.com/>
- <http://www.8052.com/>
- http://www.brothersoft.com/Home_Education_Science_8085_Simulatot_19818.html
- <http://www.chip-architect.com/>

³ Editor In-Chief McGraw hill publishing inc. N.Y.

- <http://www.clickon-cpu.com/>
- <http://www.cpu-museum.com/>
- <http://www.cpu-museum.net/>
- <http://www.datasheetcatalog.com/>
- <http://www.emu8086.com/>
- <http://www.emulation.com/>
- <http://www.emulators.com/pentium4.htm>
- <http://www.freemware.org/>
- <http://www.ieee.org/>
- <http://www.intel.com/>
- <http://www.microprocessor.sccc.ru/>
- <http://www.old-computer.com/museum/computer.asp?st=1&c=805>
- <http://www.orcad.com>
- <http://www.rdos.net/sim/>
- <http://www.thefreecountry.com/>
- <http://www.tomshardware.com/>
- <http://www.x86.org/>
- <http://www.x86-64.org/>

The detailed literature survey suggested that we need to develop the study material on the concentrated topic like microprocessor, microcontroller, circuit simulation and development tools.



CHAPTER 2

BASICS OF MICROPROCESSOR 8085



2.1 INTRODUCTION:-

8085 is one of the topics of present work. Some experiments which can enlighten the basic concepts of 8085 was planned.

To understand 8085 properly the concept like timing diagram, interrupts, and interfacing are necessary. For this, the basic block diagram, instruction set, and programming aspects are to be thoroughly understood.

Following are necessary to study 8085.

- Address, data and control bus.
- Detailed knowledge of instruction sets
- Timing process of 8085
- Basic programming technique.

2.2 MAJOR BLOCKS OF MICROPROCESSOR 8085:-

The block diagram of 8085A is shown in Figure 2.1.

- **GENERAL FEATURES:-**
 - It is a 40 pin DIP device
 - It is 8-bit parallel central processor
 - Needs +5V supply
 - Basic speed is 3 MHz and above
 - Has four vectored interrupts
 - Facility of serial Input-Output
 - Can handle decimal, binary and double precision arithmetic
 - Can access directly 64KB memory
 - On chip system controller and clock generator
 - 1.3 μ s instruction cycle.




FIGURE 2.1 Block diagram and Pin configuration of 8085A

• **DESCRIPTION:-**

8085 contains following blocks:

- 1) Registers: special purpose and general purpose
- 2) Interrupt control
- 3) Serial I/O control
- 4) Address/data buffers
- 5) Timing and control unit
- 6) IR and decoder
- 7) Arithmetic logic unit (ALU)

General purpose registers are B, C, D, E, H and L each of 8-bits. They can be used as independent 8-bit registers or paired 16-bits registers. Following pairs are

possible: BC, DE and HL. Pairs are used for 16-bit arithmetic and to address the data in memory. HL is as special type of pair which always stores the address of memory location for accessing.

Special purpose registers are A, FLAGS, PC, SP and IR. The accumulator is one default operand storage register for some arithmetic and logical instruction, second operand can be register or memory.

Flags register stores the result of arithmetic or logical instruction by setting or resetting the individual flip-flops. Following is the structure.

D ₇	D ₆	D ₅	D ₄	D ₃	D ₂	D ₁	D ₀
S	Z	X	AC	X	P	X	CY

CY = Carry flag, set when carry or borrow occurs

P = Parity flag, set for even parity

AC = Auxiliary flag, set when carry occur due to operation of D₃ digit. Used for BCD arithmetic.

Z = Zero flag, set if the result is zero.

S = Sign flag, set if the result is negative number.

Stack pointer register always points to the last byte of the stack (at TOS). Filling up of stack decrements SP while retrieving of stack increments SP. Used by PUSH and POP instruction.

Instruction register is not user accessible. It stores the op-code byte of any instruction and gives this information to decoder (instruction decoder).

Interrupt control unit takes care of following interrupts.

INTR, RST 7.5, RST 6.5, RST 5.5 and TRAP.

They are written (above) in their increasing priority. TRAP is non-maskable. Except TRAP other interrupts can be enabled or disabled by interrupt enable (EI) or DI instructions. RST means restart (execution from predefined location). They have vectored addresses. RST 6.5, RST 5.5 and INTR are level sensitive, while RST 7.5 is edge sensitive. TRAP is edge and level sensitive. Sampling of interrupts takes place one cycle before the last cycle of the instruction being executed on the descending edge of the clock pulse.

A valid interrupt must occur at least 160ns before sampling time. RSTs interrupts are masked by SIM instruction and can be read off by RIM instruction. Serial input/output is possible through SID and SOD pins of 8085. For each bit transaction, SIM or RIM instruction is to be executed. RIM inputs bits while SIM outputs the bits.

8085 has multiplexed address and data lines ($AD_7 - AD_0$) (LOW ADDRESS LINES). During T_1 clock cycle, high ALE latches address present on AD_0-AD_7 pins into external latch. During other clock cycles ($T_2, T_3 \dots$) same pins i.e. AD_0-AD_7 work as data lines D_7-D_0 .

Timing and control unit includes pins for clock, control signal (\overline{RD} , \overline{WR} , READY and ALE), status lines (S_0, S_1 and IO/\overline{M}), DMA (HOLD, HLDA) and reset ($\overline{RESETIN}$, RESETOUT). Clock is provided by crystal (>6 MHz frequency). Crystal frequency is internally divided by 2. READY is for synchronization of external slow memory or device, S_0, S_1 and IO/\overline{M} are for hardware debugging and represent machine status. HOLD and HLDA are used for DMA application. $\overline{RESETIN}$ is for 8085A initialization and RESETOUT for peripheral initialization.

IR and decoder are for instruction code byte storage and identification of the type of instruction.

ALU can perform arithmetic and logical operation on operands of 8-bit length. These two operands are stored in A and one temporary register before ALU operation. Some results of instruction execution are provided in flag register by ALU.

• **PIN DISCRPTION:-**

- **$A_8 - A_{15}$ (OUTPUT 3-STATE) PIN NO. 21 TO 28**
Address bus; the most significant 8-bits of the memory address or the 8-bits of the I/O address, 3-state during Hold and Halt modes.
- **$AD_0 - AD_7$ (INPUT OUTPUT 3-STATE) PIN NO. 12 TO 19**
Multiplexed address / data bus: Lower 8-bits of the memory address (or I/O address) appear on the bus during the first clock cycle of the machine state. It then becomes the data bus during the second and third clock cycles. 3-state during HOLD and HALT modes.
- **ALE (OUTPUT) PIN NO. 30**
Address latch enable: It occurs during the first clock cycle of a machine state and enables the address to get latched into the on-chip latch of peripherals.

The falling edge of ALE is set to guarantee setup and hold times for the address information. ALE can also be used to strobe the status information. ALE is never 3-stated.

▪ **S₀, S₁ (OUTPUT)** **PIN NO. 29 & 33**

Data bus status: encoded status of the bus cycle.

S ₀	S ₁	Cycle
0	0	HALT
0	1	WRITE
1	0	READ
1	1	FETCH

S₁ can be used on an advanced R/ \overline{W} status.

▪ **\overline{RD} (OUTPUT 3-STATED)** **PIN NO. 32**

READ: indicates the selected memory or I/O device is to be read and that the data bus is available for the data transfer. 3-stated during HOLD and HALT.

▪ **\overline{WR} (OUTPUT 3-STATED)** **PIN NO. 31**

WRITE: indicates the data on the data bus is to be written into the selected memory or I/O device. Data is set up at the trailing edge of \overline{WR} . 3-state during HOLD and HALT modes.

▪ **READY (INPUT)** **PIN NO. 35**

If READY is high during a read or writes cycle it indicates that the memory or peripheral is ready to send or receive data. If READY is low, the CPU will wait for READY to go high before completing the read or write cycle.

▪ **HOLD (INPUT)** **PIN NO. 39**

HOLD: indicates that another master is requesting the use of the address and data buses. The CPU, upon receiving the hold request, will relinquish the use of buses soon after the completion of the current machine cycle. Internal processing can regain the buses only after the HOLD is removed. When the HOLD is acknowledged, the Address, Data, \overline{RD} , \overline{WR} , and IO/\overline{M} lines are 3-stated.

▪ **HLDA (OUTPUT)** **PIN NO. 38**

HOLD ACKNOWLEDGE: indicates that the CPU has received the HOLD request and that it will relinquish the buses in the next clock cycle. HLDA

goes low after the HOLD request is removed. The CPU takes the buses one half clock cycles after HLDA goes low.

- **INTR (INPUT) PIN NO. 10**
INTERRUPT REQUEST: is used as a general purpose interrupt. It is sampled only during the next to the last clock cycle of the instruction. If it is active, the program counter (PC) will be inhibited from incrementing and an $\overline{\text{INTA}}$ will be issued. During this cycle a RESTART or CALL instruction can be inserted to jump to the interrupt service routine. The INTR is enabled and disabled by software. It is disabled by RESET and immediately after an interrupt is accepted.
- **$\overline{\text{INTA}}$ (OUTPUT) PIN NO. 11**
INTERRUPT ACKNOWLEDGE: is used instead of (and has the same timing as) $\overline{\text{RD}}$ during the instruction cycle after an INTR is accepted. It can be used to activate the 8259 INTERRUPT CHIP or some other INTERRUPT PORT.
- **RST 5.5, RST 6.5 AND RST 7.5 (INPUTS) PIN NO. 9, 8 AND 7**
RESTART INTERRUPTS: These three inputs have the same timing as INTR except they cause an internal RESTART to be automatically inserted. Priority is highest for RST 7.5 then RST 6.5 and lastly RST 5.5. All these have higher priority than INTR.
- **TRAP (INPUT) PIN NO. 6**
TRAP INTERRUPT: is a non-maskable restart interrupt. It is recognized at the same time as INTR. It is unaffected by any mask or INTERRUPT enable. It has the highest priority of any interrupt.
- **$\overline{\text{RESETIN}}$ (INPUTS) PIN NO. 36**
RESET sets the program counter to zero and resets the INTERRUPT Enable and HLDA flip-flop. None of the other flags or registers (except the Instruction Register) are affected. The CPU is held in the reset condition as long as reset is applied.
- **RESETOUT (OUTPUTS) PIN NO. 3**
Indicates CPU is being reset. It can be used as a system RESET. The signal is synchronized to the processor clock.

- **X₁, X₂ (INPUTS)** **PIN NO. 1 AND 2**
Crystal or R-C network connections to set the internal clock generator. X₁ can also be an external clock input instead of crystal. The input frequency is divided by 2 to give the internal operating frequency.
- **CLKOUT (OUTPUTS)** **PIN NO. 37**
Clock output for use as a system clock when a crystal or R-C network is used as an input to the CPU. The period of CLK is twice the X₁, X₂ input period.
- **IO/ \overline{M} (OUTPUTS)** **PIN NO. 34**
IO/ \overline{M} indicates whether the read/write is to memory or I/O device. 3-stated during HOLD and HALT mode.
- **SID (INPUTS)** **PIN NO. 5**
Serial data input line. The data on this line is loaded into accumulator bit 7 whenever a RIM instruction is executed.
- **SOD (OUTPUTS)** **PIN NO. 4**
Serial data output line. The output SOD is set or reset as specified by the SIM instruction.
- **VCC: +5 V supply** **PIN NO. 40**
- **VSS: Ground reference** **PIN NO. 20**

2.3 INPUT/OUTPUT DEVICES OF MICROPROCESSOR 8085:

8085A processor can be interfaced with various I/O devices through their controller peripheral chips. We have considered in present work following peripheral chips.

1. 82C55A (PPI) :- Programmable Peripheral Interface.
2. 8251A (USART):- Universal Synchronous/Asynchronous Receiver and Transmitter.

2.3.1 82C55A Programmable Peripheral Interface (PPI)⁴:-

Figure 2.2 shows Pin diagram and block diagram of 82C55A PPI chip.

• FUNCTIONAL DESCRIPTION:-

- **Data Bus buffer:** - This 3-state bi-directional 8-bit buffer is used to interface the 82C55A to the system data bus. Data is transmitted or received by the

⁴ 82C55A Programmable Peripheral Interface (PPI) INTEL® Datasheet

buffer upon execution of input or output instructions by the CPU. Control words and status information are also transferred through the data bus buffer.




FIGURE 2.2 Pin description and Functional block diagram of 82C55A

- **Read/write and control logic:** - The function of this is to manage all of the internal and external transfers of both Data and Control or status words. It accepts inputs from the CPU Address and Control buses and in turn, commands to both of the Control Groups.

($\overline{\text{CS}}$) Chip Select. A “LOW” on this input pin enables the communication between the 82C55A and the CPU.

($\overline{\text{RD}}$) Read. A “LOW” on this input pin enables the 82C55A to send the data or status information to the CPU on the data bus. In essence, it allows the CPU to “read from” the 82C55A.

($\overline{\text{WR}}$) Write. A “LOW” on this input pin enables the CPU to write data or control words into the 82C55A.

(A_0 and A_1) port select 0 and port select 1. These input signals, in conjunction with the $\overline{\text{RD}}$ and $\overline{\text{WR}}$ inputs, control the selection of one of the three ports or the control word register. They are normally connected to the least significant bits of the address bus (A_0 and A_1).

(RESET) Reset. A “HIGH” on this input initializes the control register to 9BH and all ports (A, B, C) are set to the input mode. “Bus hold” devices internal to the 82C55A will hold the I/O port inputs to a logic “1” state with a maximum hold current of 400 μA .

- **Group A and Group B controls:** - The functional configuration of each port is programmed by the systems software. In essence, the CPU “outputs” a control word to the 82C55A. The control word contains information such as “mode”, “bit set”, bit reset”, etc., that initializes the functional configuration of a 82C55A.

Each of the control blocks (Group A and Group B) accepts “commands” from the Read/Write Control logic, receives “control words” from the internal data bus and issues the proper commands to its associated ports.

Control Group A – Port A and Port C upper ($\text{C}_7 - \text{C}_4$)

Control Group B – Port B and Port C lower ($\text{C}_3 - \text{C}_0$)

The control word register can be both written and read as shown in the “Basic Operation” table. Figure 2.3 shows the control word format for both read and write operations. When the control word is read, bit D7 will always be a logic “1”, as this implies control word mode information.




FIGURE 2.3 Mode definition format for 82C55A

A1	A0	RD	WR	CS	INPUT OPERATION (READ)
0	0	0	1	0	PORT A → Data bus
0	1	0	1	0	PORT B → Data bus
1	0	0	1	0	PORT C → Data bus
1	1	0	1	0	Control word → Data bus
OUTPUT OPERATION (WRITE)					
0	0	1	0	0	Data bus → Port A
0	1	1	0	0	Data bus → port B
1	0	1	0	0	Data bus → port C
1	1	1	0	0	Data bus → Control word
DISABLE FUNCTION					
X	X	X	X	1	Data bus → Three-state
X	X	1	1	0	Data bus → Three-state

Table 2.1 82C55A BASIC OPERATION

- **Ports A, B and C:** - The 82C55A contains three 8-bit ports (A, B and C). All can be configured to a wide variety of functional characteristics by the system software but each has its own special features or “personality” to further enhance the power and flexibility of the 82C55A.




FIGURE 2.4 BUS-HOLD CONFIGURATION

Port A One 8-bit data output latch/buffer and one 8-bit data input latch. Both “pull-up” and “pull-down” bus-hold devices are present on port A. Bus-hold configuration for port A is shown in figure 2.4 (A).

Port B One 8-bit data input/output latch/buffer and one 8-bit data input buffer. Bus-hold configuration for port B is shown in figure 2.4 (B).

Port C One 8-bit data output latch/buffer and one 8-bit data input buffer (no latch for input). This port can be divided into two 4-bit ports under the mode control. Each 4-bit port contains a 4-bit latch and it can be used for the control signal output and status signal inputs in conjunction with ports A and B. Bus-hold configuration for port C is shown in figure 2.4 (B).

- **Operational description:-**

- **Mode selection:-** There are three basic modes of operation that can be selected by the system software:

Mode 0 – Basic Input/Output

Mode 1 – Strobed Input/Output

Mode 2 – Bi-directional Bus




FIGURE 2.5 BASIC MODE DEFINITIONS AND BUS INTERFACE

When the reset input goes “high”, all ports will be set to the input mode with all 24 port lines held at a logic “one” level by internal bus hold devices. After the reset is removed, the 82C55A can remain in the input mode with no additional initialization required. This eliminates the need to pull-up or pull-down resistors in all-CMOS designs. The control word register will contain 9BH. During the execution of the system program, any of the other modes may be selected using a single output instruction. This allows a single 82C55A to service a variety of peripheral devices with a simple software maintenance routine. Any port programmed as an output port is initialized to all zeros when the control word is written.

The modes for port A and port B can be separately defined, while port C is divided into two portions as required by the Port A and Port B definitions. All of the output registers, including the status flip-flops, will be reset whenever the mode is changed. Modes may be combined so that their functional definition can be “tailored” to almost any I/O structure.

The mode definitions and possible mode combination mode combinations may seem confusing at first, but after a cursory review of the complete device

operation a simple, logical I/O approach will surface. The design of the 82C55A has taken into account things such as efficient PC board layout, control signal definitions Vs. PC layout and complete functional flexibility to support almost any peripheral device with no external logic. Such design represents the maximum use of the available pins.

- **Single Bit Set/Reset feature:** - Any of the eight bits of port C can be set or reset using a single Output instruction. This feature reduce software requirement in control-based application.

When Port C is being used as status/control for Port A or B, these bits can be set or reset by using the Bit Set/Reset operation just as if they were output ports. Figure 2.5 shows Bit Set/Reset format for port C.




FIGURE 2.6 Bit Set/Rest Format

- **Interrupt Control Functions:-** When 82C55A is programmed to operate in mode 1 or mode 2, control signals are provided that can be used as interrupt request inputs to the CPU. The interrupt request signals, generated from port C, can be inhibited or enabled by setting or resetting the associated INTE flip-flop, using the bit set/reset of port C. This function allows the programmer to enable or disable a CPU interrupt by a specific I/O device without affecting any other device in the interrupt structure.

- **INTE Flip-Flop Definition:-**

(BIT-SET) – INTE is Set – Interrupt Enable

(BIT-RESET) – INTE is Reset – Interrupt Disable

- **Operating Modes:-**

- **Mode 0** (basic Input/Output). This functional configuration provides simple input and output operations for each of the three ports. No handshaking is required; data is simply written to or read from specific port.

Mode 0 Basic Functional Definitions

Two 8-bit ports and two 4-bit ports

Any port can be input or output


Outputs are latched

Input are not latched


16 different Input/Output configurations possible

A		B		Group A		#	Group B	
D4	D3	D1	D0	PORT A	PORT C (UPPER)		PORT B	PORT C (LOWER)
0	0	0	0	Output	Output	0	Output	Output
0	0	0	1	Output	Output	1	Output	Input
0	0	1	0	Output	Output	2	Input	Output
0	0	1	1	Output	Output	3	Input	Input
0	1	0	0	Output	Input	4	Output	Output
0	1	0	1	Output	Input	5	Output	Input
0	1	1	0	Output	Input	6	Input	Output
0	1	1	1	Output	Input	7	Input	Input
1	0	0	0	Input	Output	8	Output	Output
1	0	0	1	Input	Output	9	Output	Input
1	0	1	0	Input	Output	10	Input	Output
1	0	1	1	Input	Output	11	Input	Input
1	1	0	0	Input	Input	12	Output	Output
1	1	0	1	Input	Input	13	Output	Input
1	1	1	0	Input	Input	14	Input	Output
1	1	1	1	Input	Input	15	Input	Input

Table 2.2 Mode 0 port definition 16 combination for input/out configuration



Mode 0 Basic Input



Mode 0 Basic Output

FIGURE 2.7 Mode 0 Basic Input/Output timing diagram

- **Mode 1 – (Strobed Input/Output).** This functional configuration provides a means for transferring I/O data to or from a specified port in conjunction with strobes or “handshaking” signals. In mode 1, port A and port B use the lines on port C to generate or accept these “handshaking” signals.

Mode 1 Basic function Definitions:

Two Groups (Group A and Group B)

Each group contains one 8-bit port and one 4-bit control/data port

The 8-bit data port can be either input or output. Both inputs and outputs are latched

The 4-bit is used for control and status of the 8-bit port.

Input control Signal Definition:

STB (Strobe Input). A “LOW” on this input loads data into the input latch.




FIGURE 2.8 (A) Mode 1 Strobed Input definitions




FIGURE 2.8 (B) Mode 1 Strobed Input definitions timing diagram

FIGURE 2.8 Input Control Signal definition

IBF (Input Buffer Full flip-flop). A “HIGH” on this output indicates that the data has been loaded into the input latch: in essence, and

acknowledgment. IBF is set by \overline{STB} input being low and reset by the rising edge of the \overline{RD} input.

INTR (Interrupt Request). A “HIGH” on this output can be used to interrupt the CPU when an input device is requesting service. INTR is set by the condition: \overline{STB} is a “ONE”, IBF is a “ONE” and INTE is a “ONE”. It is reset by the falling edge of \overline{RD} . This procedure allows an input device to request service from the CPU by simply strobing its data into the port.

INTE A. Controlled by bit set/reset of PC₄.

INTE B. Controlled by bit set/reset of PC₂.

Output control Signal Definition:




FIGURE 2.9 (A) Mode 1 Strobed Output definitions




FIGURE 2.9 (B) Mode 1 Strobed Output definitions timing diagram

FIGURE 2.9 Output Control Signal definition

$\overline{\text{OBF}}$ (Output Buffer Full Flip-flop). The $\overline{\text{OBF}}$ output will go “LOW” to indicate that the CPU has written data out to be specified port. This does not mean valid data is sent out of the port at this time since $\overline{\text{OBF}}$ can go true before data is available. Data is guaranteed valid at the rising edge of $\overline{\text{OBF}}$. The $\overline{\text{OBF}}$ flip-flop will be set by the rising edge of the $\overline{\text{WR}}$ input and reset by $\overline{\text{ACK}}$ input being low.

$\overline{\text{ACK}}$ (Acknowledge Input). A “LOW” on this input informs the 82C55A that the data from port A or port B is ready to be accepted. In essence, a response from the peripheral device indicating that it is ready to accept data.

INTR (Interrupt Request). A “HIGH” on this output can be used to interrupt the CPU when an output device has accepted data transmitted by the CPU. INTR is set when $\overline{\text{ACK}}$ is a “ONE”, $\overline{\text{OBF}}$ is a “ONE” and INTE is a “ONE”. It is reset by the falling edge of $\overline{\text{WR}}$.

- **Mode 2 - (Strobed Bi-Directional Bus I/O).** The functional configuration provides a means for communicating with a peripheral device or structure on a single 8-bit bus for both transmitting and receiving data (Bi-Directional bus I/O). “HANDSHAKING” signals are provided to maintain proper bus flow discipline similar to mode 1. Interrupt generation and enable/disable function are also available.

Mode 2 Basic functional definitions:


Used in Group A only

One 8-bit, Bi-Directional bus port (port A) and 5-Bit control port (port C)


Both input and output are latched

The 5-bit control port (port C) is used for control and status for the 8-bit, Bi-Directional bus port (port A)

Bi-Directional Bus I/O Control Signal Definition:



Mode 2 control word and Mode 2 configuration



Mode 2 Bi-Directional timing diagram




FIGURE 2.10 (A) Mode 2 And Mode 0 Input/Output Configuration

INTR (Interrupt Request). A high on this output can be used to interrupt the CPU for both input or output operations.




FIGURE 2.10 (B) Mode 2 And Mode 1 Input/Output Configuration

FIGURE 2.10 MODE 2 COMBINATIONS

Output operations

$\overline{\text{OBF}}$ (Output Buffer Full). The $\overline{\text{OBF}}$ output will go “LOW” to indicate that the CPU has written data out to port A.

$\overline{\text{ACK}}$ (Acknowledge). A “LOW” on this input enables the three-state output buffer of port A to send out the data. Otherwise, the output buffer will be in the high impedance state.

INTE 1 (The INTE flip-flop associated with $\overline{\text{OBF}}$). Controlled by bit set/reset of PC4.

Input Operations

$\overline{\text{STB}}$ (Strobe input). A “LOW” on this loads data into the input latch.

IBF (Input Buffer Full Flip-Flop). A “HIGH” on this output indicates that data has been loaded into the input latch.

INTE 2 (The INTE flip-flop associated with IBF). Controlled by bit set/reset of PC4.

- **Special mode combination considerations:-** There are several combinations of modes possible. For any combination, some or all of port C lines are used for control or status. The remaining bits are either inputs or outputs as defined by a “Set Mode” command.

During a read of port C, the state of all the port C lines, except the $\overline{\text{ACK}}$ and $\overline{\text{STB}}$ lines, will be placed on the data bus. In place of the $\overline{\text{ACK}}$ and $\overline{\text{STB}}$ line states, flag status will appear on the data bus in the PC2, PC4 and PC6 bit positions as illustrated by Table 2.3.

INTERRUPT ENABLE FLAG	POSITION	ALTERNATE PORT C PIN SIGNAL (MODE)
INTE B	PC2	$\overline{\text{ACK}}_B$ (Output Mode 1) or $\overline{\text{STB}}_B$ (Input Mode 1)
INTE A2	PC4	$\overline{\text{STB}}_A$ (Input Mode 1 Or Mode 2)
INTE A1	PC6	$\overline{\text{ACK}}_A$ (Output Mode 1 Or Mode 2)

TABLE 2.3 INTERRUPT ENABLE FLAGS IN MODE 1 AND MODE 2

Though a “Write port C” command, only the port c pins programmed as outputs in a Mode 0 group can be written. No other pins can be affected by a “Write port C” command, nor can the interrupt enable flags be accessed.

To write to any port C output programmed as an output in Mode 1 group or to change an interrupt enable flag, the “Set/Reset port C Bit” command must be used.

With a “Set/Reset port C Bit” command, any port C line programmed as an output (including IBF and $\overline{\text{OBF}}$) can be written or an interrupt enable flag can be either set or reset. Port C lines programmed as inputs, including $\overline{\text{ACK}}$ and $\overline{\text{STB}}$ lines, associated with Port C are not affected by a “Set/Reset port C Bit” command. Writing to the corresponding port C bit positions of the $\overline{\text{ACK}}$ and $\overline{\text{STB}}$ lines with the “Set/Reset port C Bit” command will affect the Group A and Group B interrupt enable flags, as shown in Table 2.3.

- **Current drive capability:-** Any output on port A, B and C can sink or source 2.5mA. This feature allows the 82C55A to directly drive Darlington type drivers and high-voltage displays that require such sink or source current.
- **Reading Port C Status:-** In Mode 0, Port C transfers data to or from the peripheral device. When the 82C55A is programmed to function in Modes 1 and 2, port C generates or accepts “handshaking” signals with the peripheral device. Reading the contents of signals of port C allows the programmer to test or verify the “status” of each peripheral device and change the program flow accordingly.

There is not special instruction to read the status information from port C. A normal read operation of port C is executed to perform the function.




FIGURE 2.11 MODE 2 STATUS WORD FORMAT

2.3.2 8251A Universal Synchronous/Asynchronous Receiver and Transmitter (USART)⁵

Figure 2.12 shows Pin diagram and block diagram of 8251A PPI chip.

- **FUNCTIONAL DESCRIPTION:-**

- **General:** - The 8251A is Universal Synchronous/Asynchronous Receiver/Transmitter designed for a wide range of Intel Microprocessor such like 8048, 8080, 8085, 8086 and 8088. Like other I/O devices in a microcomputer system, its functional configuration is programmed by the system's software for maximum flexibility. The 8251A can support most serial data techniques in use, including IBM "Bi-sync".

In a communication environment an interface device must convert parallel format system data into serial format for transmission and convert incoming serial format data into parallel system data for reception. The interface device must also delete or insert bits or characters that are functionally unique to the communication technique. In essence, the

⁵ 8251A Universal Synchronous/Asynchronous Receiver and Trasmmitter (USART) INTEL® DATASHEET

interface should appear “transparent” to the CPU, a simple input or output of byte-oriented system data.




FIGURE 2.12 PIN DISCRIPTION AND BLOCK DIAGRAM OF 8251A

- **Data Bus Buffer:** - This 3-state Bi-Directional, 8-bit buffer is used to interface the 8251A to the system Data Bus. Data is transmitted or received by the buffer upon execution of INput or OUTput instruction of the CPU. Control words, Command words and Status information are also transmitted through the Data Bus Buffer. The Command Status, 8-bit registers communicate with the system bus through the Data Bus Buffer. This functional block accepts inputs from the system Control bus and generates control signals for overall device operation. It contains the Control Word Register and Command Word Register that store the various control formats for the device functional definition.
- **RESET (Reset):**- A “HIGH” on this input forces the 8251A into an “Idle” mode. The device will remain at “Idle” until a new set of control words is written into the 8251A to program its functional definition. Minimum RESET pulse width is 6 t_{CY} (clock must be running).
A command reset operation also puts the device into the “Idle” state.
- **CLK (Clock):**- The CLK input is used to generate internal device timing and is normally connected to the Phase 2 (TTL) output of the Clock Generator. No external inputs or outputs are reference to CLK but the frequency of CLK must be greater than 30 times the Receiver or Transmitter data bit rate.
- **\overline{WR} (Write):**- A “LOW” on this input informs the 8251A that the CPU is writing data or control words to the 8251A.
- **\overline{RD} (Read):**- A “LOW” on this input informs the 8251A that the CPU is reading data or status information from the 8251A.
- **C/ \overline{D} (control/Data):**- This input, in conjunction with the \overline{WR} and \overline{RD} inputs, informs the 8251A that the word on the Data Bus is either a data character, control word or status information.

1 = control / status; 0 = data

C/ \overline{D}	\overline{RD}	\overline{WR}	\overline{CS}	
0	0	1	0	8251A DATA → DATA BUS
0	1	0	0	DATA BUS → 8251A DATA
1	0	1	0	STATUS → DATA BUS
1	1	0	0	DATA BUS → CONTROL

X	1	1	0	DATA BUS \rightarrow 3-STATE
X	X	X	1	DATA BUS \rightarrow 3-STATE

- **$\overline{\text{CS}}$ (Chip Select):-** A “LOW” on this input selects the 8251A. No reading or writing will occur unless the device is selected. When $\overline{\text{CS}}$ is high, the Data Bus is in the float state and $\overline{\text{RD}}$ and $\overline{\text{WR}}$ have no effect on the chip.
- **Modem Control:-** The 8251A has a set of control inputs and outputs that can be used to simplify the interface to almost any modem. The modem control signals are general purpose in nature and can be used for functions other than modem control, if necessary.
- **$\overline{\text{DSR}}$ (Data Set Ready):-** The $\overline{\text{DSR}}$ output signal is a general-purpose, 1-bit inverting output port. Its condition can be tested by the CPU using Status Read operation. The $\overline{\text{DSR}}$ input is normally used to test modem condition such as Data Set Ready.
- **$\overline{\text{DTR}}$ (Data Terminal Ready):-** The $\overline{\text{DTR}}$ output signal is a general-purpose, 1-bit inverting output port. It can be set “LOW” by programming the appropriate bit in the Command instruction word. The $\overline{\text{DTR}}$ output signal is normally used for modem control such as Data Terminal Ready.
- **$\overline{\text{RTS}}$ (Request to Send):-** The $\overline{\text{RTS}}$ output signal is a general-purpose, 1-bit inverting output port. It can be set “LOW” by programming the appropriate bit in the Command instruction word. The $\overline{\text{RTS}}$ output signal is normally used for modem control such as Request to Send.
- **$\overline{\text{CTS}}$ (Clear to Send):-** A “LOW” on this input enables the 8251A to transmit serial data if the T_x Enable bit in the Command byte is set to a “ONE”. If either a T_x Enable off or $\overline{\text{CTS}}$ off condition occurs while, the T_x will transmit all the data in the USART, written prior to T_x Disable Command before shutting down.
- **Transmitter Buffer:-** The transmitter Buffer accepts parallel data from the Data Bus Buffer, converts it to a serial bit stream, inserts the appropriate characters or bits (based on the communication technique) and output a composite serial stream of data on the T_xD output pin on the falling edge $\overline{T_xC}$. The transmitter will begin transmission upon being enabled if $\overline{\text{CTS}} = 0$. The T_xD line will be held in the marking state

immediately upon a master Reset or when T_X enable or \overline{CTS} is off or the transmitter is empty.

- **Transmitter Control:-** The transmitter Control manages all activities associated with the transmission of serial data. It accepts and issues signals both externally and internally to accomplish this function.
- **T_XRDY (Transmitter Ready):-** This output signals the CPU that the transmitter is ready to accept a data character. The T_XRDY output pin can be used as an interrupt to the system, since it is masked by $T_XEnable$; or for polled operation, the CPU can check T_XRDY using Status Read operation. T_XRDY is automatically reset by the leading edge of WR when a data character is loaded from the CPU.

Note that when using the polled operation, the T_XRDY status bit is *not* masked by $T_XEnable$, but will only indicate the Empty/Full Status of the T_X Data Input Register.

- **T_XE (Transmitter Empty):-** When the 8251A has no characters to send, the T_XEMPTY output will go “HIGH”. It resets upon receiving a character from CPU if the transmitter is enable. T_XEMPTY remains high when the transmitter is disable. T_XEMPTY can be used to indicate the end of a transmission mode, so that the CPU “knows” when to “turn the line around” in the half-duplex operational mode.

In the Synchronous mode, a “HIGH” on this output indicates that a character has not been loaded and the **SYNC** character or characters are about to be or are being transmitted automatically as “fillers”. T_XEMPTY does not go low when the **SYNC** characters are being shifted out.

- **$\overline{T_XC}$ (Transmitter Clock):-** The transmitter Clock controls the rate at which the character is to be transmitted. In the Synchronous transmission mode, the Baud Rate (1x) is equal to the $\overline{T_XC}$ frequency. In Asynchronous transmission mode, the baud rate is a fraction of the actual T_XC frequency. A portion of the mode instruction selects the factor: it can be 1, 1/16 or 1/64 the $\overline{T_XC}$. The falling edge of $\overline{T_XC}$ shifts the serial data out of the 8251A.
- **Receiver Buffer:-** The receiver accepts serial data, converts this serial input to parallel format, checks for bits or characters that are unique to the

communication technique and sends an “assembled” character to the CPU. Serial data is input to R_XD pin, and is clocked in on the rising edge of R_XC.

- **Receiver control:-** This function block manage all receiver-related activity which consists of the following features.

The R_XD initialization circuit prevents the 8251A from mistaking an unused input line for an active low data line in the “break condition”. Before starting to receive serial characters on the R_XD line, a valid “1” must first be detected after chip master Reset. Once this has been determined, a search for a valid low (Start bit) is enabled. This feature is only active in the asynchronous mode, and is only done once for each master Reset.

The Flase Start bit detection circuit prevents false starts due to a transient noise spike by first detecting the falling edge and then strobing the normal center of the Start bit (R_XD = low).

Parity error detection sets the corresponding status bit.

The framing Error status bit is set if the Stop bit is absent at the end of the data byte (asynchronous mode).

- **R_XRDY (Receiver Ready):-** This output indicates that the 8251A contains a character that is ready to be input to the CPU. R_XRDY can be connected to the interrupt structure of the CPU or, for polled operation, the CPU can check the condition of R_XRDY using a Status Read operation.

R_XEnable, when off, holds R_XRDY in the Reset Condition. For Asynchronous mode, to set R_XRDY, the Receiver must be enabled to sense a Start bit and a complete charater must be assembled and transferred to the Data Output Register. For Synchronous mode, to set R_XRDY, the Receiver must be enabled and a character must finish assembly and be transferred to the Data Output Register.

Failure to read the receiver character from the R_X Data Output Register prior to the assembly of the next R_X Data character will set overrun condition error and the previous character will be written over and lost. If the R_X Data is being read by the CPU when the internal transfer is occurring, overrun error will be set and the old character will be lost.

- **$\overline{R_xC}$ (Receiver Clock):-** The receiver Clock controls the rate at which the character is to be received. In the Synchronous mode, the Baud Rate (1x) is equal to the actual frequency of the $\overline{R_xC}$. In Asynchronous mode, the Baud Rate is a fraction of the actual $\overline{R_xC}$ frequency. A portion of the mode instruction selects this factor: 1, 1/16 or 1/64 the $\overline{R_xC}$. Data is sampled into the 8251A on the rising edge of $\overline{R_xC}$.
- **SYNDET / BRKDET (SYNC Detect / Break Detect):-** This pin is used in Synchronous mode for SYNDET and may be used as either input or output programmable through the Control Word. It is reset to output mode low upon RESET. When used as an output (internal Sync mode), the SYNDET pin will go “HIGH” to indicate that the 8251A has located the SYNC character in the Receive mode. If the 8251A is programmed to use double Sync characters (bi-sync), then SYNDET will go “HIGH” in the middle of the last bit of the second Sync character. SYNDET is automatically reset upon a Status Read operation.
When used as an input (external SYNC detect mode), a positive going signal will cause the 8251A to start assembling data characters on the rising edge of the next $\overline{R_xC}$. Once in SYNC, the “HIGH” input signal can be removed. When External SYNC Detect is programmed, internal SYNC Detect is disabled.
- **BREAK (Async Mode Only):-** This output will go high whenever the receiver remains low through two consecutive stop bit sequences (including the start bits, data bits, and parity bits). Break Detect may also be read as a Status bit. It is reset only upon master chip Reset or R_x Data returning to a “one” state.
- **Operational description:-**
 - **General:-** The complete functional definition of the 8251A is programmed by the system’s software. A set of control words must be sent out by the CPU to initialize the 8251A to support the desired communications format. These control words will program the: BAUD RATE, CHARACTER LENGTH, NUMBER OF STOP BITS, SYNCHRONOUS or a SYNCHRONOUS OPERATION, EVEN/ODD/OFF PARTY, etc. in the

synchronous mode, operations are also provided to select either internal or external synchronization.

Once programmed, the 8251A is ready to perform its communication functions. The T_XRDY output is raised “HIGH” to signal the CPU that the 8251A is ready to receive a data character from the CPU. This output (T_XRDY) is reset automatically when the CPU writes a character into the 8251A. On the other hand, the 8251A receives serial data from the MODEM or I/O device. Upon receiving an entire character, the R_XRDY is raised “HIGH” to signal the CPU that the 8251A has a complete character ready for the CPU to fetch. R_XRDY is reset automatically upon the CPU data read operation.

The 8251A cannot begin transmission until the T_XENABLE (Transmitter Enable) bit is set in the Command instruction and it has received a Clear To Send ($\overline{\text{CTS}}$) input. The TXD output will be held in the marking state upon Reset.

- **Programming the 8251A:-** Prior to starting data transmission or reception, the 8251A must be loaded with a set of control words generated by the CPU. These control signals define the complete functional definition of the 8251A and must immediately follow a Reset operation (internal or external)

The control words are split into two formats:

1. Mode instruction
2. Command instruction

Mode instruction:- This instruction defines the general operational characteristics of the 8251A. It must follow a Reset operation (internal or external). Once the Mode instruction has been written into the 8251A by the CPU, SYNC characters or Command instructions may be written.

Command instruction:- This instruction defines a word is used to control the actual operation of the 8251A.

Both the Mode and Command instructions must conform to a specified sequence for proper device operation. The Mode instruction must be written immediately following a Reset operation, prior to using the 8251A for data communication.




FIGURE 2.13 TYPICAL DATA BLOCK

All control words written into the 8251A after the Mode instruction will load the Command instruction. Command instructions can be written into the 8251A at any time in the data block during the operation of the 8251A. To return to the Mode instruction format, the master Reset bit in the Command instruction word can be set to initiate an internal Reset operation which automatically places the 8251A back into the Mode instruction format. Command instructions must follow the Mode instruction or Sync characters.

- **Mode Instruction Definition:** - The 8251A can be used for either Asynchronous or Synchronous data communication. To understand how the Mode instruction defines the functional operation of the 8251A, the designer can best view the device as two separate components, one Asynchronous and other Synchronous, sharing the same package. The format definition can be changed only after a Master Chip Reset. For explanation purposes the two formats will be isolated.

When parity is enabled it is not considered as one of the data bits for the purpose of programming word length. The actual parity bit received on the R_X Data line cannot be read on the Data Bus. In the case of programmed character length of less than 8-bits, the least significant Data Bus bits will hold the data; unused bits are “don’t care” when writing data to the 8251A and will be “zeros” when reading the data from the 8251A. Below Figure 2.14 shows Mode instruction format for Asynchronous Mode.





FIGURE 2.14 ASYNCHRONOUS MODE INSTRUCTION FORMAT

- Asynchronous Mode (Transmission):-** Whenever a data character is sent by the CPU the 8251A automatically adds a Start bit (low level) followed by the data bits (least significant bit first), and the programmed number of Stop bits to each character. Also, an even or odd Parity bits is inserted prior to the Stop bit(s), as defined by the Mode instruction. The character is then transmitted as a serial data stream on the T_xD output. The serial data is shifted out on the falling edge of the $\overline{T_xC}$ at a rate equal to 1, 1/16 or 1/64 that of the $\overline{T_xC}$, as defined by the Mode instruction. BREAK characters can be continuously sent to the T_xD if commanded to do so.


When no data characters have been loaded into the 8251A the T_xD output remains “HIGH” (marking) unless a BREAK (continuously low) has been programmed.
- Asynchronous Mode (Receiver):-** The R_xD line is normally high. A falling edge on this line triggers the beginning of a START bit. The validity of this START bit is checked by again strobing this bit at its nominal center (16X or 64X mode only). If a low is detected again, it is

valid STRAT bit, and the bit counter will start counting. The bit counter thus locates the center of the data bits, the parity bit (if it exists) and the stop bit, if parity error occurs, the parity error flag is set. Data and parity bits are sampled on the R_{xD} pin with the rising edge of the R_{xC} . If a low level is detect as the STOP bit the Framing Error flag will be set. The STOP bit signals the end of a character. Note that the *receiver* requires only one stop bit, regardless of the number of stop bit programmed. This character is then loaded into the parallel I/O buffer of the 8251A. The R_{xRDY} pin is raised to signal the CPU that a character is ready to be fetched. If a previous character has not been fetched by the CPU, the present character replaces it in the I/O buffer, and the OVERRUN Error flag is raised (thus the previous character is lost). All of the error flags can be reset by an Error Reset instruction. The occurrence of any of these errors will not affect the operation of the 8251A. Below figure 2.15 shows Asynchronous Mode transmission and receiver format.



FIRGURE 2.15 ASYNCHRONOUS MODE TRANSMITTER AND RECEIVER

FORMAT



- **Synchronous Mode (Transmission):-** The TxD output is continuously high until the CPU sends its first character to the 8251A which usually is a SYNC character. When the \overline{CTS} line goes low, the first character is serially transmitted out. All characters are shifted out on the falling edge of \overline{TxC} . Data is shifted out at the same rate as the \overline{TxC} .

Once transmission has started, the data stream at the TxD output must continue at the \overline{TxC} rate. If the CPU does not provide the 8251A with a data character before the 8251A Transmitter Buffers become empty. The SYNC characters (or character if in single SYNC character mode) will be automatically inserted in the TxD data stream. In this case, the $TxEMPTY$ pin is raised high to signal that the 8251A is empty and SYNC characters are being sent out. $TxEMPTY$ does not go low when SYNC is being shifted out. The $TxEMPTY$ pin is internally reset by a data character being written into the 8251A. Below Figure 2.16 shows Mode instruction format for Synchronous Mode.




FIGURE 2.16 SYNCHRONOUS MODE INSTRUCTION FORMAT

- Synchronous Mode (Receive):-** In this mode, character synchronization can be internally or externally achieved. If the SYNC mode has been programmed, ENTER HUNT command should be included in the first command instruction word written. Data on the R_{XD} pin is then sampled on the rising edge of $\overline{R_XC}$. The content of the R_X buffer is compared at every bit boundary with the first SYNC character until a match occurs. If the 8251A has been programmed for two SYNC characters, the subsequent received character is also compared; when both SYNC characters have been detected, the USART ends the HUNT mode and is in character synchronization. The SYNDET pin is then set high, and is reset automatically by the STATUS READ. If parity is programmed, SYNDET will not be set until the middle of the parity bit instead of the middle of the last data bit.

In the external SYNC mode, synchronization is achieved by applying a high level on the SYNDET pin, thus forcing the 8251A out of the HUNT mode. The high level can be removed after one $\overline{R_XC}$ cycle. An ENTER HUNT command has no effect in the Asynchronous mode of operation. Parity error and overrun error are both checked in the same way as in the Asynchronous R_X mode. Parity is checked when not in HUNT, regardless of whether the receiver is enabled or not.




FIGURE 2.17 SYNCHRONOUS MODE DATA FORMAT

The CPU can command the receiver to enter the HUNT mode if synchronization is lost. This will also set all the used character bits in the buffer to a “one”, thus preventing possible false SYNDET caused by data

that happens to be in R_x Buffer at ENTER HUNT time. Note that the SYNDET FLIP-FLOP is reset at each Status Read, regardless of whether internal or external SYNC has been programmed. This does not cause the 8251A to return to the HUNT mode. When in SYNC mode, but not in HUNT, Sync detection is still functional, but only occurs at the “known” word boundaries. Thus, if one Status Read indicates SYNDET and a second Status Read also indicates SYNDET, then the programmed SYNDET characters have been received since the previous Status Read. When external SYNDET mode is selected, internal Sync detect is disabled, and the SYNDET FLIP-FLOP may be set at any bit boundary.

- **COMMAND INSTRUCTION DEFINITION:-** Once the function definition of the 8251A has been programmed by the Mode instruction and the Sync characters are loaded (if in Sync mode) then the device is ready to be used for data communication. The Command instruction controls the actual operation of the selected format. Functions such as: Enable Transmit/Receive, Error Reset and Modem Controls are provided by the Command instruction. Below Figure 2.18 shows command instruction format.




FIGURE 2.18 COMMAND INSTRUCTION FORMAT

Once the mode instruction has been written into the 8251A and Sync character inserted if necessary, then all further “control writes” ($C/\overline{D} = 1$)

will load a command instruction. A Reset Operation (internal or external) will return the 8251A to the Mode Instruction format.

- **STATUS READ DEFINITION:-** In data communication systems it is often necessary to examine the “status” of the active device to ascertain if errors have occurred or other conditions that require the processor’s attention. The 8251A has facilities that allow the programmer to “read” the status of the device at any time during the functional operation.

A normal “read” command is issued by the CPU with $C/\overline{D} = 1$ to accomplish this function. Below Figure 2.19 shows Status read format for 8251A.




FIGURE 2.19 STATUS READ FORMAT

Some of the bits in the Status Read format have identical meaning to external output pins so that the 8251A can be used in a completely polled or interrupt-driven environment. T_xRDY is an exception.

2.4 MEMORY ORGANIZATION OF 8085A^{6,7,8}:-

8085A is mostly interfaced with RAM and EPROM memory chips. We know that 8085A has 16-address lines. This enables it to address 64 Kilobytes (KB) of memory locations. To make a useful system 8085 generally EPROM and RAM chips together comprise this address space. 6264 is a commonly used RAM chip with 2764A and 27128 EPROM chips widely used chip with 8085A. Figure 2.20 and 2.21 shows pin diagram of EPROM 2764A and RAM 6264 respectively.

The address space of 8085A in Hexadecimal (HEX) location induces from 0000H to FFFFH. Normally, in memory organization of 8085A first few Kilobytes of memory locations are used for EPROM area and rest are used for RAM area.

A typical memory organization of 8085A is shown in Figure 2.22 and 2.23. For interfacing 2764A with 8085A a decoder 74LS155 and a latching IC 74LS373 are used. The interfacing circuit for the same is shown in Figure 2.23. Note that this circuit is a part of the detailed circuitry of microprocessor trainer kit.




FIGURE 2.20 PIN DIAGRAM OF 2764A EPROM

⁶ “0000 to 8085 Introduction to Microprocessor for Engineers and scientists” 2nd edition, P. K. Ghosh and P. R. Sridhar

⁷ “Microprocessor Architecture, Programming and Application with the 8085” 3rd Ed, R. S. Gaonkar

⁸ Intel® Datasheet




FIGURE 2.21 PIN DIAGRAM OF 6264 RAM

IC 74LS373 de-multiplexes the AD₀ to AD₇ lines of 8085A, when ALE becomes high and it enables IC 74LS373 through its pin no. 11 (G), to latch the address A₀ to A₇. Active low enable pin no. 1 that is \overline{OC} of IC 74LS373 is permanently grounded. The output of Q₀ to Q₇ of IC 74LS373 (i.e. A₀ to A₇ address lines) are connected with the address lines A₀ to A₇ of EPROM 2764A. The rest of the address lines of 2764A, i.e. A₈ to A₁₂ address lines are connected with corresponding address lines of 8085A. The EPROM 2764A has a pin named OE which helps to read data out. This \overline{OE} pin directly connected with the \overline{RD} of 8085A. Also pin \overline{PGM} and V_{PP} are connected with V_{CC}.




Figure 2.22 EPROM 2764 INTERFACING CIRCUIT FOR 8085A




Figure 2.23 RAM 6264 INTERFACING CIRCUIT FOR 8085A

The chip selection is controlled by the decoder 74LS155. 74LS155 is used to select the memory chips 2764A (EPROM), 6264 (RAM) and I/O chips 8279 and 8255.

To separate the memory and I/O device the output pins of 74LS155 are divided into two groups that is 1Y0, 1Y1, 1Y2 and 1Y3 are for I/O device selection and 2Y0, 2Y1, 2Y2 and 2Y3 are for memory chip selection.

74LS155 has four enable pins out of which three are active low and one remaining two (where one is active low and another is active high) are connected with IO/ \overline{M} pin of 8085A. Here, active high is connected with enabling of outputs of internal decoder 1 of 74LS155. While active low is connected with the internal decoder-2 of 74LS155. Hence, whenever IO/ \overline{M} pin of 8085A is high, I/O devices are selected, and when IO/ \overline{M} is low, memory chips are selected. This we can explain as below table 2.4

IO/ \overline{M}	A (A_{14})	B (A_{15})	SELECTION
0	0	0	EPROM 2764A (2Y0)
0	1	0	RAM 6264 (2Y1)

TABLE 2.4: SELECTION USING ADDRESS LINES

The interfacing circuit of RAM 6264 involves 74LS373 and 74LS155 and 8085. IC 74LS373 and 74LS155 are having the same connection details with the 8085A as discussed above. The only difference in this one is that the A and B input lines of 74LS155 selects 6264 through output pin 2Y, by accepting $A_{15}=0$, $A_{14}=1$. As shown in above table.

The detailed circuit diagram is shown in figure 2.23. Note that since this is Read/Write memory one should connect \overline{RD} and \overline{WR} pins with 6264. In 8085A system \overline{WR} is connected with \overline{WR} and \overline{RD} is connected with \overline{OE} of 6264. 6264 has two chip select lines i.e. CS_1 and CS_2 . CS_1 is driven by 74LS155 while CS_2 is connected with V_{CC} .

From Figure 2.23 we learn that the EPROM memory area ranges from 0000H to 1FFFH. Similarly, from Figure 2.24 the RAM area extends from 4000H to 5FFFH.

Such type of memory maps help to understand the memory management aspect of the system.



CHAPTER 3

BASICS OF MICROCONTROLLER 89C51



3.1 **INTRODUCTION** :-

The 89C51 is an embedded microcontroller, a chip which has a computer processor with all its support functions, memory and I/O built into the device. These built in functions minimize the need for external circuits and devices to be designed in the final application. The 89C51 is a member of the Microcontroller-51 family. The features of the 89C51 are:

- Compatible with MCS-51 products
- 4K bytes of In-System reprogrammable flash memory
 - Endurance: 1,000 write/erase cycles
- Fully static operation: 0 Hz to 24 MHz
- Three-level program memory lock
- 128 x 8-bit internal RAM
- 32 programmable I/O lines
- Two 16-bit Timer/Counter
- Six interrupt sources
- Programmable Serial channel
- Low-Power idle and Power-Down Modes

It is also a low-power, high-performance CMOS 8-bit microcontroller with 4K bytes of flash Programmable and Erasable Read Only Memory (PEROM). The on chip flash memory allows the program memory to be reprogrammed in system or by a conventional non-volatile memory programmer. By combining a versatile 8-bit CPU with flash on a monolithic chip, the 89C51 is a powerful microcomputer which provides a highly flexible and cost effective solution to many embedded control applications.

Figure 3-1 shows the pin configurations of 89C51 microcontroller.




FIGURE 3.1 PIN CONFIGURATION OF 89C51 MICROCONTROLLER

Pin Description:-

VCC

Pin no. 40

Supply voltage +5V.

GND

Pin no. 20

Ground

XTAL1

Pin no. 19

Input to the inverting oscillator amplifier and input to the internal clock operating circuit.

XTAL2

Pin no. 18

An output from the inverting oscillator amplifier clock..

RST

Pin no. 09

Reset input. A high on this pin for two machine cycles while the oscillator is running resets the device.

ALE/PROG

Pin no. 30

Address Latch Enable output pulse for latching the low byte of the address during accesses to external memory. This pin is also the program pulse input (PROG) during flash programming.

PSEN

Pin no. 29

Program store enable is read strobe to external program memory. When the 89C51 is executing code from external program memory, PSEN activations are skipped during each access to external data memory.

$\overline{\text{EA}}$ /VPP**Pin no. 31**

External Access Enable. $\overline{\text{EA}}$ must be strapped to GND in order to enable the device to fetch code from external program memory locations starting at 0000H up to FFFFH. EA should be connected to Vcc for internal program execution. This pin also receives the 12v programming enable voltage (Vpp) during programming, for parts that require 12-volt Vpp.

Port 0**Pin no. 39 to 32**

Port 0 is an 8-bit open-drain Bi-Directional I/O port. As an output port, each pin can sink eight TTL inputs. When 1's are written to port 0 pins, the pins can be used as high impedance inputs. It can also be configured to be the multiplexed low order address/data bus during accesses to external program and data memory. In this mode P0 has internal pull-ups. It also receives the code bytes during flash programming, and outputs the code bytes during program verification. External pull-ups are required during program verification.

Port 1**Pin no. 01 to 08**

Port 1 is an 8-bit bi-directional I/O port with internal pull-ups. The port 1 output buffers can sink/source four TTL inputs. When 1's are written to port 1 pin they are pulled high by the internal pull-ups and can be used as inputs. As inputs, port 1 pins that are externally being pulled low will source current (I_{IL}) because of the internal pull-ups. Port 1 also receives the low-order address bytes during flash programming and verification.

Port 2**Pin no. 21 to 28**

Port 2 is an 8-bit bi-directional I/O port with internal pull-ups. The port 2 output buffers can sink/source four TTL inputs. When 1's are written to port 2 pins they are pulled high by the internal pull-ups and can be used as inputs. As inputs, port 2 pins that are externally being pulled low will source current (I_{IL}) because of the internal pull-ups. It emits the high order address byte during fetches from external program memory and during accesses to external data memory the use 16-bit addresses. During the accesses to external data memory that use 8-bit addresses, port 2 emits the contents of the P2 special function register. It also receives the high order address bits and some control signals during flash programming and verification.

Port 3

Pin no. 10 to 17

Port 3 is an 8-bit Bi-Directional I/O port with internal pull-ups. The port 3 output buffers can sink/source four TTL inputs. When 1's are written to port 3 pins they are pulled high by the internal pull-ups and can be used as inputs. As inputs, port 3 pins that are externally being pulled low will source current (I_{IL}) because of the pull-ups. It also serves the function of various special features of the 89C51 as shown below in table 3-1:

Port Pin	Alternate Function
P3.0	RXD (serial input port)
P3.1	TXD (serial output port)
P3.2	INT0 (external interrupt 0)
P3.3	INT1 (external interrupt 1)
P3.4	T0 (timer 0 external input)
P3.5	T1 (timer 1 external input)
P3.6	WR (external data memory write strobe)
P3.7	RD (external data memory read strobe)

TABLE 3.1 PORT 3 DUAL FEATURES

It also receives some control signals for Flash programming and verification.

3.2 Major Blocks of Microcontroller 89C51

The major blocks of microcontroller 89C51 are:

1. Special Function Register (SFR)
2. Accumulator
3. B Register
4. R Register
5. Program Status Word (PSW)
6. Stack Pointer (SP)
7. Data Pointer (DPTR)
8. Ports 0 to 3
9. Serial Data Buffer
10. Timer Register
11. Control Register

Figure 3-2 shows a function block diagram of the 89C51 microcontroller.




FIGURE 3.2 BLOCK DIAGRAM OF 89C51

- **SPECIAL FUNCTION REGISTER (SFR):**

The 89C51 is a flexible microcontroller with a relatively large number of modes of operations. This operating mode of 89C51 can be inspected as well as changed by manipulating the values of the 89C51's Special Function Registers (SFRs). SFRs are accessed as if they were normal Internal RAM. The only difference is that Internal RAM is from address 00h through 7Fh whereas SFR register exist in the address range of 80h through FFh. Each SFR has an address (80h through FFh) and a name. Table 3-2 contains a list of all the SFRs and their addresses.

Symbol	Name	Address
*ACC	Accumulator	0E0h
*B	B Register	0F0h
*PSW	Program Status Word	0D0h
SP	Stack Pointer	81h
DPTR	Data Pointer 2 Bytes	
DPL	Low Byte	82h
DPH	High Byte	83h
*P0	Port 0	80h
*P1	Port 1	90h
*P2	Port 2	0A0h
*P3	Port 3	0B0h
*IP	Interrupt Priority control	0B8h
*IE	Interrupt Enable control	0A8h
TMOD	Timer/Counter Mode Control	89h
*TCON	Timer/Counter Control	88h
TH0	Timer/Counter 0 High Byte	8Ch
TL0	Timer/Counter 0 Low Byte	8Ah
TH1	Timer/Counter 1 High Byte	8Dh
TL1	Timer/Counter 1 Low Byte	8Bh
*SCON	Serial Control	98h
SBUF	Serial Data Buffer	99h
PCON	Power Control	87h

* = Bit Addressable

TABLE 3.2 LIST OF SFRS AND THEIR ADDRESSES

- **ACCUMULATOR**

ACC is the Accumulator register. The mnemonics for Accumulator-Specific instructions, however, refer to the Accumulator simply as A.

- **B REGISTER**

The B register is used during multiply and divide operations. For other instructions it can be treated as another scratch pad register.

- **R REGISTER**

The “R” registers are a set of eight registers that are named R0, R1, R2, R3, R4, R5, R6, and R7. Along with accumulator “R” registers are very important “helper” registers. Accumulator alone would not be very useful if it were not for these “R” registers. They are used to temporarily store values.

- **PROGRAM STATUS WORD**

The PSW register contains program status information as detailed in figure 3-3.

(MSB)					(LSB)		
CY	AC	F0	RS1	RS0	OV	-	P
SYMBOL	POSITION		NAME AND SIGNIFICANCE				
CY	PSW.7		Carry flag.				
AC	PSW.6		Auxiliary carry flag. (for BCD operation)				
F0	PSW.5		Flag 0 (available to the user for general purposes.)				
RS1	PSW.4		Register bank select control bits 1 &				
RS0	PSW.3		0, Set/Cleared by software to determine working register bank				
OV	PSW.2		Overflow flag.				
-	PSW.1		User defined flag.				
P	PSW.0		Parity flag.				
Set/Cleared by hardware each instruction cycle to indicate an odd/even number of “one” bits in the accumulator, i.e. even parity.							
NOTE:							
THE CONTENTS OF (RS1, RS0) ENABLE THE WORKING REGISTER BANKS AS FOLLOWS:							
		(0, 0)	-	BANK 0(00H - 07H)			
		(0, 1)	-	BANK 1(08H - 0FH)			
		(1, 0)	-	BANK 2(10H - 17H)			
		(1, 1)	-	BANK 3(18H - 1FH)			

FIGURE 3.3 PROGRAM STATUS WORD REGISTER

- **STACK POINTER**

The Stack Pointer Register is 8 bits wide. It is incremented before data is stored during PUSH and CALL executions. While the stack may reside anywhere in on-chip RAM, the Stack Pointer is initialized to 07H after a reset. This causes the stack to begin at location 08H.

- **DATA POINTER**

The Data Pointer (DPTR) consists of a high byte (DPH) and a low byte (DPL). Its intended function is to hold a 16-bit address. It may be manipulated as a 16-bit register or as two independent 8-bit registers.

- **PORTS 0 TO 3**

P0, P1, P2, and P3 are the SFR latches of Ports 0, 1, 2, and 3 respectively.

- **SERIAL DATA BUFFER**

The Serial Data Buffer is actually two separate registers, a transmit buffer and a receive buffer register. When data is moved to SBUF, it goes to the transmit buffer where it is held for serial transmission. (Moving a byte to SBUF is what initiates the transmission.) when data is moved from SBUF, it comes from the receive buffer.

- **TIMER REGISTER**

Register pairs (TH0, TL0), and (TH1, TL1) are the 16-bit counting registers for Timer/Counters 0, and 1, respectively.

- **CONTROL REGISTER**

Special Function Registers IP, IE, TMOD, TCON, T2CON, SCON, and PCON contain control and status bits for the interrupt system, the Timer/Counters, and the serial port.

3.3 **Input-Output Devices of Microcontroller 89C51**

Four ports P0, P1, P2, and P3 of 89C51 microcontroller are the main Input/Output devices. The four ports of the 89C51, P0, P1, P2, and P3 each use eight pins, making them 8-bit ports. Port 0 and Port 2 can be used for either address or data. Port 3 can be used to provide interrupt and serial communication signals. Port 1 is used for data only, no dual function. For this reason, 24 of the pins may each be used for one of two entirely different functions.

Address corresponding to each port is as follow:

Port 0 -	80h
Port 1 -	90h
Port 2 -	A0h
Port 3 -	B0h

All ports are bit addressable. The port pins are also TTL as well as CMOS compatible.

- **P1-P3 STRUCTURE AND OPERATION**

All four ports in the 89C51 are Bi-Directional. Each consists of a latch (Special Function Register P0 through P3), an output driver, and an input buffer. The output drivers of Ports 0 and 2, and input buffers of Port 0, are used in accesses to external memory. All the Port 3 pins are multifunctional. They are not only port pins, but also serve the functions of various special features. Figure 3.4 shows the structure of P1 and its components.




FIGURE 3.4 89C51 PORT1 STRUCTURE

The other ports P2 and P3 are basically the same except with extra circuitry to allow their dual functions. [P0 is also having the same structure but without load (R1) as shown in figure 3.4].

The 89C51 ports have both the latch and buffer. Now the question is, in reading the port, are we reading the status of the latch? It totally depends on which instruction we are using. Therefore, when reading the ports there are two possibilities:

1. Reading the input pin, or
2. Reading the latch.

To make any bits of 89C51 an input port, we first must write a 1 (logic high) to that bit. Look at the following sequences of events to see why.

- **READING THE INPUT PIN**

To make any bits of 89C51 an input port, we first must write a 1 (logic high) to that bit. Look at the following sequences of events to see why.

1. By writing 1 to the port bit it is written to the latch and the D latch has “high” on its Q. Therefore, $Q = 1$ and $\overline{Q} = 0$.

2. Since $\overline{Q} = 0$ and is connected to the transistor M1 gate, the M1 transistor is off.
3. When the M1 transistor is off, it blocks any path to the ground for any signal connected to the input pin and the input signal is directed to the tri-state BUF2.
4. When reading the input port in instructions such as “MOV A, P1” we are really reading the data present at the pin. In other words, it is bringing into the CPU the status of the external pin. This instruction activates the read pin of BUF2 (TRI-STATE buffer2) and lets data at the pins flow into the CPU's internal bus.

- **WRITING “0” TO THE PORT**

Now what happens if we write a “0” to a port that was configured as an input port?

If we write a 0 (low) to port bits, then $Q = 0$ and $\overline{Q} = 1$. As a result of $\overline{Q} = 1$. As a result of $\overline{Q} = 1$, the M1 transistor is “on”. If M1 is “on”, it provides the path to ground for both R1 and input pin.

Therefore any attempt to read the input pin will always get the “low” ground signal regardless of the status of the input pin. This can also lead to damage the port, as explained next.

- **AVOID DAMAGING THE PORT**

When connecting a switch to an input port of the 89C51 we must be very careful. This is due to the fact that the wrong kind of connection can damage the port. Never connect direct V_{CC} to the 89C51 port pin.

If a switch with V_{CC} and ground is connected directly to the pin and the M1 transistor is “on” it will sink current from both internal load R1 and external V_{CC} . This can be too much current for M1 and will blow the transistor and, as a result, damage the port bit. We are using buffer/driver IC, to convert any input switch to a buffer/driver IC before it is fed to the 89C51 pin.

- **INSTRUCTIONS READING THE STATUS OF INPUT PORT:**

Mnemonics	Examples
MOV A, Px	MOV A, P1
JNB Px.y, ...	JNB P1.2, TARGET
JB Px.y, ...	JB P1.3, TARGET
MOV C, Px.y	MOV C, P1.4
CJNE A, Px, ...	CJNE A, P1, TARGET

- **READING LATCH**

Since in reading the port, some instructions read the port and some others read the latch, we next consider the case of reading the port where it reads the internal port latch.

“ANL P1, A” is an instruction that reads the latch instead of the input pin, when this instruction is executed.

1. The read latch activates the tri-state buffer of BUF1 and brings the data from the Q latch into CPU.
2. This data is ANDed with the contents of register A.
3. The result is written to the latch.

After writing the result to the latch, there are two possibilities:

1. If $Q = 0$, then $\overline{Q} = 1$ and M1 is “on”, and the output pin has “0”, the same as the status of the output pin has “1”, the same as the status of the Q latch.
2. If $Q = 1$, then $\overline{Q} = 0$ and the M1 is “off”, and the output pin has “1”, the same as the status of the Q latch.

So, the instruction that reads a value performs an operation and rewrites it to the latch. This is often called “read-modify-write”. These types of instructions use the port as the destination operand.

- **READ MODIFY WRITE INSTRUCTIONS:**

Mnemonics	Example
ANL	ANL P1, A
ORL	ORL P1, A
XRL	XRL P1, A
JBC	JBC P1.1, TARGET
CPL	CPL P1.2
INC	INC P1
DEC	DEC P1
DJNZ	DJNZ P1, TARGET
MOV Px.y, C	MOV P1.2, C
CLR Px.y	CLR P1.3
SETB Px.y	SETB P1.4

- **OUTPUT PORTS**

All ports are configured as output port as power is applied to any 89C51 microcontroller, and also by providing proper reset pulse.

3.4 Memory Organization of 89C51: -

The 89C51 has separate address spaces for Program Memory and Data Memory.

- **PROGRAM MEMORY**

The Program Memory can be up to 64K bytes long, the 4K byte internal and 60K byte external. Figure 3-5 shows a map of the 89C51 Program memory.




FIGURE 3.5 THE 89C51 PROGRAM MEMORY

- **DATA MEMORY**

The 89C51 can address up to 64K bytes of Data Memory external to the chip. The “MOVX” instruction is used to access the external data memory. The 89C51 has 128 bytes of on-chip RAM plus a number of Special Function Registers (SFRs). The lower 128 bytes RAM can be accessed either by direct addressing (MOV data addr) or

by indirect addressing (MOV @Ri). Figure 3.6 shows the 89C51 Data Memory organization.




FIGURE 3.6 THE 89C51 PROGRAM MEMORY


- **DIRECT AND INDIRECT ADDRESS AREA**

The 128 bytes of RAM which can be accessed by both direct and indirect addressing can be divided into 3 segments.

1. Register Banks 0-3: Locations 0 through 1FH (32 bytes). ASM51 and the device after reset default to register bank 0. To use the other register banks the user must select them in the software. Reset initializes the Stack Pointer to location 07H and it is incremented once to start from location 08H which is the first register (R0) of the second register bank. Thus in order to use more than one register bank, the SP should be initialized to a different location of the RAM where it is not used for data storage.
2. Bit Addressable Area: 16 bytes have been assigned for this segment, 20H-2FH. Each one of the 128 bits of this segment can be directly addressed (0-7FH). Each of the 16 bytes of the segment can also be addressed as a byte.
3. Scratch Pad Area: Bytes 30H to 7FH are available to the user as data RAM. However if the stack pointer has been initialized to this area, enough number of bytes should be left aside to prevent SP data destruction.

SECTION 2

**EXPERIMENTS ON
MICROPROCESSOR**





CHAPTER 4

ADVANCE EXPERIMENTS ON 8251



4.1 ROLL OF 8251 WITH MICROPROCESSOR 8085:-

The I.C. 8251A is useful for synchronous or asynchronous serial communication. One can directly interface 8251A with 8085A microprocessor. The basic features of this interface chip are as follows:

- **For Synchronous operation:-**
 - Character length can be 5, 6, 7, or 8 bits.
 - Synchronization can be achieved internally or externally.
 - Sync character can be automatically inserted.
 - Synchronous baud rate can be DC to 265K baud.
- **For Asynchronous operation:-**
 - The character length can be 5, 6, 7, or 8 bits.
 - Clock rate can be 1, 16 or 64 times baud rate.
 - Break character generation facility is available.
 - Stop bits can be programmed to be 1, 1½ or 2.
 - In-built false start bit detection facility.
 - Automatic break detect and handling facility.
 - Asynchronous baud rate from DC to 19.2K baud.
- It can be operated full duplex and double buffered mode.
- Parity, over-run and frame error can be detected.

Direct interface ability of 8251A with 8085A microprocessor has given good applied gadgets like:

1. Interfacing with CRT terminal.
2. Interfacing with telephone lines.

In the present work it is aimed to present the important characteristics of 8251A in such a way that student can verify the same experimentally without using extensive hardware. The examples shown above need good amount of hardware to use 8251A. For more details refer to section 1 chapter 2. We concentrate on the asynchronous mode of 8251A.

4.2 CONTINUOUS TRANSMISSION OF DATA ON TxD PIN:-

In this experiment the basic understanding of transmission section 8251A is considered. The data stored into the register of 8085A is transmitted over TxD pin continuously. The faithful transmission of the data is verified by the waveform displayed on the oscilloscope. For this experiment we have used 8251A

chip embedded in the microprocessor kit ESA-85. Hence, it is necessary to understand the basics of 8251A and its interfacing with the microprocessor kit.

o **Basics of 8251A:-**

8251A is made of following units.

- 1) Data bus buffer, 2) Read/write control 3) Modem control 4) Transmitter section 5) Receiver section

Data bus buffer accepts data and commands from microprocessor and passes them to 8251A. Similarly, the status word and data bytes assembled by 8251A are passed to microprocessor through this unit.

Read/write unit is driven by microprocessor control signals. It has \overline{RD} , \overline{WR} , RESET, \overline{CS} and C / \overline{D} pins. Out of these, \overline{RD} , \overline{WR} , RESET, and \overline{CS} have conventional meaning. C / \overline{D} pin when HIGH declares that the byte on data bus buffer is a command or status word, and if LOW the conformation of data on data bus.

Modem control unit has few control signals: \overline{DSR} (Data Set Ready), \overline{DTR} (Data Terminal Ready), \overline{RTS} (Request To Send) and \overline{CTS} (Clear To Send). \overline{RTS} is command controlled while \overline{DSR} can be status checked. The transmitter section works as shown in Figure 4.1.




FIGURE 4.1 TRANSMITTER SECTION OF 8251A

Transmitter accepts parallel bytes from microprocessor via internal bus of 8251A. These bytes are transferred to output shift register, which shift them bit by bit on T_xD pin. This activity is done under the control of control logic. When buffer register becomes empty it makes T_xRDY pin high to signal microprocessor to send data. When output register is empty it makes T_xE pin high indicate that it has nothing to transmit. The receiver works as shown in Figure 4.2




FIGURE 4.2 RECEIVER SECTION OF 8251A

Receiver section accepts data bits at R_xD on every $\overline{R_xC}$ pulse. The logic circuit of receiver separates framing information (start bit, stop bit) or sync bytes and assembles data byte and passes this assembled byte to receiver buffer register. At this time, it informs microprocessor to collect assembled bytes from buffer by making R_xRDY high.

8251A offers two ways of data transmission and / or reception: **Synchronous** and **Asynchronous**. Asynchronous mode format is shown in Figure 4.3.




FIGURE 4.3 ASYNCHRONOUS MODE FORMAT OF 8251A

In Asynchronous mode data, bytes are accompanied by framing bits, i.e. start bit and stop bits to distinguish each data byte from other. If parity bits are desired, they are added by 8251A and removed at receiver. Number of data bits, parity bits and number of stop bits are programmable. Each data byte is headed by a start pulse and ended by stop bits.

○ **Programming of 8251A: -**

To achieve proper data communication with microprocessor and peripheral devices, 8251A has to be programmed correctly. Figure 4.4 explains logic sequence for proper programming of 8251A.




FIGURE 4.4 FLOWCHART SHOWING LOGICAL SEQUENCE OF PROGRAMMING 8251A

Mode instruction format (for synchronous and asynchronous) and command word format are described in Figure 4.5 and Figure 4.6 respectively. These Figures are self-explanatory.




FIGURE 4.5 MODE WORD FORMAT

Status word is of 8-bits. Each bit provides status of signal. Following explains each bit of status word. Status word is shown in figure 4.6.

D0 = T_XRDY : T_XRDY status bit is not conditioned by $\overline{\text{CTS}}$ or T_XEN

D1 = R_XRDY : Receiver Ready

D2 = T_XEMPTY : Transmitter Empty (Means output register of transmitter is empty, no data is being sent, if T_XEN=1)

D3 = PE : Parity Error. PE flag is set whenever parity error is detected

D4 = OE : Overrun Error. The OE flag is set when the microprocessor does not read a character before the next one becomes available, in the receiver's buffer.

D5 = FE: Framing Error (Asynchronous mode only)

The FE flag is set when a valid stop bit is not detected at the end of every character. Note that PE, OE and FE errors can be reset by ER bit of command instruction and they do not inhibit operation of the 8251A.

D6 = Syndet / Brkdet : Same as I/O pin.

D7 = $\overline{\text{DSR}}$: Data Set Ready: This status bit indicates that $\overline{\text{DSR}}$ is at a zero level.




FIGURE 4.6 COMMAND WORD FORMAT AND STATUS WORD

○ **Interfacing of 8251A in microprocessor kit: -**

The communication through 8251A can be done with the help of TxD, RxD and modem control signals. For serial communication a well known standard RS-232 is used. Figure 4.7 shows how one can interface 8251A with outside world following RS-232 standard.




FIGURE 4.7 HARDWARE DETAILS OF MICROPROCESSOR KIT

SHOWING 8251A AND RS-232 INTERFACING

At this stage it is necessary to know what are the specifications of RS-232 standards. One should note that RS-232 was developed particularly for the communication between terminal and modem. It is also interesting to note that RS-232 standard was developed before the existence of TTL logic. Hence, to establish serial communication among two devices which use ICs following TTL logic require translator levels which takes care of the differences of RS-232 voltage level and TTL voltage level.

RS-232:-

Figure 4.8 shows the RS-232 25-pin connector and its signals. The signals are divided into four groups: data signals, control signals, timing signals and grounds. For data lines, the voltage level from +3 V to +15 V is defined as logic 0, and from -3 V to -15 V as logic 1 (normally, voltage levels are ± 12 V). This is negative true logic.

Because of incompatibility with TTL logic, voltage translator called **line drivers** and **line receiver** are required for TTL logic with the RS-232 signals.

The minimum interface required three lines: pins 2, 3 and 7, as shown in Figure 4.9. These lines are defined in relation to the DTE; the terminal transmits at pin 2 and receives on pin 3. On the other hand, the DCE transmits on pin 3 and receives on pin 2. Typically, data transmission with a handshake requires eight lines.




FIGURE 4.8 MINIMUM CONFIGURATION OF CONTROL SIGNAL BETWEEN DTE AND DCE




FIGURE 4.9 RS-232 SIGNAL DEFINITIONS AND PIN ASSIGNMENTS

Let's come back to Figure 4.7. In this figure we have used two level translators ICs MC1488¹ and MC1489². From this two ICs MC1488 converts the TTL voltage level of 8251A to a negative logic and RS-232 voltage level. The MC1489 converts the RS-232 signals to a positive TTL voltage level. In Figure 4.7 three parts

¹ Appendix A

² Appendix A

of MC1488 translates T_xD , \overline{DTR} and \overline{RTS} signals of 8251A to RS-232 level, while three parts of IC-MC1489 are used to convert RS-232 levels to the TTL level which are connected with R_xD , \overline{DSR} and \overline{CTS} . The details of IC MC-1488 and MC1489 are given in appendix I.

EXPERIMENT I: - CONTINUOUS TRANSMISSION OF DATA ON T_xD PIN^[R.P-1]

AIM: - To transmit given data continuously in asynchronous mode over T_xD pin of 8251A with following specifications

- Baud rate: same as clock
- Character length: 8-bit
- Parity: not required
- Stop bits: two

Software reset is to be performed and then proceed. Command / status Port = 21H. Data Port address = 20H.

Apparatus: - 8085A based microprocessor kits, a single power supply +5V, $\pm 12V$ and CRO.

Procedure: - The 8085A microprocessor kit with 8251A and level translator ICs MC1488 and MC1489 is connected to power supply. The RS-232 connector details are noted and \overline{CTS} pin is identified and connected to +5V to make $\overline{CTS} = 0$. This enables 8251A transmissions. A small program is run to reset 8251A.

```

MVI A, 00H
OUT 21H
OUT 21H
OUT 21H
MVI A, 40H
OUT 21H

```

In the above program first two instructions select synchronous mode. Next two instructions select two sync bytes as zeros. Last two instructions are used to perform software reset by making IR bit 1 in command word.

To configure 8251A as per above specifications mode control word would be

S_2	S_1	EP	PE	L_2	L_1	B_2	B_1	
1	1	0	0	1	1	0	1	= CDH

Command word enables transmitter for data transmission. Generally, Error Reset is also made high. So, command word becomes:

EH	IR	$\overline{\text{RTS}}$	ER	SBRK	R _x E	$\overline{\text{DTR}}$	T _x EN	
0	0	0	1	0	0	0	1	= 11H

To start data transmission, the CPU fills the buffer register of transmitter with data. For this, microprocessor checks the status of 8251A by reading its status word to confirm that buffer is empty. This can be done by “IN PORT” instruction i.e. IN 21H and the remaining program for data transmission is as follows:

```

MVI A, CDH
OUT 21H
MVI A, 11H
OUT 21H
EMPTY:    IN 21H      ; READ STATUS WORD
          ANI 01H      ; AND CHECK RXRDY =1
          JZ EMPTY    ; IF RXRDY = 0 WAIT
MVI A, AA   ; MOVE DATA TO A
OUT 20H      OUTPUT FOR TRANSMISSION
JMP EMPTY   ; TRANSMIT CONTINUOUSLY

```

The complete program looks like this:

Mnemonics	Memory address	Machine codes
MVI A, 00H	8000	3E, 00
OUT 21H	8002	D3, 21
OUT 21H	8004	D3, 21
OUT 21H	8006	D3, 21
MVI A, 40H	8008	3E, 40
OUT 21H	800A	D3, 21
MVI A, CD	800C	3E, CD
OUT 21H	800E	D3, 21
MVI A, 11H	8010	3E, 11
OUT 21H	8012	D3, 21
EMPTY: IN 21H	8014	DB, 21
ANI 01	8016	E6, 01
JZ EMPTY	8018	CA, 14, 80
MVI A, AA	801B	3E, AA

OUT 20H	801D	D3, 20
JMP EMPTY	801F	C3, 14, 80

In the above program, machine codes and memory location where program is stored is also given by entering program through the keyboard of the microprocessor kit. The program is executed for data: DATA = 55H and AAH

Pin 19 (T_XD) of 8251A is connected to CRO and the data transmission is observed as following Table 4.1.




TABLE 4.1 OBSERVED AND THEORITICAL OUTPUT OF T_XD PIN OF 8251A

4.3 8251A AS A RECEIVER AND TRANSMITTER ON THE SAME KIT:-

In this experiment the receiver and transmitter part of 8251A are studied. To interface transmitter circuitry and receiver circuitry the kit ESA-85 is used. The basics of receiver, transmitter and interfacing circuits are discussed earlier.

EXPERIMENT II: - 8251A AS A RECEIVER AND TRANSMITTER ON THE SAME KIT^[R.P-1]

Apparatus: -

8085A based microprocessor kits, a single power supply +5V, ±12V and CRO.

Procedure: -

In this experiment data are stored at 8100 to 8109 and transmitted through T_XD pin. The same data is received through R_XD and stored at 8200 to 8209.

The RS-232 pin details are noted from the user's manual of the ESA-85 microprocessor kit and T_xD pin is connected to R_xD and RTS with $\overline{\text{CTS}}$.

Command / Status Port address = 20H Data Port address = 21H.

Mode word = CDH / Command word = 35H.

The program is loaded from 8000H memory location and the data to be transmitted is stored at 8100H.

Mnemonics	Memory address	Machine codes
MVI A, 00H	8000	3E, 00
OUT 21H	8002	D3, 21
OUT 21H	8004	D3, 21
OUT 21H	8006	D3, 21
MVI A, 40H	8008	3E, 40
OUT 21H	800A	D3, 21
MVI A, CD	800C	3E, CD
OUT 21H	800E	D3, 21
MVI A, 35H	8010	3E, 35
OUT 21H	8012	D3, 21
LXI H, 8100H	8014	21, 00, 81
LXI D, 8200H	8017	11, 00, 82
EMPTY: IN 21H	801A	DB, 21
ANI 01H	801C	E6, 01
JZ EMPTY	801E	CA, 1A, 80
MOV A, M	8021	7E
INX H	8022	23
OUT 20H	8023	D3, 20
WAIT: IN 21H	8025	DB, 21
ANI 02H	80R.P-2	E6, 02
JZ WAIT	8029	CA, 25, 80
IN 20H	802C	DB, 20
XCHG	802E	EB
MOV M, A	802F	77
INX H	8030	23
MVI A, 09H	8031	3E, 09

CMP L	8033	BD
XCHG	8034	EB
JNZ EMPTY	8035	C2, 1A, 80
RST 3	8038	DF

The program is executed and the first 10 data stored at 8100H to 8109H are checked. The data gets transmitted to 8200H to 8209H location. This is a block moving using serial communication technique for the given kit. RST-3 instruction brings the control back to monitor program.

4.3 SERIAL COMMUNICATION BETWEEN TWO KITS:-

In this experiment communication between two identical but independent kits are studied. The experiment is divided into two parts.

- 1) One kit working as a transmitter while another kit working as a receiver i.e. **One-way communication.**
- 2) Both the kit are working as a receiver and transmitter i.e. **Two-way communication.**

The circuit details and interfacing remains same as discussed in previous two experiments.

EXPERIMENT III: - SERIAL COMMUNICATION BETWEEN TWO KITS^[R.P-1]

Apparatus: -

8085A based microprocessor kits, a single power supply +5V, $\pm 12V$ and CRO.

Procedure: -

For data transfer between two 8085A based microprocessor kits using RS-232 interface, the two kits are connected using RS-232 connectors as shown in Figure 4.10




FIGURE 4.10 CONNECTION OF THE RS-232 SIGNALS BETWEEN TWO KITS

- **PROGRAM FOR ONE-WAY COMMUNICATION: -**

In this case, two separate programs are written for both kits. The two programs are identified as master and slave program.

MASTER PROGRAM

Mnemonics	Memory address	Machine codes
MVI A, 00H	8000	3E, 00
OUT 21H	8002	D3, 21
OUT 21H	8004	D3, 21
OUT 21H	8006	D3, 21
MVI A, 40H	8008	3E, 40
OUT 21H	800A	D3, 21
MVI A, FE	800C	3E, FE
OUT 21H	800E	D3, 21
MVI A, 25H	8010	3E, 25
OUT 21H	8012	D3, 21
MVI B, 09H	8014	06, 09
LXI H, 8100H	8016	21, 00, 81
EMPTY: IN 21H	8019	DB, 21
ANI 01H	801B	E6, 01
JZ EMPTY	801D	CA, 1A, 80

RTRAN:	MOV A, M	8020	7E
	OUT 20H	8021	D3, 20
	IN 21H	8023	DB, 21
	ANI 08H	8025	E6, 08
	JNZ RTRAN	80R.P-2	CA, 20, 80
	INX H	802A	23
	DCR B	802B	05
	JNZ EMPTY	802C	C2, 19, 80
	RST 3	802F	DF

Here, “ANI 01H” checks T_xRDY condition. “ANI 08H” checks parity error. “JZ RTRAN” makes a loop to transmit same byte if parity error has occurred. Register B is a counter. Location 8100H to 8109H store data to be transmitted.

SLAVE PROGRAM

	Mnemonics	Memory address	Machine codes
	MVI A, 00H	8000	3E, 00
	OUT 21H	8002	D3, 21
	OUT 21H	8004	D3, 21
	OUT 21H	8006	D3, 21
	MVI A, 40H	8008	3E, 40
	OUT 21H	800A	D3, 21
	MVI A, FE	800C	3E, FE
	OUT 21H	800E	D3, 21
	MVI A, 35H	8010	3E, 35
	OUT 21H	8012	D3, 21
	MVI B, 09H	8014	06, 09
	LXI H, 8200H	8016	21, 00, 82
EMPTY:	IN 21H	8019	DB, 21
	ANI 02H	801B	E6, 02
	JZ EMPTY	801D	CA, 19, 80
	IN 20H	8020	DB, 20
	MOV M, A	8022	77
	INX H	8023	23

DCR B	8024	05
JNZ EMPTY	8025	C2, 19, 80
RST 3	8028	DF

The program is first executed in the slave kit and then in the master kit. The data of the slave kit is then checked. It is observed that the location 8200H to 8209H of the slave kit contains the same data of master kit stored at 8100H to 8109H. This is **One - Way communication** from the master to the slave kit.

● PROGRAM FOR TWO-WAY COMMUNICATION: -

Both the kits are loaded with master and slave program. Master kit is the one that transmits the data. The program remains the same.

MASTER PROGRAM

	Mnemonics	Memory address	Machine codes
	MVI A, 00H	8000	3E, 00
	OUT 21H	8002	D3, 21
	OUT 21H	8004	D3, 21
	OUT 21H	8006	D3, 21
	MVI A, 40H	8008	3E, 40
	OUT 21H	800A	D3, 21
	MVI A, FE	800C	3E, FE
	OUT 21H	800E	D3, 21
	MVI A, 25H	8010	3E, 25
	OUT 21H	8012	D3, 21
	MVI B, 09H	8014	06, 09
	LXI H, 8100H	8016	21, 00, 81
EMPTY:	IN 21H	8019	DB, 21
	ANI 01H	801B	E6, 01
	JZ EMPTY	801D	CA, 1A, 80
	MOV A, M	8020	7E
	OUT 20H	8021	D3, 20
	INX H	8023	23
	DCR B	8024	05
	JNZ EMPTY	8025	C2, 19, 80

	MVI A, 35H	8028	3E, 35
	OUT 21H	802A	D3, 21
	MVI B, 09H	802C	06, 09
	LXI H, 8200H	802E	21, 00, 82
WAIT:	IN 21H	8031	DB, 21
	ANI 02H	8033	E6, 02
	JZ WAIT	8035	CA, 31, 80
	IN 20H	8038	DB, 20
	MOV M, A	803A	77
	INX H	803B	23
	DCR B	803C	05
	JNZ WAIT	803D	C2, 31, 80
	RST 3	8040	DF

Data to be transmitted are stored at 8100H and received data are stored at 8200H.

SLAVE PROGRAM

Mnemonics	Memory address	Machine codes
MVI A, 00H	8000	3E, 00
OUT 21H	8002	D3, 21
OUT 21H	8004	D3, 21
OUT 21H	8006	D3, 21
MVI A, 40H	8008	3E, 40
OUT 21H	800A	D3, 21
MVI A, FE	800C	3E, FE
OUT 21H	800E	D3, 21
MVI A, 35H	8010	3E, 35
OUT 21H	8012	D3, 21
MVI B, 09H	8014	06, 09
LXI H, 8200H	8016	21, 00, 82
WAIT: IN 21H	8019	DB, 21
ANI 02H	801B	E6, 02
JZ WAIT	801D	CA, 19, 80
IN 20H	8020	DB, 20

	MOV M, A	8022	77
	INX H	8023	23
	DCR B	8024	05
	JNZ WAIT	8025	C2, 19, 80
	MVI A, 25H	8028	3E, 25
	OUT 21H	802A	D3, 21
	MVI B, 09H	802C	06, 09
EMPTY:	IN 21H	8031	DB, 21
	ANI 01H	8033	E6, 01
	JZ EMPTY	8035	CA, 31, 80
	MOV A, M	8038	7E
	OUT 20H	8039	D3, 20
	INX H	803B	23
	DCR B	803C	05
	JNZ EMPTY	803D	C2, 19, 80
	RST 3	8040	DF

Data to be transmitted are stored at 8100H and received data are stored at 8200H. The slave program is executed first. The data transfer on both kits is verified. Data from the location 8100H to 8109H of the master kit is now at 8200H to 8209H on the slave kit. Similarly, the data at 8100H to 8109H of the slave kit is stored in the master kit at memory location 8200H to 8209H.



CHAPTER 5

ADVANCE EXPERIMENTS ON 8255



5.1 ROLL OF 8255 WITH MICROPROCESSOR 8085A: -

The 8255 chip is very widely used chip with the 8085A processor. The basic description of 825 is done in earlier chapter 2. Our basic aim is to understand the mode I and II operations of 8255 without involving the extra hardware, that is, this experiment can be performed within a given microprocessor kit. The basics of mode I and mode II are explained in the following topic.

- **BASICS OF 8255:**

Generally, 8255 is understood by its block diagram which contains A DATA BUS BUFFER, R/W CONTROL LOGIC, THREE PORTS **A, B & C** AND THEIR CONTROL BLOCKS. Each Port consists of 8-bit. Each Port can be configured through control word register. The selection of the Ports and control word registers is done by pins A_0 and A_1 .

8255 can be used in three different modes: **mode 0, mode 1 & mode 2**. Since, mode 0 is very simple we will not consider in present paper.

- **MODE 1:**

This mode is known as STROBED I/O MODE. The data transfer takes place under the control of “**HANDSHAKING**” signals. Port A & B works as I/O Ports & Port C provides handshaking signals. Mode 1 can be divided into I/P & O/P modes. Figure 5.1 illustrates both of these modes.




FIGURE 5.1 (A) Mode 1 Strobed Input definitions




FIGURE 5.1 (B) Mode 1 Strobed Output definitions

The handshaking signals are as follows:

- 1) $\overline{\text{STB}}$ (STROBE INPUT): - A low on this Input loads data into the input latch.
- 2) IBF (Input Buffer Full Flip Flop): - A high on the Output indicates that data has been loaded into the I/P latch, i.e. an acknowledgement. IBF is set by $\overline{\text{STB}}$ input being low and is reset by the rising edge of the $\overline{\text{RD}}$ input.
- 3) $\overline{\text{OBF}}$ (Output Buffer Full Flip-Flop): - The $\overline{\text{OBF}}$ output will go low to indicate that the CPU has written data out to the specified Port. The $\overline{\text{OBF}}$ flip-flop will be set by the rising edge of the $\overline{\text{WR}}$ input and reset by $\overline{\text{ACK}}$ input being low.

- 4) \overline{ACK} (Acknowledge Input): - A low on this input informs the 8255 that the data from Port A or Port B has been accepted, i.e. a response from the peripheral device indicating that it has received the data output by the CPU.
- 5) INTR (Interrupt Request): - A high on this output can be used to interrupt the CPU when the input device is requesting service, or an output device has accepted data transmitted by the CPU. The status word for Mode 1 is illustrated in Figure 5.2.




FIGURE 5.2 Mode – 1 status word format

- **MODE 2 (STROBED BI-DIRECTIONAL BUS I/O) :**

Bi-directionality is available with Port A only. Port B can be used in Mode 0 or Mode 1 as input or output. The five bits of Port C are used to generate handshaking signals. Figure 5.3 illustrate the details of Mode 2.




FIGURE 5.3 details of mode 2 including hardware and signal timings

The control signals have the same meaning as in Mode 1. Figure 5.4 shows the status word definition for the Mode 2.




FIGURE 5.4 Mode 2 status word format

■ **MODE 1 EXPERIMENT: -**

In this experiment the basic concept of parallel communication through handshaking signal is studied. Port A and Port B are taken as two I/O devices. The interfacing of their data bus and handshaking signals are achieved from a single 8255 chip.

❖ **EXPERIMENT I: - STUDY OF MODE 1 (PORT A OUTPUT AND PORT B INPUT)^[R.P-2]**

Figure 5.5 (A) shows the circuit diagram to use 8255 in Mode 1. Here Port A is configured as output Port while Port B is configured as input Port. Data communication in Mode 1 can be done by two ways: STATUS CHECK and INTERRUPT driven. We will discuss about interrupt driven communication. From Figure 5.5 (A), we know that to generate interrupt for Port A and Port B the interrupt enable flip-flops INTE_A and INTE_B are to be set through Port C pins, PC₆ and PC₂ respectively. The control word to configure 8255 in Mode 1 with Port A O/P & Port B I/P is as follows.




FIGURE 5.5 (A) Port A as output Port and Port B as input Port in mode 1




FIGURE 5.5 (B) Handshaking signals indicating timing to output data from Port A





FIGURE 5.5 (C) Handshaking signals indicating timing to receive data by Port B.



To set PC₆ and PC₂ the required BSR control words are as follows:

0	X	X	X	B ₂	B ₁	B ₀	S/R	
0	0	0	0	1	1	0	1	0D for PC ₆
0	0	0	0	0	1	0	1	05 for PC ₂

❖ HARDWARE CONNECTION:

Take available 8085 microprocessor based kit, from the user's manual find out the connector for 8255. Determine the correlation of connector pins with the 8255 pins and connect them as follows.

PA ₇ → PB ₇	PA ₁ → PB ₁
PA ₆ → PB ₆	PA ₀ → PB ₀
PA ₅ → PB ₅	PC ₇ → PC ₂
PA ₄ → PB ₄	PC ₁ → PC ₆ (Through Inverter)
PA ₃ → PB ₃	PC ₃ (INTRA) → RST 6.5 → FE0C H
PA ₂ → PB ₂	PC ₀ (INTRB) → RST 5.5 → FE06 H

Also find out the control word, Port address and address for Port A, Port B and Port C of 8255 in your kit. In our case we have control word register address 03H and Port A, B and C as 00H, 01H, and 02H respectively.

The following program is entered in the kit.

8000	06 11	MVI B, 11H	; COUNTER
8002	3E A6	MVI A, A6H	; CONTROL WORD FOR 8255
8004	D3 43 / 03	OUT 03H	; TO CONTROL WORD REGISTER
8006	3E 0D	MVI A, 0DH	; BSR WORD TO SET INTE _A (PC ₆)
8008	D3 43 / 03	OUT 03H	; TO CONTRL WORD REGISTER
800A	3E 05	MVI A, 05H	; BSR WORD TO SET INTE _B (PC ₂)
800C	D3 43 / 03	OUT 03H	; TO CONTRL WORD REGISTER
800E	3E 08	MVI A, 08H	; DATA TO ENABLE ALL INTERRUPTS
8010	30	SIM	; THROUGH SIM
8011	21 00 82	LXI H, 8200H	; POINTER TO DATA SOURCE
8014	11 00 83	LXI D, 8300H	; POINTER TO DATA DESTINATION
8017	LOOP : FB	EI	; ENABLE INTERRUPTS
8018	C3 17 80	JMP LOOP	; REPEAT

Generally, at the vector addresses of RSTs jump instructions are stored. Find out from the manual of your kit these jump locations for RST6.5 and RST5.5. In our case, they are FE0CH and FE06H for RST6.5 and RST5.5 respectively. Note that such RSTs (hardware interrupts) should be free to use in the kit.

In our case, the locations where RST6.5 and RST 5.5 jumps were not sufficient to provide enough memory locations, so we again used two more jump instructions as follows:

At FE0CH JMP 810C for RST 6.5 At FE06H JMP 8100 for RST 5.5

You can check your kit for such situation. Now, store following service routines for RST6.5 and RST5.5 at the final jump address.

For RST 6.5 enter following program starting at 810CH

810C	7E	MOV A, M	; TAKE DATA FROM 8200H TO A
810D	D3 40 / 00	OUT 00H	; OUTPUT TO PORT A
810F	23	INX H	;
8110	05	DCR B	;
8111	C2 15 81	JNZ OUT1	; ALL BYTES TAKEN?
8114	76	HLT	; YES, HAULT
8115	OUT 1 : C9	RET	; OTHERWISE GOTO MAIN PROGRAM

For RST 5.5 enter following program starting at 8100H

8100	DB 01 / 41	IN 01H	; READ DATA FROM PORT B
8102	12	STAX D	; STROE TO DESTINATION
8103	13	INX D	; POINTED TO BY DE
8104	C9	RET	; AND RETURN TO MAIN PROGRAM

Now enter source data at 8200.

When you run the above program the source data at 8200 will be copied at destination addresses 8300 onward.

❖ **UNDERSTANDING PROGRAM:**

In the main program when instruction EI will be executed it will generate interrupt on RST 6.5, **WHY?** To understand this, consider Figure 5 (B). Here, before microprocessor writes data to Port A, signal INTR_A , that is pin PC3 is already high which we have connected with RST 6.5. So, execution of EI will generate an interrupt on RST 6.5, JMP FE0C at its vector address 0034H will take control at FE0CH. Then, service routine which starts with instruction MOV A, M will output a byte to the Port A. After that JNZ OUT1 will transfer control to main processor instruction JMP LOOP, if all bytes from source are not transmitted.

Now, let us understand how the Port B will generate INTR_B . When the service routine for RST 6.5 writes data for Port A through instruction MOV A, M and OUT 00H, $\overline{\text{OBF}}_A$ will go low for some time. This $\overline{\text{OBF}}_A$ we have connected with

\overline{STB}_B . Hence Port B receives strobe pulse and data from Port A. \overline{STB}_B will make IBF_B high. Now, to let the CPU know to read the data $\overline{RD} = 1$ $IBF_B = 1$ and $\overline{STB}_B = 1$ will make $INTR_B$ high. See Figure 5.5 (C).

This high $INTR_B$ which we have connected with RST 5.5 will cause program control to jump to location 002CH which is a vector location of RST 5.5. At this address the instruction JMP FE06H will transfer control to location 8100H. At this location the service routine for RST 5.5 is written, the instruction IN 01H will make the \overline{RD} low to read the data from Port B & store it from 8300H onward. The low \overline{RD} will make the $INTR_B$ low. After sometime the \overline{RD} will go high causing IBF_B to be low, which is inverted and applied as $\overline{ACK}_A = 1$ to Port A. This high state of \overline{ACK}_A will make $INTR_A$ high to fetch another byte from memory thus executing the service routine for RST 5.5. In this way alternate generation of RST 6.5 and 5.5 will execute service routine to transmit bytes from the source and receive at destination.

■ **MODE 2 EXPERIMENT: -**

In this experiment the concept of Bi-directional communication is studied. In a 8255 Port A can be configured in Bi-directional mode. In this mode the control signals are generated by Port C pins.

The Bi-directionality of the communication is studied by two different experiments. In first experiment Port A is configured as O/P Port and Port B is configured as I/P Port. In second experiment Port A is configured as I/P Port and Port B is configured as O/P Port.

● **Port A as Output Port and Port B as Input Port^[R.P-2]:-**

In this experiment the hardware details is shown in Figure 5.6. The pin connections are also shown as below.

● **HARDWARE CONNECTION:**

For case one, i.e. to make Port A Output and Port B Input connect the pins on the 8255 connector (as per your kit connection) as follows:

$PA_0 \rightarrow PB_0$	$PA_5 \rightarrow PB_5$
$PA_1 \rightarrow PB_1$	$PA_6 \rightarrow PB_6$
$PA_2 \rightarrow PB_2$	$PA_7 \rightarrow PB_7$
$PA_3 \rightarrow PB_3$	$PC_7 (\overline{OBF}_A) \rightarrow PC_2 (\overline{STB}_B)$
$PA_4 \rightarrow PB_4$	$PC_6 (\overline{ACK}_A) \leftarrow PC_1 (\overline{IBF}_B) \text{ (Through Inverter)}$




FIGURE 5.6 Port A as Output Port and Port B as Input Port

Now, enter the following program after modifying branch location as per your kit's requirement.

8000	06 11	MVI B, 11H	; COUNTER
8002	3E C6	MVI A, C6H	; CONTROL WORD TO
8004	D3 03	OUT 03H	; CONFIGURE PORT A IN MODE 2 AND PORT B AS I/P PORT IN MODE 1
8006	3E 0D	MVI A, 0DH	; BSR MODE WORD TO
8008	D3 03	OUT 03H	; SET PC ₆
800A	3E 05	MVI A, 05H	; BSR MODE WORD TO
800C	D3 03	OUT 03H	; SET PC ₂
800E	3E 08	MVI A, 08H	; DATA TO ENABLE ALL INTERRUPTS
8010	30	SIM	;
8011	21 00 82	LXI H, 8200H	; SOURCE POINTER
8014	11 00 83	LXI D, 8300H	; DESTINATION POINTER
8017 LOOP :	FB	EI	;
8018	C3 17 80	JMP LOOP	;

The vector addresses in our system are as follows;

(PC ₃) INTR _A	RST 6.5	FE0C	JMP 8150
(PC ₀) INTR _B	RST 5.5	FE06	JMP 8100

This means enter the codes of instruction JMP 8150 at address FE0C and the codes of JMP 8150 at address FE06H. This is only true for our kit. Modify as per your kit. Now enter at 8150 and 8100 locations following program, which are service routine for RST 6.5 and RST 5.5, respectively.

For RST 6.5 AT 8150

8150	7E	MOV A, M	; TAKE DATA FROM 8200 TO A
8151	D3 00	OUT 00H	; OUTPUT TO PORT A
8153	23	INX H	;
8154	05	DCR B	;
8155	C2 59 81	JNZ OUT	; ALL BYTES TAKEN?
8158	76	HLT	; YES, HALT
8159 OUT:	C9	RET	; OTHERWISE, GO TO MAIN PROGRAM

For RST 5.5 AT 8100

8100	DB 01	IN 01H	; READ DATA AT PORT B
8102	12	STAX D	; STORE TO DESTINATION
8103	13	INX D	; POINTED TO BY DE
8104	C9	RET	; AND RETURN TO MAIN PROGRAM

• **Port A as Input Port and Port B as Output Port^[R.P-2]:-**

In this experiment the hardware detail is shown in Figure 5.7.




FIGURE 5.7 Port A as Input Port and Port B as Output Port

Now to make Port A input in mode 2 and Port B output in mode 1 connect the pins of 8255 as follows:

$PA_0 \rightarrow PB_0$ $PA_5 \rightarrow PB_5$
 $PA_1 \rightarrow PB_1$ $PA_6 \rightarrow PB_6$
 $PA_2 \rightarrow PB_2$ $PA_7 \rightarrow PB_7$
 $PA_3 \rightarrow PB_3$ $PC_1 (\overline{OBF}_B) \rightarrow PC_4 (\overline{STB}_A)$
 $PA_4 \rightarrow PB_4$ $PC_2 (\overline{ACK}_B) \leftarrow PC_1 (IBF_A) \text{ (Through Inverter)}$

Now, enter the following program:

```

8000          06 11      MVI B,      ; COUNTER
                        11H
8002          3E D4      MVI A,      ; CONTROL WORD TO CONFIGURE
                        D4H          PORT A IN MODE 2 AND PORT B AS
                                O/P IN
8004          D3 43      OUT 43H      MODE 1
8006          3E 09      MVI A,      ; BSR MODE WORD TO
                        09H
8008          D3 43      OUT 43H      ; SET PC4 (INTE2)
800A          3E 05      MVI A,      ; BSR MODE WORD TO
                        05H
800C          D3 43      OUT 43H      ; SET PC2 (INTE1)
800E          3E 0C      MVI A,      ; DATA TO ENABLE ALL
                        08H          INTERRUPTS
8010          30         SIM          ;
8011          21 00 84    LXI H,      ; SOURCE POINTER
                        8400H
8014          11 00 85    LXI D,      ; DESTINATION POINTER
                        8500H
8017  LOOP:  FB         EI          ;
8018          C3 17 80    JMP          ;
                        LOOP

```

Enter JMP instruction at addresses FE0C and FE06 as follow:

```

FE0C          JMP 8150      RST 6.5
FE06          JMP 8100      RST 5.5

```

Now, enter following program at 8150 and 8100 for RST 6.5 and RST 5.5 service routines.

For RST 5.5 AT 8150

8150	7E	MOV A, M	; DATA TO A FROM 8400
8151	D3 41	OUT 41H	; OUTPUT THROUGH PORT B
8153	23	INX H	;
8154	05	DCR B	;
8155	C2 59 81	JNZ OUT	; ALL BYTES TRANSFERRED?
8158	76	HLT	; YES, HALT
8159	OUT : C9	RET	; OTHERWISE, RETURN TO MAIN PROGRAM

For RST 6.5 AT 8100

8100	DB 40	IN 40H	; READ FROM PORT A
8102	12	STAX D	; AND STORE AT DE = 8500
8103	13	INX D	; ONWARD
8104	C9	RET	; AND RETURN TO MAIN PROGRAM

Note that in this case you may have to interface Port A and Port B through buffer chip, e.g. 7407. This logic of programs for mode 2 is almost equivalent as mode 1.



CHAPTER 6

ADVANCE EXPERIMENTS ON INTERRUPTS



In this experiment the basic concepts of interrupt of 8085A are studied. Interrupt checking; interrupt reorganization; their vector addresses; priority; masking etc are understood through the specially designed interfacing circuit. These circuits are to be connected to the microprocessor kit ESA-85.

6.1 ROLL OF HARDWARE AND SOFTWARE INTERRUPTS WITH MICROPROCESSOR 8085^[R.P-3]:-

o BASICS THEORY:-

An interrupt in 8085A is a facility to suspend execution of any current program of 8085A temporarily and switch to the program execution of interrupting device. The microprocessor-based system is always busy executing certain program. During such times if external devices want the service from 8085A (for execution of its dedicated program) they inform the processor by the use of interrupts. For this the device has to have a connection over any of the interrupt pins. There can be more than one devices which can be connected with interrupt pins of 8085A.

o INTERRUPT CHECKING BY 8085A:-

The 8085A does not know at what time which device may put interrupt request. This means the device can put interrupt request at any time. This is why interrupt process is called “asynchronous events”. To take care of such “at any time occurring processes”, interrupts, the 8085A checks during the penultimate clock of every instruction whether any interrupt request has occurred on any interrupt pins or not.

o RECOGNITION:-

There is a definite way for the interrupt recognition. This is different for different hardware pins of 8085A. Table 6.1 describes the conditions that have to meet in order for the interrupt requests to be recognized by the 8085A.

As shown in Table 6.1, a device connected with RST 7.5 pin needs to perform a low to high transition in order to get its interrupt recognized by 8085A. While device connected with RST 6.5, RST 5.5 and INTR pins have to maintain a HIGH level on the corresponding interrupt pin till 8085A completes the execution of current instruction. The heavy lines in the signal drawings in Table 6.1 explain this situation.






INTERRUPTS	SIGNAL CONDITION	COMMENTS
RST 7.5		Low to High transitions Sensitive
RST 6.5		High level sensitive
RST 5.5		High level sensitive
TRAP		Low to high level transition and High level sensitive
INTR		Only level sensitive

TABLE 6.1 SIGNAL CONDITIONS FOR RECOGNITION ON DIFFERENT INTERRUPT PINS OF 8085A

○ **VECTOR ADDRESSES:-**

The devices generate interrupts to have execution of their programs. (I.E. execution of their service routines). For this, the processor should know about the address of the service routine. To reduce the hardware for this matter, 8085A has ready-made addresses for interrupt pins RST 7.5, RST 6.5, RST 5.5 and TRAP. This means whichever device generates interrupt on any of these pins, the address of the service routine, for that device is given by the 8085A. In other words, the addresses of service routine for respective interrupting pins are pre-defined. Hence, these addresses are called “vector addresses”. Table-6.2 Provides vector addresses of interrupts pins of 8085A.

Pin name	Vector address
RST 7.5	003C
RST 6.5	0034
RST 5.5	002C
TRAP	0024

TABLE-6.2 VECTOR ADDRESSES OF INTERRUPTS OF 8085A

○ **SPECIAL CHARACTERISTIC OF INTR:-**

The INTR pin of 8085A has a special characteristic in terms of providing the address of the service routine of the device connected with it. The interrupting device which generates interrupt on pin INTR has to provide the address of its subroutine.

Whenever interrupt occurs on INTR, the 8085A disables interrupts and provides $\overline{\text{INTA}}$ signal. The device should sense this signal. Generally the device sends the code of RSTn instruction or the code of CALL instruction (which provides a chance to user to have his own address, e.g. CALL user address) in response to $\overline{\text{INTA}}$. The RSTn code would provide vector address, where as CALL code needs user's supplied address.

When the device generates code for CALL instruction, the 8085A provides two more $\overline{\text{INTA}}$ pulses (cycles). In response to these two cycles, the device has to provide 2-byte address of the service routine.

In this paper through a given circuit simple way is provided to generate address of service routine.

- **PRIORITY AND MASKING:-**

In 8085A the default priority of interrupts are as follows:

TRAP > RST 7.5 > RST 6.5 > RST 5.5 > INTR

This means TRAP assumes highest priority and INTR assumes lowest priority.

Masking is a facility by which one can avoid the interrupts, i.e. even if interrupts take place, they are not recognized if they are masked. In 8085A masking can be performed on RST 7.5, RST 6.5, and RST 5.5 only. TRAP is non-maskable. For masking, a special instruction SIM is to be executed.

- **ENABLING AND DISABLING INTERRUPTS :-**

In order to get the interrupts serviced (i.e. to make pc to point to vector addresses for valid interrupts) they are to be enabled. This condition of enabling is applicable to RST 7.5, RST 6.5, RST 5.5 and INTR. The TRAP is not conditioned to enabling. In 8085A this enabling is done by executing an instruction called EI. This means, prior to any interrupt request user should include EI instruction in his main program.

Disabling of interrupt is valid for RST 7.5, RST 6.5, RST 5.5 and INTR. One has to use DI instruction for this purpose. A reset also will disable interrupts. When any interrupt is recognized the processor disables the other interrupts (except TRAP).

○ **COMMON HARDWARE FOR THE EXPERIMENT: -**

To study the various concepts of the 8085A interrupts, we have designed and tested a circuit, which is shown in Fig. 6.1.




Figure 6.1 Interrupt generation circuit

This circuit is divided into two parts.

1. Interrupt generation circuit
2. Code providing circuit for INTR.

1. Interrupt generation circuit:-

In this circuit to generate interrupts for five different interrupt pins i.e. TRAP, RST 7.5, RST 6.5, RST 5.5 and INTR, of 8085A five pushbutton types of switches are used, one terminal of all these switches, sw1, sw2, sw3, sw4, and sw5 are connected with ground. The other terminal of these switches becomes single inputs to individual NAND gates. Refer to Fig 6.1. The second input of all NAND gates are connected to ground through the switch sw6. The outputs of these NAND gates are terminated on a strip connector J1. Then individual wire connection from J1 is to be

done with interrupt pins, which would ultimately connect each interrupting switch (SW1 to SW5) with the interrupt pin of 8085A refer to Table-6.3.

Switch	NAND gate	Interrupt
SW1	U1A (7400)	TRAP
SW2	U1B (7400)	RST 7.5
SW3	U1C (7400)	RST 6.5
SW4	U1D (7400)	RST 5.5
SW5	U2A (7400)	INTR

Table 6.3 Connections of interrupt generating switches with interrupt pins of 8085A

To generate individual independent interrupt on any of the 8085A interrupt pin press any switch from sw1 to sw5. Switch sw6 generates simultaneous interrupts on all pins of 8085A.

2. Code providing circuit for INTR: -

This is specially designed for INTR. Eight SPDT switches are used to set 0s and / or 1s on the data lines through a buffer IC 74LS245. The fixed terminals of all switches i.e. terminal 2 of switches sw7 to sw14 are connected to individual data lines through 74LS245. The floating terminals of switches are connected with ground or VCC i.e. terminal 3 of switches are connected with ground and terminals 1 are connected with VCC. The outputs of 74LS245 are terminated on another connector J3. From connector J3 wires are stretched to data pins of 8085A kit. The pins G and DIR of 74LS245 are connected to $\overline{\text{INTA}}$ and +5V, respectively. When $\overline{\text{INTA}}$ from 8085A becomes low, it enables 74LS245 to pass the status of switches sw7 to sw14 to the data lines.




FIGURE 6.2 CODE PROVIDING CIRCUIT FOR INTR

- **EXPERIMENTAL**
- **HARDWARE CONNECTION:-**

Inspect the hardware details of your microprocessor kit. Find out the correct pins of the connector, which lead to the connection to interrupt pins of 8085A processor chip. For example the kit we have used (ESA-85-2 ELECTRO SYSTEMS ASSOCIATES, BANGALORE), is having following details for interrupt pins of 8085A, which is shown in Table 6.4.

Connector P1	Pin
Not available*	TRAP
7	RST 7.5
8	RST 6.5
9	RST 5.5
Not available*	INTR

Table 6.4 Details of interrupt pins of 8085A

Using the information such as presented in Table 6.4, one should connect the wires from connector P1 on interfacing module (refer to Figure 6.1) to the connector on microprocessor kit. In our case this is shown in Table 6.5.

* We have bypassed the circuit of the kit.

Connector J1 (of interfacing module)	Connector (Kit) P1	8085A processor
PIN 1	Not available	TRAP
PIN 2	7	RST 7.5
PIN 3	8	RST 6.5
PIN 4	9	RST 5.5
PIN 5	Direct on chip 8085A	INTR

Table 6.5 Connection over connector J1 of interfacing module

For understanding the interrupt INTR one should connect the data lines, AD0 to AD7 of 8085A with the connector J3 of interfacing module. Also the $\overline{\text{INTA}}$ pin of 8085A is to be connected with pin 2 of connector J4 of interfacing module. Connect +5V supply with pin 1 of J4. In our case the connection of data lines with interfacing module is as shown in Table 6.6.

Connector J3 (interfacing module)	Connector (kit)	8085A
PIN 1	Direct on chip 8085A	12
PIN 2	Direct on chip 8085A	13
PIN 3	Direct on chip 8085A	14
PIN 4	Direct on chip 8085A	15
PIN 5	Direct on chip 8085A	16
PIN 6	Direct on chip 8085A	17
PIN 7	Direct on chip 8085A	18
PIN 8	Direct on chip 8085A	19

Connector J4 (interfacing module)	Connector (kit)	8085A
PIN 2	Direct on chip 8085A	INTA
PIN 1	POWER SUPPLY	+ 5V

Table 6.6 Connection over connector J3 and J4 of interfacing module

After proper hardware connection, one can perform various experiments on interrupts.

6.2 TO GENERATE THE INTERRUPT OF CHOICE AND EXECUTE ITS SERVICE ROUTINE: -

- APPERATUS USED:= Microprocessor kit, Interfacing module, Power supply
- PREPARATION:=

First of all we should develop service routines for different interrupts to understand the aim of this experiment. The vectored addresses of all interrupts of 8085A are not having enough space to accommodate any service routine. Hence it is a common practice to write JMP instructions at the vectored addresses.

For present experiment the JMP instruction for the interrupts are as presented in Table 6.7.

Interrupts	Vector address	Jump instruction	
		1	2
TRAP	0024	NOT USED	NOT USED
RST 7.5	003C	JMP FE12	JMP 8700
RST 6.5	0034	JMP FE0C	JMP 8600
RST 5.5	002C	JMP FE06	JMP 8500
INTR	Vector address of any RSTn inst. Or address indicated in CALL address instruction	CALL CDCD	

TABLE 6.7 JUMP INSTRUCTIONS OF VECTORED ADDRESSES

Enter the following program at location 8000H onward to enable all interrupts.

```

START:  MVI A, 0FH    8000          3E, 0F
        SIM          8002          30
        EI           8003          FB
        JMP          8004          C3, 00, 80
        START

```

From table 6.7 one can learn that if interrupt RST 7.5 takes place the instruction JMP FE12 written at 003C in the EPROM area will take control at RAM

location FE12. The codes of these “JUMP” instructions are permanently stored in EPROM. Hence, one cannot change these instructions. But looking at these new locations i.e. FE12, FE0C and FE06 in table 6.7 we find that they also have not enough locations to accommodate the service routine as they are also very close. This means one cannot write service routine at these locations also. For this reason before servicing the interrupt user has to store codes of desired JMP instruction at FE12, FE02 and FE06. Table 6.7 also contains these secondary addresses. From Table 6.7 we learn that the service routine for RST 7.5, RST 6.5, and RST 5.5 should be written from 8700, 8600, and 8500 addresses onward.

Note that TRAP is not free in our kit. Hence we have not written any service routine. For each interrupt following service routine are written.

For RST 7.5

MVI A, 30H	8700	3E, 30
MVI B, 30H	8702	06, 30
ADD B	8704	80
STA 8200H	8705	32, 00, 82
RST 3	8708	DF

This service routine will add 30H with 30H and stores the answer at 8200H when RST 7.5 interrupt take place.

For RST 6.5

MVI A, 30H	8600	3E, 30
MVI B, 30H	8602	06, 30
ADD B	8604	80
STA 8100H	8605	32, 00, 81
RST 3	8608	DF

This is same as RST 7.5 service routine, except that this routine will store the result at 8100.

For RST 5.5

MVI A, 30H	8500	3E, 30
MVI B, 30H	8502	06, 30
ADD B	8504	80
STA 8000H	8505	32, 00, 80
RST 3	8508	DF

This is same as RST 7.5's service routine, Except that it store the result at 8000.

For INTR

On occurring INTR user has to supply code on receiving $\overline{\text{INTA}}$ s. In present experiment, we have to use switches SW7 to SW14 to generate such code to perform experiment. Set these switches in the interface module for following states. We have done this because we want to use CALL instruction in response to INTR.

SW14	SW13	SW12	SW11	SW10	SW9	SW8	SW7	
1	1	0	0	1	1	0	1	= CDH

These settings of switches will input data CDH to 74LS245. On occurring of INTR, the first $\overline{\text{INTA}}$ low pulse will occur. We connected this $\overline{\text{INTA}}$ with G (Pin 19) of 74LS245. Hence, $\overline{\text{INTA}}$ will enable 74LS245 to put data CD on data lines of microprocessor kit. This data is code of CALL instruction. On interpretation the microprocessor will generate two more $\overline{\text{INTA}}$ pulses. This will enable 74LS245 two more times to output data CD and CD. This will in effect, becomes equivalent to provide instruction.

CALL CDCD

At address CDCD store the codes of instruction JMP 8800 and store the codes of following program at 8800 onward.

MVI A, 30H	8800	3E, 30
MVI B, 30H	8802	06, 30
ADD B	8804	80
STA 8400H	8805	32, 00, 84
RST 3	8808	DF

Thus, when INTR occurs, the service routine at 8800H will be executed giving result at 8400H.

○ **PROCEDURE:-**

First connect interfacing module with kit using information supplied in Tables. Now execute program from location 8000 to enable all interrupts. Now to generate any interrupt press any key from SW1 to SW5. The service routine of the respective interrupt will get executed and result will be available at respective memory location. Following Table 6.8 guides for the same.

SWITCH	Interrupt	Final service routine address	result location
SW1	TRAP	--	--
SW2	RST 7.5	8700	8200
SW3	RST 6.5	8600	8100
SW4	RST 5.5	8500	8090
SW5	INTA	8800	8400

TABLE 6.8 FOR INSPECTING MEMORY LOCATIONS

In this experiment at the result location one must find 60H data for successful execution of service routines.

6.3 TO VERIFY THE PRIORITIES OF INTERRUPT: -

The hardware and other details remains as discussed in 6.2. Other details are as follows.

○ **PROCEDURE:-**

Connect all connections of interfacing module with microprocessor kit. Now press switch SW6 (reset key). This will generate all interrupt simultaneously. But as per hardware priority TRAP assumes highest priority. So its service routine will be executed. Note that in our case TRAP is not available. To check priority of RST 7.5 disconnect TRAP. Now press SW6, only the service routine of RST 7.5 will be executed, since RST 7.5 assumes highest priority. You can verify this by examining location 8200. Similarly one can check priority of any interrupts.

6.4 **TO UNDERSTAND THE MASKING OF INTERRUPTS: -**

The hardware and other details for this experiment do not change much more. Other details are as follows.

○ **PROCEDURE:-**

Use instruction SIM to mask the RST 7.5, RST 6.5, and RST 5.5. Disconnect TRAP. Let all other interrupts be connected. Now enter following program from 8000 to onward as main program.


START:	MVI A, 0FH	8000	3E, 0F
	SIM	8002	30
	EI	8003	FB
	JMP START	8004	C3, 00, 80

The data 0F in A before the execution of SIM instruction masks interrupts RST 7.5, RST 6.5, and RST 5.5.

Now execute main program stored at 8000H. Press SW6 (to generate all interrupts simultaneously). This would allow RST 7.5 to be serviced first as it is having highest priority (since TRAP is not connected). But instead INTR will be serviced because RST 7.5, RST 6.5 and RST 5.5 are masked in main program. Verify by examining location 8400. One can set proper masking in SIM and verify the masking for further combinations of interrupts RST 7.5, RST 6.5 and RST 5.5.

SECTION 3

**EXPERIMENTS ON
MICROCONTROLLER
89C51**





CHAPTER 7

ADVANCE EXPERIMENTS ON KEYBOARD INTERFACE



Myriad of microcontroller projects include switches, and a combination of switches that we call keypad or keyboard which allows user to control the circuits inside. The control might be of any kind. It might involve changing of switch position to begin an operation, to press a key of option selection, or for any assigned operation to be performed related to that key press. For small tasks one can use pushbutton, toggle, or slide switches. Many of the large projects might call for a keyboard with an array of switches. Keyboards offer more options than individual switches or pushbuttons, at lower cost and compact size. It is the basic input device for any system by which human can easily communicate with machine. There are many applications in which keyboards are used, like Electronic Locks, EPROM Programmers, and many Test Instruments.

This chapter provides the one of the perspective to add keyboard to the microcontroller based system.

7.1 Basics of Keyboard Used^[R.P-4]

Keyboard used in this experiment is “4x10 matrix keyboard”. An 8x5 matrix keyboard is arranged into 4x10 matrixes. This arrangement will provide a compact 40-key 4x10 matrix keyboard which can be easily implemented to any application.

Figure 7.1 shows the 8x5 matrix arrangement. Figure 7.2 shows the 4x10 matrix arrangement for the 40-key keyboard. This will provide the internal as well as the final pictorial representation of the keyboard.




Figure 7.1 8X5 matrix arrangement of Keyboard




FIGURE 7.2 4x10 MATRIX FOR 40-KEY KEYBOARD

Thirteen control lines are shown in Figure 7.2, which are interfaced with the microcontroller. Each key is connected to its corresponding two control lines, one row side and one column side. These thirteen control lines are divided into row and column signals. One to Five control lines are controlling the columns and Six to Thirteen are for the rows compare this with Figure 7.1. See the numbers like 1-13, 1-12, 2-13 , 5-8 shown in Figure 7.2. These numbers show that when the user press the key numbered 1-13 for example, the control lines 1 & 13 are shorted and show continuity. One can check the working of keyboard by pressing each key and measuring the continuity between numbered control lines.

7.2 Interfacing of Keyboard with 89C51 Microcontroller

To see the key press of the keyboard, LCD (Liquid Crystal Display) is one of the better alternatives today. So to see the result of key pressed we have used the 1-line 16-character LCD module. The details of the circuit diagram are shown in Figure 7.3.




FIGURE 7.3 CIRCUIT DIAGRAM OF KEYBOARD INTERFACE WITH AT89C51 MICROCONTROLLER

We have connected each control line of the keyboard to V_{CC} via 10K resistor. Figure 7.4 shows the logic for single key of the keyboard. Initially the rows and columns are getting +5v.

The columns control lines (1-5) are connected to Port 2 (P2.0-P2.4) and the row control lines (6-13) are connected to Port 0 (P0.0 to P0.7). On the other side of AT89C51 microcontroller LCD module is interfaced with Port 1 (P1.0-P1.7) and Port 3 (P3.2, P3.3, & P3.4). The connection details of the Keyboard & LCD module are listed in Table 7.1(a) and Table 7.1(b).




FIGURE 7.4 THE LOGIC FOR SINGLE KEY OF THE KEYBOARD

Signal from LCD module	AT89c51 Port Pins
GND	GND
VCC	VCC
RS	P3.2
R/W	P3.3
E	P3.4
D0	P1.0
D1	P1.1
D2	P1.2
D3	P1.3
D4	P1.4
D5	P1.5
D6	P1.6
D7	P1.7

TABLE 7.1(A) CONNECTION DETAILS OF LCD AND AT89C51 MICROCONTROLLER

Control Lines		AT89c51 Port Pins
ROWS	13	P0.0
	12	P0.1
	11	P0.2
	10	P0.3
	09	P0.4
	08	P0.5
	07	P0.6
	06	P0.7
COLUMNS	05	P2.4
	04	P2.3
	03	P2.2
	02	P2.1
	01	P2.0

TABLE 7.1(B) CONNECTION DETAILS OF KEYBOARD AND AT89C51 MICROCONTROLLER

- **CIRCUIT FUNCTION**

The 10x4 matrix keyboard shown in Figure 7.2 provides 40 keys. The keyboard has actually 8-rows and 5-columns. The first ten keys will represent numbers 0-9, next twenty-six keys represent the alphabets A to Z and remaining four keys represent the symbols. The circuit shows that rows are connected with P0 (P0.0 to P0.7) and columns are connected with P2 (P2.0 to P2.4). As high potential is applied to rows and columns of the keyboard, initially they remain high (+5v). The columns and rows make contact only when a key is pressed.

When a key is pressed, the key must be identified by its column and the row, and the intersection of the column and row must change from high to low. To detect a pressed key, the microcontroller grounds all rows by providing “0” to the Port 0, then it read the columns. If the data read from the columns P2.4 to P2.0 = 11111, no key has been pressed and the process continues until a key press is detected. However, if one of the column bits has zero, this means that a key press has occurred. For example, if P2.4 to P2.0 = 11110, shows a key in column 1 has been pressed. After a

key press is detected, the microcontroller will go through the process of identifying the key. Starting from the top row, the microcontroller grounds it by providing a low to row connected to control line 13 (P0.0) only; then it reads the columns. If the data read is all 1's, no key in that row is activated and the process is moved to the next row. It grounds the next row, reads the columns, and checks for any zero. This process continues until the row is identified. After identification of the row in which the key has been pressed, the next task is to find out which column the pressed key belongs to.

Finally microcontroller gets the key pressed by matching the logic combination of row and column. Then the pressed key assigned code is displayed on the LCD module.

- **SOFTWARE FLOWCHART: -**




FIGURE7.5 SOFTWARE FLOWCHART FOR KEYBOARD INTERFACE WITH AT89C51 MICROCONTROLLER

- **KEYBOARD INTERFACE WITH AT89C51 SOFTWARE: -**

The software is responsible for identifying the key pressed and displaying the key code on the LCD module. For this reading the codes and outputting the same to the proper Port at proper time is done through proper instructions of the microcontroller. In this case the software is written, such that the key press is displayed on the LCD module.

Software for keyboard interface and display initialization is self explanatory and is given as below:

; LCD & Keyboard Interface with Microcontroller

; Main program

\$MOD51

DB0	EQU	P1.0
DB1	EQU	P1.1
DB2	EQU	P1.2
DB3	EQU	P1.3
DB4	EQU	P1.4
DB5	EQU	P1.5
DB6	EQU	P1.6
DB7	EQU	P1.7
EN	EQU	P3.4
RW	EQU	P3.3
RS	EQU	P3.2
DATA1	EQU	P1

LJMP MAIN

ORG 150H

MAIN:	LCALL	INIT_LCD	; LCD initialization
	LCALL	CLEAR_LCD	; Clear LCD
	CLR	RS	
	MOV	DATA1, #80H	; Set cursor at 80h
	SETB	EN	
	LCALL	DELAY	
	CLR	EN	
	LCALL	WAIT_LCD	

```

MOV      A, #P'
LCALL    WRITE_TEXT      ; Write the message to LCD
MOV      A, #R'
LCALL    WRITE_TEXT
MOV      A, #E'
LCALL    WRITE_TEXT
MOV      A, #S'
LCALL    WRITE_TEXT
MOV      A, #S'
LCALL    WRITE_TEXT
MOV      A, #' '
LCALL    WRITE_TEXT
MOV      A, #A'
LCALL    WRITE_TEXT
MOV      A, #N'
LCALL    WRITE_TEXT
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP
CLR      RS
MOV      DATA1, #0C0H
SETB     EN
LCALL    DELAY
CLR      EN
LCALL    WAIT_LCD
MOV      A, #Y'
LCALL    WRITE_TEXT
MOV      A, #' '
LCALL    WRITE_TEXT
MOV      A, #K'

```

	LCALL	WRITE_TEXT	
	MOV	A, #'E'	
	LCALL	WRITE_TEXT	
	MOV	A, #'Y'	
	LCALL	WRITE_TEXT	
	MOV	A, #'!'	
	LCALL	WRITE_TEXT	
	MOV	A, #'!'	
	LCALL	WRITE_TEXT	
	MOV	P2, #0FFH	; Make P2 input port
AAB1:	MOV	P0, #00H	; Ground all rows
	MOV	A, P2	; Read all columns
	ANL	A, #1FH	; Mask unused bits
	CJNE	A, #1FH, AAB1	; Check till all keys released
AAB2:	LCALL	DELAY	; Call 20ms delay
	MOV	A, P2	; See if any key is pressed
	ANL	A, #1FH	; Mask unused bits
	CJNE	A, #1FH, OVER	; Check for key press
	SJMP	AAB2	; Jump to check again
OVER:	MOV	P0, #0FEH	; Ground row 1
	MOV	A, P2	; Read all columns
	ANL	A, #1FH	; Mask unused bits
	CJNE	A, #1FH, ROW1	; Key in row 1, find column
	MOV	P0, #0FDH	; Ground row 2
	MOV	A, P2	; Read all columns
	ANL	A, #1FH	; Mask unused bits
	CJNE	A, #1FH, ROW2	; Key in row 2, find column
	MOV	P0, #0FBH	; Ground row 3
	MOV	A, P2	; Read all columns
	ANL	A, #1FH	; Mask unused bits
	CJNE	A, #1FH, ROW3	; Key in row 3, find column
	MOV	P0, #0F7H	; Ground row 4

	MOV	A, P2	; Read all columns
	ANL	A, #1FH	; Mask unused bits
	CJNE	A, #1FH, ROW4	; Key in row 4, find column
	MOV	P0, #0EFH	; Ground row 5
	MOV	A, P2	; Read all columns
	ANL	A, #1FH	; Mask unused bits
	CJNE	A, #1FH, ROW5	; Key in row 5, find column
	MOV	P0, #0DFH	; Ground row 6
	MOV	A, P2	; Read all columns
	ANL	A, #1FH	; Mask unused bits
	CJNE	A, #1FH, ROW6	; Key in row 6, find column
	MOV	P0, #0BFH	; Ground row 7
	MOV	A, P2	; Read all columns
	ANL	A, #1FH	; Mask unused bits
	CJNE	A, #1FH, ROW7	; Key in row 7, find column
	MOV	P0, #07FH	; Ground row 8
	MOV	A, P2	; Read all columns
	ANL	A, #1FH	; Mask unused bits
	CJNE	A, #1FH, ROW8	; Key in row 8, find column
	LJMP	AAB2	; Keep doing the same task
ROW1:	MOV	DPTR, # CODE1	; Set Data pointer to code1
	LJMP	GET	; Get the column and key code
ROW2:	MOV	DPTR, # CODE2	; Set Data pointer to code2
	LJMP	GET	; Get the column and key code
ROW3:	MOV	DPTR, # CODE3	; Set Data pointer to code3
	LJMP	GET	; Get the column and key code
ROW4:	MOV	DPTR, # CODE4	; Set Data pointer to code4
	LJMP	GET	; Get the column and key code
ROW5:	MOV	DPTR, # CODE5	; Set Data pointer to code5
	LJMP	GET	; Get the column and key code
ROW6:	MOV	DPTR, # CODE6	; Set Data pointer to code6
	LJMP	GET	; Get the column and key code
ROW7:	MOV	DPTR, # CODE7	; Set Data pointer to code7
	LJMP	GET	; Get the column and key code

ROW8:	MOV	DPTR, #CODE8	; Set Data pointer to code8
GET:	RRC	A	; Rotate Acc right once with carry
	JNC	GETDATA	; Check for no carry
	INC	DPTR	; Increment DPTR by one
	LJMP	GET	; Back in loop
GETDATA:	CLR	A	
	MOVC	A, @A+DPTR	; Get the key code from look-up
	MOV	R7, A	; table
	LCALL	CLEAR_LCD	; Clear LCD
	MOV	A, R7	
	LCALL	WRITE_TEXT	; Write the key code on LCD
	LJMP	AAB1	; Scan for the next key pressed
INIT_LCD:			; LCD initialization sub-routine
	CLR	RS	
	MOV	DATA1, #38H	
	SETB	EN	
	LCALL	DELAY	
	CLR	EN	
	LCALL	WAIT_LCD	
	CLR	RS	
	MOV	DATA1, #0EH	
	SETB	EN	
	LCALL	DELAY	
	CLR	EN	
	LCALL	WAIT_LCD	
	CLR	RS	
	MOV	DATA1, #06H	
	SETB	EN	
	LCALL	DELAY	
	CLR	EN	
	LCALL	WAIT_LCD	
	RET		
CLEAR_LCD:			; Clear LCD sub-routine
	CLR	RS	

```

MOV      DATA1, #01H
SETB     EN
LCALL    DELAY
CLR      EN
LCALL    WAIT_LCD
RET

WRITE_TEXT:                                ; Data write LCD sub-routine
SETB     RS
MOV      DATA1, A
SETB     EN
LCALL    DELAY
CLR      EN
LCALL    WAIT_LCD
RET

WAIT_LCD:                                ; LCD delay sub-routine
MOV      R2, #03H
MOV      R3, #0FFH
CLR      EN
CLR      RS
SETB     RW
MOV      DATA1, #0FFH
SETB     EN
MOV      A, DATA1
LOOP:   JB      ACC.7, HERE2
HERE2:  NOP
NOP
DJNZ     R3, HERE2
DJNZ     R2, LOOP
CLR      EN
CLR      RW
LCALL    DELAY
RET

DELAY:                                ; Delay sub-routine for keyboard
MOV      R2, #37

```

```

AGAIN:    MOV        R3, #255
HERE1:    NOP
            NOP
            DJNZ       R3, HERE1
            DJNZ       R2, AGAIN
            RET
            ORG        900H                ; Look-up table for key code
CODE1:    DB         '1', '3', '5', '7', '9'
CODE2:    DB         '2', '4', '6', '8', '0'
CODE3:    DB         'A', 'C', 'E', 'G', 'T'
CODE4:    DB         'B', 'D', 'F', 'H', 'J'
CODE5:    DB         'K', 'M', 'O', 'Q', 'S'
CODE8:    DB         'L', 'N', 'P', 'R', 'T'
CODE7:    DB         'U', 'W', 'Y', '?', '&'
CODE6:    DB         'V', 'X', 'Z', '.', '!'
            END

```

• **SOFTWARE EXPLANATION: -**

Software provides LCD initialization and data write function for the LCD module. LCD is cleared and message “PRESS ANY KEY!!!” is displayed on the LCD module. After that the program for detection and identification of key activation is started. P0 and P2 are initialized as output and input, respectively. The major stages of the program are listed below:

- For all key has been released, “0s” are output to all rows (P0) at once, and the columns (P2) are read and checked repeatedly until all the columns are high. When all columns are found to be high, the program waits for a short amount of time before it goes to the next stage of waiting for a key to be pressed.
- For any key closure, the columns are scanned over and over in an infinite loop until one of them has a “0” on it. After the key press detection, it scans the columns (P2) again. It ensures that the first key press detection was not an erroneous one. It goes to the next stage to detect which row it belongs to; otherwise, it goes back into the loop to detect a real key press.

- For which row the key belongs to, it grounds one row at a time by sending appropriate code to Port 0 and reading the columns each time. If it finds that all columns are high, this means that the key press cannot belong to that row; therefore, it grounds the next row and continues until it finds the row the key press belongs to. After finding the row, it sets-up the starting address for the look-up table holding the key codes for that row and goes to the next stage to identify the key.
- For any key press, it rotates the columns bits right, one bit at a time, in the carry flag and checks to see if it is low("0"). If the carry flag is set DPTR is incremented once. Upon finding the zero, it pulls out the ASCII code for that key from the look-up table.
- When the key code is identified and transferred to accumulator from look-up table, the display is cleared and key code is written on the LCD module. The program is looped back for the other key press detection.

- **Final Output: -**

When the system is started initial message on LCD "PRESS ANY KEY!!!" will be displayed. As soon as the key is pressed on the keyboard, the display is cleared and key assigned code will be displayed on the LCD module.



CHAPTER 8

ADVANCE EXPERIMENTS ON DISPLAY INTERFACE



Moving message displays are now days getting more importance for better advertisement. Due to different varieties and versatility such displays are useful at various places, for example, to show the information for the trains in railway stations or in hotel lounges to assist the hosts. These displays are available starting from simple LED's to LCD modules.

In this chapter a simple way to design and construct a moving message display system using AT89C51 microcontroller is emphasized.

8.1 BASICS OF DISPLAY USED^[R.P-5 & 6]

The 5x7 matrix modules made of Kwaliti Photonics Private Limited is used for this experiment, the module number is KLP1057I. It is a common anode type of module. The details of this module are shown in Figure 8.1 and Figure 8.2.




FIGURE 8.1 PIN CONFIGURATION OF 5X7 DISPLAY MODULE




FIGURE 8.2 INTERNAL DIAGRAM OF 5X7 DISPLAY MODULE

Figure 8.1, describes the pin arrangement of seven rows and five columns. Figure 8.2 shows the internal arrangement of LED's in 5x7 matrix. One can note that in order to lit any particular LED one has to connect the positive voltage to the corresponding column and ground the corresponding row.

8.2 BASIC KNOWLEDGE OF 5X7 MATRIX LED DISPLAY

In this experiment three 5x7 modules are combined resulting in a 15x7 matrix display. Thus AT89C51 microcontroller controls the seven rows and fifteen columns of the display. The corresponding rows and columns of the display are activated under the control of software written for microcontroller to create the effect of moving characters.

8.3 RUNNING CHARACTER DISPLAY INTERFACE USING 89C51

To interface the AT89C51 with three 5x7 display modules, the IC 74LS245 as buffer/drivers is used. The details of the circuit diagram are shown in Figure 8.3.




FIGURE 8.3 CIRCUIT DIAGRAM OF MOVING MESSAGE DISPLAY

The corresponding rows of all the three displays are connected in series. Hence there are seven rows and fifteen columns in the display. This can be visualized from Figure 8.4.




FIGURE 8.4: INTERNAL DIAGRAM OF 15X7 DISPLAY MODULE

All the seven rows of the display are connected to inputs of 74LS245 that is IC U2. The output of the same IC is connected to port1 of microcontroller. Out of total fifteen columns, i.e. from C1 to C15, columns C1 to C7 are connected to port2 of microcontroller through 74LS245 IC U4. Similarly the remaining eight columns C8 to C15 are connected to port3 of microcontroller through 74LS245 IC U3. The microcontroller is provided with power on reset and a working frequency of 11.0592 MHz.

The connection details of modules with the microcontroller ports are shown in detail in Table 8.1.

Signal from display	AT89c51 Port Pins
DP1-DP2-DP3	
R1-U2-A0	P1.0
R2-U2-A1	P1.1
R3-U2-A2	P1.2
R4-U2-A3	P1.3
R5-U2-A4	P1.4
R6-U2-A5	P1.5
R7-U2-A6	P1.6
DP1	
C1-U3-A0	P3.0
C2-U3-A1	P3.1
C3-U3-A2	P3.2
C4-U3-A3	P3.3
C5-U3-A4	P3.4
DP2	
C1-U3-A5	P3.5
C2-U3-A6	P3.6
C3-U3-A7	P3.7
C4-U4-A0	P2.0
C5-U4-A1	P2.1
DP3	
C1-U4-A2	P2.2
C2-U4-A3	P2.3
C3-U4-A4	P2.4
C4-U4-A5	P2.5
C5-U4-A6	P2.6

TABLE 8.1 CONNECTION DETAILS OF DISPLAY MODULE CONNECTED TO AT89C51 MICROCONTROLLER PORTS.

- CIRCUIT FUNCTION**

To display character pattern, certain data codes must be applied to the buffer IC 74LS245 inputs A0 to A7 whose output B0 to B7 is connected to 15x7 matrix displays by means of microcontroller port output. Port1 is used to control the seven rows. Port3 and Port4 are used to control the fifteen columns of 15x7 matrix display. Figure 5, shows the block diagram of the moving message display.




FIGURE 8.5 CORRESPONDENCE OF PORTS WITH ROW-COLUMN OF 15X7 DISPLAYS

Each column can be selected by sending corresponding data to Port3 and Port2. For example to select the first column (C01) one has to send 00h to Port3 and 40h to Port2. Table 8.2 shows the column selection code from C01 to C15.

COLUMN	PORT3								PORT2							
	P3.7	P3.6	P3.5	P3.4	P3.3	P3.2	P3.1	P3.0	P2.7	P2.6	P2.5	P2.4	P2.3	P2.2	P2.1	P2.0
C01 (0040H)	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0	0
C02 (0020H)	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0	0
C03 (0010H)	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0	0
C04 (0008H)	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0	0
C05 (0004H)	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0	0
C06 (0002H)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	0
C07 (0001H)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1
C08 (8000H)	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
C09 (4000H)	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0	0
C10 (2000H)	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0	0
C11 (1000H)	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0	0
C12 (0800H)	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0	0
C13 (0400H)	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0	0
C14 (0200H)	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0	0
C15 (0100H)	0	0	0	0	0	0	0	1	0	0	0	0	0	0	0	0

TABLE 8.2: COLUMN SELECTION CODES FOR 15X7 MATRIX MOVING MESSAGE DISPLAYS

Note that P2.7 is not connected so treated as “0” in code generation. When single column is selected one has to provide the corresponding row selection codes also, to lit the LED’s of selected column. The row selection code differs as per the user requirement for the

message to display. To display “5x7” on the module one has to select the column first and provide row the data codes. Each row-column selection pattern is separated by less than 1s delay. This switching delay between the row-column selection pattern is such that human eye can not detect the single row-column selection pattern and form a continuous character pattern of “5x7” in this case. Table 8.3 shows the row selection codes to be provided when particular column is selected to display message “5x7”.

COLUMN SELECTED	ROW CODE	ROWS R7 TO R1 - PORT1							
		P1.7 (NC)	P1.6 (R7)	P1.5 (R6)	P1.4 (R5)	P1.3 (R4)	P1.2 (R3)	P1.1 (R2)	P1.0 (R1)
C15	30H	0	0	1	1	0	0	0	0
C14	36H	0	0	1	1	0	1	1	0
C13	36H	0	0	1	1	0	1	1	0
C12	36H	0	0	1	1	0	1	1	0
C11	0EH	0	0	0	0	1	1	1	0
C10	3BH	0	0	1	1	1	0	1	1
C09	57H	0	1	0	1	0	1	1	1
C08	6FH	0	1	1	0	1	1	1	1
C07	57H	0	1	0	1	0	1	1	1
C06	3BH	0	0	1	1	1	0	1	1
C05	3EH	0	0	1	1	1	1	1	0
C04	5EH	0	1	0	1	1	1	1	0
C03	6EH	0	1	1	0	1	1	1	0
C02	76H	0	1	1	1	0	1	1	0
C01	78H	0	1	1	1	1	0	0	0

TABLE 8.3 ROW-COLUMNS SELECTION CODE TO GENERATE CHARACTER PATTERN OF “5X7”

By means of software burnt in microcontroller these codes are output to three ports and corresponding pattern is created on display module. This can be visualized in Figure 7.6.




FIGURE 8.6 “5X7” MESSAGE PATTERN ON DISPLAY MODULE

By means of software appropriate column is selected and row codes for each digit (i.e. 5-width 7-hieght) are fetched from the ROM. Row codes are saved on memory location 700h onwards. For moving the message “5x7 HNP”, shift the row data

selection right side once as the data on ROM are 700h onwards. So for first shift DPTR (data pointer) must be set to 701h and for continuous shifting increment the DPTR till the last data saved. For better understanding, Figure 8.7 shows the step by step display pattern of the module.




FIGURE 8.7: STEP BY STEP DISPLAY PATTERN OF THE MODULE

After the completion of last step, data 7fh is given to the port 1 twelve more times selecting each time the corresponding column so that the display will be cleared and again loop back to step 1. In this way moving message “5x7 HNP” is displayed.

○ SOFTWARE FLOWCHART

Figure 8.8 shows the flowchart of the software used for moving message display.




FIGURE 8.8 SOFTWARE FLOW CHART

• MOVING MESSAGE DISPLAY SOFTWARE

The software is responsible to maintain the movement of the characters on the display. For this reading the codes and outputting the same to the proper port at proper time is done through proper instructions of the microcontroller. In the present case the software is written, such that the message '5x7 HNP' is displayed sequentially. Software for display initialization and data write is self explanatory and is given as below:

; Moving message display using 15x7 matrix

; Main program

\$MOD51

	LJMP	MAIN	
	ORG	150H	
MAIN:	MOV	SP, #40H	; Move stack pointer to 40H
NEXT:	MOV	DPTR, #700H	; Load Data pointer = 700H
	LCALL	CLRDISP	; Clear display
	LCALL	DATANXT	; Call data and display to module
	MOV	R0, #24H	; Store no. of data in R0
NEXT1:	INC	DPTR	; Increment DPTR to point next data
	MOV	P2, #00H	; Clear port2
	LCALL	DATANXT	; Call data and display to module
	DJNZ	R0, NEXT1	; If R0 is not zero jump to next1
	LJMP	NEXT	; Run program in continuous loop
DATANXT:	MOV	R6, #01	; Initialize count in R6
AB2:	MOV	R7, #100	; Initialize count in R7
AB1:	MOV	R3, #00H	; R3 = 00h for 1 st code from memory
	MOV	R1, #01H	; Column 1 selection of P3
NXTDATA:	MOV	A, R3	; Get the data from memory
	MOVC	A, @A+DPTR	
	MOV	P1, A	; Sent data to P1 for row codes
	MOV	P2, #00H	; Off port2 connected display
	MOV	P3, R1	; Select column of display
	MOV	A, R1	; Get the selection code of
	RL	A	; column in R1 again

```

MOV      R1, A
INC      R3                      ; point next data on memory
LCALL    DELAY1                ; provide switching delay
CJNE     R3, #08, NXTDATA      ; R3<=8 get the next data
MOV      R1, #01H                ; Column 1 selection of P2
NXTDATA1: MOV      A, R3        ; Get the data from memory
MOV      A, @A+DPTR
MOV      P1, A                   ; Sent data to P1 for row codes
MOV      P3, #00H                ; Off port3 connected display
MOV      P2, R1                  ; Select column of display
MOV      A, R1                   ; Get the selection code of
RL       A                       ; column in R1 again
MOV      R1, A
INC      R3                      ; point next data on memory
LCALL    DELAY1                ; provide switching delay
CJNE     R3, #15, NXTDATA1; R3<=15 get the next data
DJNZ     R7, AB1                  ; If R7#00h jump to AB1
DJNZ     R6, AB2                  ; If R6#00h jump to AB2
RET
CLRDISP: MOV      P1, #0FFH      ; Clear the display
MOV      P2, #00H
MOV      P3, #00H
RET
DELAY1:  MOV      R5, #01        ; Switching delay between columns
HERE2:  MOV      R4, #230
HERE1:  DJNZ     R4, HERE1
DJNZ     R5, HERE2
RET
ORG      700H                  ; Codes for P1
VALUE: DB      30H, 36H, 36H, 36H, 0EH, 3BH, 57H, 6FH
DB      57H, 3BH, 3EH, 5EH, 6EH, 76H, 78H, 7FH
DB      7FH, 7FH, 7FH, 7FH, 00H, 77H, 77H, 77H
DB      00H, 00H, 7BH, 77H, 6FH, 00H, 00H, 76H
DB      76H, 76H, 79H, 7FH, 7FH, 7FH, 7FH, 7FH

```

```

DB          7FH, 7FH, 7FH, 7FH, 7FH, 7FH, 7FH, 7FH
DB          7FH, 7FH, 7FH
END

```

- **Software Explanation**

Software provides initialization and data write function for the display module. Row selection codes are controlled by Port 1 of microcontroller and are stored in memory location at address 700h. These row selection codes can be fetched by means of data pointer (DPTR). Initially data pointer is set to 700h memory location which points to the first row selection data code. The display is cleared by providing the opposite logic to Port 1, Port 2, and Port 3 by means of the sub-routine CLRDISP. For the data write on display module DATANXT sub-routine is executed in the program. In DATANXT sub-routine R1 is used for column selection. R3 set to 00h to get 1st code from data pointer address (700h). R6 and R7 provides the continuous display for one whole fifteen data write function for certain period of time (approx. 1 sec.). Initially the value of R3 = 00h so when first time the instruction MOVC A,@a+DPTR is executed the data present at memory location 700h is stored in A. That is the data for row selection, and is sent to Port 1. Now the column is selected to display the row data. So the register R1 is used to provide the P3 the column selection codes. After that rotating the data of R1 by means of accumulator using RL A instruction to get the next column selection code. Incrementing DPTR provides next row selection codes. As the Port 3 eight bits are controlling the eight column selection codes we are comparing the R3 with 08h by means of CJNE R3,#08,NXTDATA. If R3 is less than 08h the program jump to NXTDATA otherwise step down and execute the next instruction. After eight data write column selection, Port 2 is activated to control the next seven column selection codes. NXTDATA1 is same as NXTDATA, the only difference is in column selection which is now controlled by Port 2. After the completion of DATANXT routine DPTR is incremented once and column selection codes are left as it is, so that the display moved the one column left. And fetch the new column selection (C01) on very right side of the display module. Again the DATANXT is called to provide the data write function to the microcontroller ports. This increment in DPTR causes the program to start fetching row codes from next memory address 700h onwards which in results visualizes the moving message on the display.

In this program appropriate delay is provided by means of DELAY1 sub-routine so that change in each row-column selection code is not visualized by human eye and constant moving message is displayed on the 15x7 display module.

- **FINAL OUTPUT**

Program given here will display moving message of “5x7 HNP” continuously.



CHAPTER 9

ADVANCE EXPERIMENTS ON LCD INTERFACE



9.1 INTRODUCTION

Sometimes it becomes necessary to display complex message which can not be tackled by simple LED's or 7-segment displays. Such display messages could be made up of numbers, characters of the alphabet, and other symbols. This type of display messages can be handled by different types of LCD modules.

A module contains one or more rows of character positions. Each character position consists of a matrix that is typically five segments, or dots wide and eight segments tall. The module forms characters by turning on the appropriate segments in a character position. LCD's are available in several sizes 1x16(1 line of 16 characters), 2x16, and 2x20 are some popular sizes used in products.

In this chapter emphasis on LCD interface with microcontroller based system is done.

9.2 BASICS OF LCD MODULE USED^[R.P-7]

In this experiment 1x16 LCD module is used. Table 9.1 summarizes the signals in the 1x16 LCD modules.

PIN	SYMBOL	INPUT/OUTPUT	FUNCTION
1	GND	INPUT	SIGNAL GROUND
2	VDD	INPUT	SUPPLY VOLTAGE (+5V)
3	V0	INPUT	CONTRAST ADJUST
4	RS	INPUT	REGISTER SELECT (1=DATA; 0=INSTRUCTION REGISTER, BUSY FLAG/ADDRS COUNTER)
5	R/W	INPUT	READ (1)/WRITE(0) SELECT
6	E	INPUT	ENABLE
7	DB0	INPUT/OUTPUT	DATA BIT 0
8	DB1	INPUT/OUTPUT	DATA BIT 1
9	DB2	INPUT/OUTPUT	DATA BIT 2
10	DB3	INPUT/OUTPUT	DATA BIT 3
11	DB4	INPUT/OUTPUT	DATA BIT 4
12	DB5	INPUT/OUTPUT	DATA BIT 5
13	DB6	INPUT/OUTPUT	DATA BIT 6
14	DB7	INPUT/OUTPUT	DATA BIT 7
15	BL1	INPUT	BACKLIGHT (ANODE)
16	BL2	INPUT	BACKLIGHT (CATHODE)

TABLE 9.1: SIGNALS OF 1X16 LCD MODULE

LCD modules use backlighting to allow viewing in dim light. A module may be reflective (which does not use backlight), Transmissive (which must use backlight), or transfective (which may use backlight or not).

LCD module is a specialized microcontroller in it self. It contains its own RAM and ROM, and executes the instructions shown below in Table 9.2.

INSTRUCTION	RS	R/W	D7	D6	D5	D4	D3	D2	D1	D0	FUNCTION
DISPLAY CLEAR	0	0	0	0	0	0	0	0	0	1	CLEAR DISPLAY, RESET DISPLAY FROM SHIFT, SET DDRAM=0
CURSOR HOME	0	0	0	0	0	0	0	0	1	X	SHIFT=0, DDRAM=0
ENTRY MODE SET	0	0	0	0	0	0	0	1	I/D	S	I/D: INCREMENT(1) , DECREMENT(0) CURSOR OR DISPLAY SHIFT AFTER DATA TRANSFER
DISPLAY ON/OFF	0	0	0	0	0	0	1	D	C	B	D: DISPLAY ON (1), OFF (0) C: CURSOR ON (1), OFF (0) B: CURSOR BLINK ON (1), OFF (0)
DISPLAY/CURSOR SHIFT	0	0	0	0	0	1	S/C	R/L	X	X	S/C: SHIFT DISPLAY (1), CURSOR (0) R/L: SHIFT RIGHT (1), LEFT (0)
FUNCTION SET	0	0	0	0	1	DL	N	0	X	X	DL: 8-BIT (1), 4-BIT (0) INTERFACE N: DUAL (1), SINGLE (0) LINE DISPLAY
CG RAM ADDRS SET	0	0	0	1	CG5	CG4	CG3	CG2	CG1	CG0	LOAD ADDRS COUNTER WITH CG0- CG5 SUBSEQUENT DATA GOES TO CGRAM
DD RAM ADDRS SET	0	0	1	DD6	DD5	DD4	DD3	DD2	DD1	DD0	LOAD ADDRS COUNTER WITH DD0 TO DD6 SUBSEQUENT DATA GOES TO DDRAM

BUSY FLAG/ADDRS COUNTER READ	0	1	BF	AC6	AC5	AC4	AC3	AC2	AC1	AC0	READ BUSY FLAG (BF) AND 0 ADDRS COUNTER (AC0-AC6)
CG/DD RAM DATA WRITE	1	0	D7	D6	D5	D4	D3	D2	D1	D0	WRITE DATA (D0-D7) TO CGRAM OR DDRAM
CG/DD RAM DATA READ	1	1	D7	D6	D5	D4	D3	D2	D1	D0	PLACE DATA FROM CGRAM OR DDRAM ON D0-D7

TABLE 9.2 INSTRUCTION TABLE

Here 16x1, CFAH1601A-YYB-JB LCD module is used. One can use any 16x1 module. Figure 9.1, shows the block diagram of an LCD module.




FIGURE 9.1 BLOCK DIAGRAM OF LCD MODULE

The modules on chip memory include a CG (character generator) ROM, CGRAM, DD (display data) RAM, an instruction register, and a data register. The CGROM stores patterns for generating 192 different characters. These are fixed in ROM and can not be altered. The CGRAM stores segment patterns for up to 16 user

designed characters such as logos, special symbols, or other simple graphics characters that we design on the 5x8 matrix. To create a custom character, we write a series of 5-bit words to the CGRAM. Each word represents the segment pattern for one row in the desired character. The patterns stored in CGRAM disappear on powering down, so we must reload them on each time we power up. Each character in the CGROM and CGRAM has an 8-bit address, or character code. Conveniently, the codes for the upper and lower case Roman alphabet and common punctuation are same as the ASCII codes for those characters (21h through 7dh). For example, the pattern for A is stored at address 41h, B is stored at 42h, and so on. An 8-bit instruction register (IR) stores instruction code and addresses, and an 8-bit data register (DR) stores character codes. When we read or write to the chip, we must select the appropriate register. The DDRAM stores up to eighty 8-bit character codes each character position on the display corresponds to an address in the DDRAM, and the character codes stored in the DDRAM determine what is displayed at each position.

Display position DDRAM address is shown below in Table 9.3 for the LCD module.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
00h	01h	02h	03h	04h	05h	06h	07h	40h	41h	42h	43h	44h	45h	46h	47h

TABLE 9.3 ADDRESSES FOR DISPLAY POSITION

On power on the LCD DDRAM is set to 00h, so we can directly write data to first 8-bits from left side as shown in Table 3. However, the 9th character as shown in memory map is at address 40h. This means that if we write a character after 8th character directly it will not appear on 9th character position. That is because the 9th character will effectively be written to address 09h, but the 9th character position is at address 40h.

Thus we need to send command to the LCD that tells it to position the cursor on the 9th character position. The “set cursor position” instruction is 80h. To this we must add the address of the location where we wish to position the cursor. So to display character at 9th position we must add 80h + 09h = 0C0h. Thus sending 0C0h to the LCD will position the cursor on 9th character position of the LCD and write the user defined character.

9.3 INTERFACING OF LCD MODULE WITH MICROCONTROLLER 89C51

Figure 9.2, shows the schematic diagram of the interface module.




FIGURE 9.2 SCHEMATIC DIAGRAM OF INTERFACE MODULE

All required signals are taken out to connector J1. Pin configuration of J1 is as follows:

<u>PIN NUMBER</u>	<u>SIGNAL</u>	<u>PIN NUMBER</u>	<u>SIGNAL</u>
1	GND	8	D2
2	VCC	9	D3
3	RS	10	D4
4	R / W	11	D5
5	E	12	D6
6	D0	13	D7
7	D1	14	VCC

Note that BL1 (anode) connected to VCC and BL2 (cathode) connected to GND and 10k pot is connected to set the contrast of the LCD.

- Connection Details of LCD Module with AT89C51 Microcontroller Ports**

<u>Signal from J1</u>	<u>AT89C51</u>	<u>Signal from J1</u>	<u>AT89C51</u>
GND	GND	D2	P1.2
V _{CC}	V _{CC}	D3	P1.3
RS	P3.2	D4	P1.4
R / W	P3.3	D5	P1.5
E	P3.4	D6	P1.6
D0	P1.0	D7	P1.7
D1	P1.1		

• **SOFTWARE FLOWCHART**




FIGURE 9.3 SOFTWARE FLOW CHART

- **LCD MODULE SOFTWARE: -**

Software for LCD initialization and data write is self explanatory and is

given as below:

; **Name plate** using LCD

; LCD initialization and DATA1 write program

; Main program

\$MOD51

DB0	EQU	P1.0	; Equate P1, P1.0 to P1.7
DB1	EQU	P1.1	; to DB0-DB7
DB2	EQU	P1.2	
DB3	EQU	P1.3	
DB4	EQU	P1.4	
DB5	EQU	P1.5	
DB6	EQU	P1.6	
DB7	EQU	P1.7	
EN	EQU	P3.4	; Equate P3, P3.2 to P3.4
RW	EQU	P3.3	; to EN, RW, RS

respectively

RS	EQU	P3.2	
DATA1	EQU	P1	; Equate P1 to DATA1
	AJMP	MAIN	
	ORG	130H	; Start program from 130h

MAIN:

MOV	SP, #50H	; Move stack pointer to 50h
LCALL	INIT_LCD	; Call initialization codes
LCALL	CLEAR_LCD	; Call clear LCD codes
CLR	RS	; Set cursor to 00h of LCD
MOV	DATA1, #80H	; Means 80h+00h=80h
SETB	EN	; HI to LO pulse
NOP		
NOP		
NOP		
NOP		
NOP		

```

NOP
NOP
CLR      EN
LCALL    WAIT_LCD      ; Give time to LCD for data
MOV      A, #'D'        ; Start giving data to LCD
LCALL    WRITE_TEXT     ; to be displayed from 80h
MOV      A, #'r'
LCALL    WRITE_TEXT     ; Writes data to LCD
MOV      A, #'.'
LCALL    WRITE_TEXT
MOV      A, #'K'
LCALL    WRITE_TEXT
MOV      A, #'.'
LCALL    WRITE_TEXT
MOV      A, #'P'
LCALL    WRITE_TEXT
MOV      A, #'.'
LCALL    WRITE_TEXT
MOV      A, #'J'        ; Cursor position at 87h
LCALL    WRITE_TEXT
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP
CLR      RS
MOV      DATA1, #0C0H   ; move cursor to 0C0h
SETB     EN              ; i.e. 80h+40h=0C0h
NOP
NOP
NOP
NOP

```

```

NOP
NOP
NOP
CLR      EN
LCALL    WAIT_LCD
MOV      A, #'O'      ; Start giving data to Display
LCALL    WRITE_TEXT
MOV      A, #'S'
LCALL    WRITE_TEXT
MOV      A, #'H'
LCALL    WRITE_TEXT
MOV      A, #'I'
LCALL    WRITE_TEXT
MOV      A, #'P'
LCALL    WRITE_TEXT
MOV      A, #'U'
LCALL    WRITE_TEXT
MOV      A, #'R'
LCALL    WRITE_TEXT
MOV      A, #'A'
LCALL    WRITE_TEXT
LCALL    DEL1          ; Stay here for a while
LCALL    DEL1
LCALL    DEL1
LCALL    RET_HOME     ; Again back to 80h
LCALL    CLEAR_LCD    ; Clear LCD cursor on Right
CLR      RS
MOV      DATA1, #80H  ; Set cursor to 80h
SETB     EN
NOP
NOP
NOP
NOP
NOP

```

```

NOP
NOP
CLR      EN
LCALL    WAIT_LCD
MOV      A, #'V'           ;Display data
LCALL    WRITE_TEXT
MOV      A, #'I'
LCALL    WRITE_TEXT
MOV      A, #'C'
LCALL    WRITE_TEXT
MOV      A, #'E'
LCALL    WRITE_TEXT
MOV      A, #'-'
LCALL    WRITE_TEXT
MOV      A, #'C'
LCALL    WRITE_TEXT
MOV      A, #'H'
LCALL    WRITE_TEXT
MOV      A, #'A'
LCALL    WRITE_TEXT
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP
CLR      RS
MOV      DATA1, #0C0H     ; Set cursor to 0C0h
SETB     EN
NOP
NOP
NOP
NOP

```

```

NOP
NOP
NOP
CLR      EN
LCALL    WAIT_LCD
MOV      A, #'N'          ; Display DATA
LCALL    WRITE_TEXT
MOV      A, #'C'
LCALL    WRITE_TEXT
MOV      A, #'E'
LCALL    WRITE_TEXT
MOV      A, #'L'
LCALL    WRITE_TEXT
MOV      A, #'L'
LCALL    WRITE_TEXT
MOV      A, #'O'
LCALL    WRITE_TEXT
MOV      A, #'R'
LCALL    WRITE_TEXT
MOV      A, #' '
LCALL    WRITE_TEXT
LCALL    DEL1
LCALL    DEL1

INIT_LCD:                                ; LCD ready subroutine

CLR      RS                ; RS=0
MOV      DATA1, #38H       ; Function set for 1line, 5x8
SETB     EN                ; HI to LO pulse
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP

```

```

        CLR        EN
        LCALL      WAIT_LCD        ; Check for data fetch
        CLR        RS              ; RS=0
        MOV        DATA1, #0EH    ; Display on, cursor on cmd
        SETB       EN              ; HI to LO pulse
        NOP
        NOP
        NOP
        NOP
        NOP
        NOP
        NOP
        CLR        EN
        LCALL      WAIT_LCD        ; Check for data fetch
        CLR        RS              ; RS=0
        MOV        DATA1, #06H    ; Entry mode set for LCD
        SETB       EN              ; HI to LO pulse
        NOP
        NOP
        NOP
        NOP
        NOP
        NOP
        CLR        EN
        LCALL      WAIT_LCD        ; Check for data fetch
        RET          ; Return to main program

CLEAR_LCD:
        CLR        RS              ; RS=0
        MOV        DATA1, #01H    ; Clear LCD cmd
        SETB       EN              ; HI to LO pulse
        NOP
        NOP
        NOP

```

```

NOP
NOP
NOP
NOP
CLR      EN
LCALL    WAIT_LCD      ; Check for data fetch
RET      ; Return to main program
WRITE_TEXT:
          ; Write DATA to LCD
SETB     RS             ; RS=1
MOV      DATA1 ,A      ; Move desired char to P1
SETB     EN             ; HI to LO pulse
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP
NOP
CLR      EN
LCALL    WAIT_LCD      ; Check for data fetch
RET      ; Return to main program
WAIT_LCD:
          ; Check for data fetch
MOV      R2, #03H       ; Count in R2
MOV      R3, #0FFH      ; Count in R3
CLR      EN             ; EN=0, RS=0, RW=1
CLR      RS
SETB     RW
MOV      DATA1, #0FFH   ; P1 as input port
SETB     EN             ; EN=1
MOV      A, DATA1       ; Get data from P1
LOOP:    JB      ACC.7, HERE2 ; Check for DB7 Bit
HERE2:   NOP             ; High=check more
NOP
DJNZ     R3, HERE2

```


	DJNZ	R2, LOOP	
	CLR	EN	; Otherwise EN=0,
	CLR	RW	; RW=0
	LCALL	DELAY	; Provide delay
	RET		; Return to main program
RET_HOME:			
	CLR	RS	; RS=0
	MOV	DATA1, #20H	; Return home cmd
	SETB	EN	; HI to LO pulse
	NOP		
	NOP		
	NOP		
	NOP		
	NOP		
	NOP		
	NOP		
	CLR	EN	
	LCALL	WAIT_LCD	; Check for data fetch
	RET		; Return to main program
DELAY:	MOV	R2, #03	; More than 2ms delay
AGAIN:	MOV	R3, #250	
HERE1:	NOP		
	NOP		
	DJNZ	R3, HERE1	
	DJNZ	R2, AGAIN	
	RET		; Return to main program
DEL1:	MOV	89H, #10H	; More than 2s delay
	MOV	R5, #25	
AGAIN1:	MOV	8BH, #00H	
	MOV	8DH, #00H	
	MOV	88H, #60H	
PON:	JNB	8FH, PON	
	MOV	88H, #00H	
	DJNZ	R5, AGAIN1	
	RET		; Return to main program
	END		; End of Program

• **FINAL OUTPUT: -**

Program given here will Display “Dr. K. P. JOSHIPURA” first and then it is cleared to display “VICE-CHANCELLOR”, and keeps on displaying these two words one by one continuously.

SECTION 4

DEVELOPMENT TOOLS





CHAPTER 10

ADVANCE EXPERIMENTS ON LOGIC ANALYZER



10.1 INTRODUCTION: -

The logic analyzer is an instrument, which provides the analysis of the logical states of digital signals with respect to time. Here, a logical state means the HIGH or LOW conditions of the digital signals with respect to time.

In digital circuits, particularly microprocessor based circuits, it is very important to know the timing relation of various signals. Such information (of timing relation) provides the ways to determine whether the system under test is working properly or not. Conventional tools, like oscilloscope is not useful to correlate the timings of digital signals, because it has limited capacity to “catch” the number of signals and low operating frequency. Generally, in complex digital circuit, e.g. microprocessor system, there is usually eight or more number of signals to be analyzed. So, for such systems logic analyzer is the proper tool. It is also known as “Hardware debugging” tool.

PRINCIPLE OF WORKING:-

Basically logic analyzer works on the principle of sampling the information of signal states at very fast rate (compared to repetitive rate of signals); then storing this information into proper sized memory and later, display it on the screen for user’s analysis.

For such sampling work, the logic analyzer has a “data capture” unit, which collects the data (logical state conditions at various points of time of signals under consideration).

CONSTRUCTION OF LOGIC ANALYZER:-

The logic analyzer can be divided into following simple parts in first attempt of understanding.

- 1) DATA CAPTURE UNIT
- 2) DATA STORAGE
- 3) DATA PROCESSING AND RELATED ELECTRONICS
- 4) DATA DISPLAY UNIT
- 5) KEY BOARD / CONTROL PANEL

1) DATA CAPTURE UNIT: -

A typical data capture unit is shown in figure 10.1. It has a small PCB fixed into a small metal case with connector at two ends. The PCB contains proper electronics component to collect the information of the logic states of all parallel inputs (channels).

One connector is having pins, which are to be connected with signals under consideration through the test probes called “pods”. For each pin of connector a separate pod is provided. One end of pod is connected with the pin of the connector and other end of pod is connected with signal. The connecting point for a signal can be a separate wire, a pin or directly the pin of some IC of interest. Usually, signals of a typical microprocessor based system are the pins of output bus connector (e.g. system expansion connector).

The other connector of capture unit contains pins to be interfaced with the parallel port of computer. So, a centronics cable will be enough to connect the data capture unit with the computer parallel port.




FIGURE 10.1 TYPICAL DATA CAPTURE UNIT

2) DATA STORAGE: -

This is made of a bank of memory chips. The collected information of all channels is stored in these chips for further processing. Information is collected every clock time of analyzer. Generally, logic analyzer has limited capacity of storage.

3) DATA PROCESSING AND RELATED ELECTRONICS:-

This is associated with the interfacing card plugged into free slot of the motherboard of the computer.

4) DATA DISPLAY UNIT:-

The monitor of the PC is used as display unit. The software supplied with PC-based analyzer, controls the means and types of displays on screen in user-friendly ways.

5) KEYBOARD / CONTROL PANEL:-

In PC-based logic analyzer the PC ASCII keyboard is just sufficient for all control and parameter settings. Even mouse also can be used.

DETAILED WORKING OF A LOGIC ANALYZER: -

We will divide this topic into various sections to discuss systematically how one can use the logic analyzer. We will mostly consider PC based logic analyzer. Following section will help to understand.

1) HARDWARE PREPARATION:-

The digital circuit which we want to test for proper functioning is called “TARGET”. First of all decide which are the signals, which you want to study for proper functioning of the circuit. The circuit may be microprocessor-based system.

Now associate these signals with the numbers of the channels of logic analyzer by noting the names of the signals with number of the channel pins of capture unit. Consider the following case where some address lines, data lines and control signals of microprocessor circuit are shown associated with pins (channels) of the capture unit.

Name of the signals	Pin number of capture unit	Name of the signals	Pin number of capture unit
ADDR0	1	DATA4	13
ADDR1	2	DATA5	14
ADDR2	3	DATA6	15
ADDR3	4	DATA7	16
ADDR4	5	ALE	17
ADDR5	6	RD	18
ADDR6	7	WR	19
ADDR7	8	S0	20
DATA0	9	S1	21
DATA1	10	CLK	22
DATA2	11	X	23
DATA3	12	X	24

TABLE 10.1 ASSOCIATED WITH PINS (CHANNELS) OF THE CAPTURE UNIT

In above Table 10.1, 24-channel logic analyzer is considered, 22 channels are used, one can associate any signal with any pin of the capture unit.

Now, with such note, physically connect the signals using pods with the pins of capture unit one by one. After this connect the other connector with the parallel

port of pc through a cable (e.g. LPT1). At this stage we would assume that we want to test the proper working of a microprocessor training kit. So, now turn on the power of the kit. Load a small program. Note that you must have thorough idea of how each instruction of this program is being executed through the hardware of microprocessor kit. This will help to analyze the signals captured by logic analyzer.

2) CONFIGURING THE ANALYZER: -

Configuring the analyzer is a process of letting the analyzer know how it has to work. It is also called setup procedure. Typically following things are to be set.

A) Clock: -

Specify whether you want internal or external clock. Here internal clock means the clock of logic analyzer while external clock means the clock of the target or any other external reference clock. For every clock pulse the parallel inputs are sampled and the logic levels (0 or 1) stored in the analyzer memory.

B) Rate: -

If you have selected internal clock then you may have to specify the clock speed (or sampling rate of logic analyzer). There may be few options. Select the befitting.

C) Display: -

Here you have to choose (setup) the type of display information. Generally, there are three options. Timing waveforms, state list or mixed.

a) Timing waveform: -

In this display mode, the screen shows the captured data graphically as a series of waveforms, one for each channel. The channels are listed along the Y-axis. The X-axis represents the position in the data buffer in order of increasing time. Here, you can compare the logical states of signals with respect to time cursor may help for this.

b) State list:-

In this display mode, data for each position is shown grouped and can be loaded into ASCII, Hexadecimal, Binary and Decimal format. Each data point position in the state display is numbered. The display can be scrolled up or down.

c) Mixed Mode: -

In this mode, the screen is divided into two parts: one area for a state list display and another for timing display. The topmost line of the state list always is the leftmost point display in the timing waveform, but selections scroll together when moving through the data. Cursors appear at the same data positions in the state list and timing sections.

All above three options can have more setup parameters, e.g. timing mode may offer the name to be associated with channels.

D) Trigger: -

The technique of starting the analyzer at a specific point is called “triggering”. There are two triggering methods.

a) Edge triggering: -

Here, one of the parallel inputs is selected as the trigger signals and the logic level desired is selected. The hardware is started and when desired trigger occurs (a transition from low to high, for example) the logic analyzer starts recording the data. This method is convenient in simple situation and is easy but is not sufficient in the case of complex problems where the trigger input may have transition several times in the program.

b) Word recognition: -

Here, the user selects which logic level each input must be in to trigger the logic analyzer. Unused or don't care inputs may be designated so that either logic level of the input will trigger the analyzer. One has to maintain the correspondence of input (channel) and the trigger word bits. In other words, one should find out the MSB of trigger word represents the channel 0 or highest available channel.

E) Memory: -

This option sets-up the buffer (memory) length used for acquisition. Choose the proper memory size from option available in this mode.

F) Threshold Voltage: -

This allows the voltage threshold to be set. This is the point at which the high / low (1/0) logic break occurs in the digital logic being tested. For TTL this is +1.4 Volts for CMOS this is half of V_{CC} volts, usually 2.5 Volts.

Apart from above setting the logic analyzer can be set for different colors, printing varieties, board address etc. Various file management like saving certain analysis and later loading it, renaming, directory changing may be available as per logic analyzer models.

3) RUN THE CAPTURE CYCLE: -

In this phase actual data collection is done. Normally, after proper setup ‘GO’ command may be used to start sampling. Acquire command also can be used. Acquire once or repeat randomly option may be available.

4) ANALYZE THE RESULTS:-

This is the very important part of the data collection interpretation. To help the analysis better various facilities like cursor movement in display, relative

measurement of position of states, changing channels are provided. One should refer to operation manual of concerned logic analyzer for better usage.

It also needs better understanding of what should be going on in the target digital system while capturing the data. Try to fit this understanding with the logic state display of waveform and decide the proper working of target system.

10.2 DEBUGGING OF MICROPROCESSOR KIT USING LOGIC STATE ANALYZER^[R.P-8] :-

To understand the working of a microprocessor we have to understand the timing waveforms of that microprocessor. For this, logic state analyzer is one of the best available tools. For present experiment 8085 based kit is used.

BASICS OF TIMING WAVEFORMS:

Normally, 8085 based trainer kits include 8085 processor, latches, logic ICs, memory chips, peripheral chips, keyboard, 7 segments displays etc. To test whether the hardware of the kit works properly or not, we can run a “known” program on the kit and check the “expected” timing waveforms on various pins of concerned ICs, or across connectors, whatever the case may be, using logic analyzer.

For this one must have thorough knowledge of what should be going inside the kit and the microprocessor while program is being executed.

Let us discuss this with real example. Take any microprocessor trainer kit. You must have its user’s manual with circuit layout. Load into its memory (usually RAM) the following program by entering its instruction codes.

```
START:    NOP
          MVI A, FFH
          JMP START
```

We have deliberately chosen such a small program because our aim is to understand the timing waveforms of instructions. The program includes one byte, two byte, and three bytes instructions.

We assemble and store this program from location 4000H onward. 4000H is our choice, you can have your own. The codes on locations 4000H to 4005H will be as follows:

4000	00	START:	NOP
4001	3E, FF		MVI A, FFH
4003	C3, 00, 40		JMP START

Usually, all kits have a key in keyboard to ‘run’ the program. Such keys are ‘Go’ or ‘Run’. Press ‘Go’ key. The routine for ‘Go’ will ask for program address.

Enter the address 4000H. This will make PC to contain 4000h. Hence, address pins will have logic states as shown below (during the first T-state).

Pin	Logic states	Pin	Logic states
A ₁₅	0	AD ₇	0
A ₁₄	1	AD ₆	0
A ₁₃	0	AD ₅	0
A ₁₂	0	AD ₄	0
A ₁₁	0	AD ₃	0
A ₁₀	0	AD ₂	0
A ₉	0	AD ₁	0
A ₈	0	AD ₀	0

Program Address = 4000H

In order to execute whole program 8085 will have to fetch code of first instruction, i.e. NOP, for this 8085 will generate an OF (Opcode Fetch) cycle. Since, AD₇- AD₀ pins are multiplexed, address on these pins is to be stored (latched) in other external latch IC. For this 8085 generates 'ALE' signal, which generally enables latch IC. Hence, when stable address 4000H is on address pins, ALE is generated. It lasts almost half the time of clock pulse. This clock pulse we call T₁. Now to understand following write up consider Figure 10.2. To fetch code 00 (for NOP) 8085 will generate \overline{RD} control signal in T₂ clock cycle. This will enable memory chip to give out code '00' from location 4000H on data bus D₀-D₇. So, after some time when \overline{RD} becomes low, the AD₇-AD₀ pins will receive following logic states.

AD ₇	AD ₆	AD ₅	AD ₄	AD ₃	AD ₂	AD ₁	AD ₀	
0	0	0	0	0	0	0	0	= 00H




FIGURE 10.2 TIMING WAVEFORM OF THREE INSTRUCTION PROGRAM

During this time higher byte of address ($AD_{15} - AD_8$) remains same. \overline{RD} remains low during T_2 and T_3 clock pulses. Approximately, after middle of T_3 , \overline{RD} becomes high again. At this stage code for first instruction NOP is taken in 8085 and interpreted. T_4 state is needed for interpretation. 8085 now knows that 'NOP' is only one byte instruction. So, in next location of RAM memory another code for next instruction is stored. Hence, it advances PC by one and makes it to contain 4001H to fetch the code of next instruction i.e. MVI A, FFH. Now, address pins contain logic state as follows.

Pin	Logic states	Pin	Logic states
A_{15}	0	AD_7	0
A_{14}	1	AD_6	0
A_{13}	0	AD_5	0
A_{12}	0	AD_4	0
A_{11}	0	AD_3	0
A_{10}	0	AD_2	0
A_9	0	AD_1	0
A_8	0	AD_0	1

Program Address = 4001H

A new OF starts with ALE in T_1 . Again during T_2 - T_3 , \overline{RD} goes low. The opcode byte 3E is available on data lines. 3E is interpreted during T_4 . 8085 understands that 3E is a code of two bytes instruction and second byte is stored in consecutive location. So, it makes PC = 4002H and fetches the data FFH from this

location. Like this fetching the codes and data continues which in turn makes the signals on the pins of microprocessor to change with time as shown in figure 10.2. From Figure 10.2 one can understand that first instruction NOP is made of one machine cycle M_1 (OF), second instruction “MVI A, FFH” is made of two machine cycles M_1 (OF) and M_2 (MR) while third instruction “JMP START” is made of three machine cycles M_1 (OF), M_2 (MR) and M_3 (MR). Op-code fetch is made of four T-states and memory read (MR) is made of three T-states. The timing waveforms show CLK, address lines, ALE, RD, and status line IO/\overline{M} , S_0 , S_1 which confirm the type of cycle.

○ **APPARATUS USED:**

The ESA-85 microprocessor kit manufactured by Electro Systems Associates, Bangalore and the PC-based 24-channel logic state Analyzer LA-2124 manufactured by Electro Systems Associates, Bangalore is used for this experiment. The photograph of experimental setup is shown in Figure 10.3. In Figure 10.3, the various components of the set-up are shown with their names on it, e.g. a cable connecting the capture unit with parallel port of PC is given the name “Computer interface cable”.




FIGURE 10.3 PHOTOGRAPH OF THE EXPERIMENTAL SETUP

○ **EXPERIMENTAL:**

The experimental setup for using logic analyzer includes a PC, data capture unit of logic analyzer, pods, parallel port cable and a target unit (i.e. hardware device under test). We will take microprocessor trainer kit as target system. It is assumed that you have loaded proper software of logic analyzer in the computer.

For hardware connections, we will connect “pods” with microprocessor kit and pod connector of data capture unit. Each pin of this connector is called “channel”. Each pin will be given number from 1 onwards on data capture unit. Now, one has to decide which signal of kit is to be connected with particular channel of the connector of capture unit.

Let us take the case of program that we have discussed. Figure 10.2 which shows timing waveforms of these program instructions contains 22 signals of 8085: CLK – 1, address lines –16, ALE-1, \overline{RD} -1, status lines-3. To understand, the timing waveforms of present program, we may have to connect those 22 signals with channels. The logic analyzer under consideration has total 24 channels. You can connect two more signals of 8085 of your choice, e.g. \overline{WR} and READY (they are optional). Table 10.1 guides you how to connect pods.

After connecting pods, turn on the PC and run the software of logic analyzer. The starting screen will be different depending on the type of logic analyzer. You may have to set the following.

- **CLOCK:** Select the clock source, i.e. internal (from logic analyzer) or external (from target system). We select external clock.
- **RATE:** If you select internal clock, then you may have to specify clock speed.
- **DISPLAY:** You have to specify one of the following
 1. Timing waveform
 2. State list
 3. Mixed mode

For present case, choose “Timing waveform”.

- **TRIGGER:** The technique of starting the analyzer (to collect or acquire data) at a specific point is called trigger.

Word recognition is one of the ways for triggering logic analyzer. One can select the specific condition of signals to take place and at that point trigger the logic analyzer. For example, in our program, the first instruction is NOP, stored at 4000h location. If you want to start the logic analyzer at the beginning of execution of this instruction the logic states of the signals are as follows.

CHANNEL	SIGNALS	STATUS	CHANNEL	SIGNALS	STATUS
CH ₀	CLK	LOW	CH ₁₂	AD ₄	LOW
CH ₁	A ₁₅	LOW	CH ₁₃	AD ₃	LOW
CH ₂	A ₁₄	HIGH	CH ₁₄	AD ₂	LOW

CH ₃	A ₁₃	LOW	CH ₁₅	AD ₁	LOW
CH ₄	A ₁₂	LOW	CH ₁₆	AD ₀	LOW
CH ₅	A ₁₁	LOW	CH ₁₇	ALE	HIGH
CH ₆	A ₁₀	LOW	CH ₁₈	$\overline{\text{RD}}$	HIGH
CH ₇	A ₉	LOW	CH ₁₉	$\overline{\text{WR}}$	HIGH
CH ₈	A ₈	LOW	CH ₂₀	IO / $\overline{\text{M}}$	LOW
CH ₉	AD ₇	LOW	CH ₂₁	S ₁	HIGH
CH ₁₀	AD ₆	LOW	CH ₂₂	S ₀	HIGH
CH ₁₁	AD ₅	LOW	CH ₂₃	READY	HIGH

CH₀ is considered LSB and CH₂₃ is considered MSB of the 24 bit trigger word. So, our trigger word becomes

CH ₂₃	CH ₂₂	CH ₂₁	CH ₂₀	CH ₁₉	CH ₁₈	CH ₁₇	CH ₁₆	CH ₁₅	CH ₁₄	CH ₁₃	CH ₁₂
1	1	1	0	1	1	1	0	0	0	0	0
CH ₁₁	CH ₁₀	CH ₉	CH ₈	CH ₇	CH ₆	CH ₅	CH ₄	CH ₃	CH ₂	CH ₁	CH ₀
0	0	0	0	0	0	0	0	0	1	0	0

Enter this binary data to frame trigger word in logic analyzer. Put the trigger cursor at zero buffer location. So, display will show captured data from very first buffer location when trigger word matches.

MEMORY:

This option sets-up the buffer (memory) length used for acquisition. Choose proper size. There may be few trivial settings. We at present don't consider them. For better understanding one must refer to manual of one's logic analyzer. Now turn on the power of kit. Enter the codes from 4000H location onward, and run the program. Power on the data capture unit. Now, give command to capture data. Within no time, captured data will be displayed on monitor screen. Fig 10.4 shows the timing waveform for our program.

○ RESULT AND DISCUSSION:

From Figure 10.4 you will realize that we have named all 24 channels having correspondence with 8085A signals, viz, CLK, A₁₅, READY. Note that READY is actually not connected with logic analyzer. These channel names are at the extreme left side of the display (i.e. column 1 of display). Column number three displays the binary values, i.e. High or Low of the all signals at the position where cursor is lying. At the top right corner you will find three cursors named A, B and T. A is positioned at location 000690, B is positioned at 000900 and T is at 000000. See Figure 10.4. These positions are the various location number of 2K buffer memory. Also note that B-T = 000018000ns is also displayed at top right corner. This is the

difference of positions of cursor B and T in memory location, i.e. $B - T = 900 - 000 = 900$ converted into time scale of nanoseconds. Each clock pulse is of 20ns. The data of 900 pulses are stored in 900 location (rate = 50 MHz). So, $B - T = 900 \times 20\text{ns} = 18000\text{ns}$. With arrow keys of ASCII keyboard you can move cursor left or right.




FIGURE 10.4 THE DISPLAY OF LOGIC STATE OF THREE INSTRUCTION PROGRAM OBTAINED BY LOGIC STATE ANALYZER LA2124

From above discussion the important information for us is that from location zero, whatever signals we wanted to capture are displayed at the time of triggering event-taking place. So, all waveforms from extreme left of them start showing logic states starting at location zero. You can easily match the data of logic analyzer with our theoretical prediction of waveforms. At extreme top right number X1101110 00000000 00000100 is the trigger word that we have framed. In this number X is there because we have not connected READY signal (23rd channel) with logic analyzer.

From analysis purpose we have marked some cursor positions on Figure 10.4 to compare it with marked position of Figure 10.2. These marks are referred to as t_1 , t_2 , t_3 , t_4 , t_5 , t_6 , t_7 , t_8 , t_9 . Since, machine cycles are not mentioned in standard display of logic analyzer, we have manually indicated them as M_1 , M_2 ...etc. in Figure 10.4. Comparing the logical states at marked position t_1 , t_2 , t_3 , t_4 , t_5 , t_6 , t_7 , t_8 , t_9 of Figure 10.2 and Figure 10.4 we can construct a table as shown in Table 10.2. Here, predicted signal waveforms and captured signal waveforms can be compared for proper working of the program under consideration. The comparison reveals that the microprocessor kit works properly because expected timing waveforms are exactly reproduced on the logic analyzer display. Note that t_1 , t_2 , ..., t_9 of logic state analyzer

are shown in binary high or low and t_1, t_2, \dots, t_9 of predicted waveforms are shown in hexadecimal as well as in binary high or low states. For example, for predicted signal waveform (Figure 10.2), entry 40H against marking t_1 represents logical states of address pin A_{15} to A_8 while 00 for the same t_1 represents address/data AD_7 to AD_0 .

signals	Output of logic analyzer (Fig. 4)									Predicted signal waveform (Fig.1)								
	T 1	T 2	T 3	T 4	T 5	T 6	T 7	T 8	T 9	T ₁	T ₂	T ₃	T ₄	T ₅	T ₆	T ₇	T ₈	T ₉
CLK	0	1	0	0	1	0	0	0	0	<div> <div>40 40 40 40 40 40 40 40 40</div> <div>H H H H H H H H H</div> </div>								
A ₁₅	0	0	0	0	0	0	0	0	0									
A ₁₄	1	1	1	1	1	1	1	1	1									
A ₁₃	0	0	0	0	0	0	0	0	0									
A ₁₂	0	0	0	0	0	0	0	0	0									
A ₁₁	0	0	0	0	0	0	0	0	0									
A ₁₀	0	0	0	0	0	0	0	0	0									
A ₉	0	0	0	0	0	0	0	0	0									
A ₈	0	0	0	0	0	0	0	0	0									
AD ₇	0	0	0	0	0	1	0	1	0	<div> <div>00 00 01 3E 02 FF 03 C3 04</div> <div>H H H H H H H H H</div> </div>								
AD ₆	0	0	0	0	0	1	0	1	0									
AD ₅	0	0	0	1	0	1	0	0	0									
AD ₄	0	0	0	1	0	1	0	0	0									
AD ₃	0	0	0	1	0	1	0	0	0									
AD ₂	0	0	0	1	0	1	0	0	1									
AD ₁	0	0	0	1	1	1	1	1	0									
AD ₀	0	0	1	0	0	1	1	1	0									
ALE	1	0	1	0	0	0	1	0	1	1	0	1	0	0	0	1	0	1
\overline{RD}	1	0	1	0	1	0	1	0	1	1	0	1	0	1	0	1	0	1
\overline{WR}	1	1	1	1	1	1	1	1	1	X	X	X	X	X	X	X	X	X
IO / \overline{M}	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S ₁	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1
S ₀	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0

TABLE 10.2: COMPARISON OF PREDICTED SIGNAL WAVEFORM WITH SIGNALS WAVEFORMS CAPTURED BY LOGIC ANALYZER



CHAPTER 11

ADVANCE EXPERIMENTS ON PCICE



11.1 INTRODUCTION: -

Emulation means attempting to be equal. In our context, the emulation is aimed at making a target microprocessor system equal in performance to a developed and working system. Here, “In-circuit” means within the target system circuit, and “Emulator” means a tool or device which helps to develop a target into working microprocessor system.

Basically, ICE can do the following

1. Read or write memory locations or Input-Output (I/O) ports of target.
2. Display CPU registers.
3. Change CPU status.
4. Map selectively memory or I/O ports of the target system into resources of the development system.
5. Execute software on the target, with single step or trace facility.

Now a days PC based ICEs are very popular. Hence, we will consider one such ICE made by Electro System Associate, Bangalore.

11.2 USING ICE IN THE LABORATORY^[R.P-9]: -

In-Circuit Emulator provides the probing without affecting the circuit function so it becomes very useful experiment in the laboratory. The installation of ICE is necessary to understand in order to use with the target. We have considered ESA-85 microprocessor kit as a target here. We use ICE to test the memory and I/O section of the given kit.

- **Experimental:-**
- **Hardware installation of ICE:-**

PC based ICEs are supplied with one PC adapter card, main control unit and target adapter.

The PC-adapter card fits into the free slot of motherboard of a PC. Then main unit is connected with this adapter card through 1 to 1 cable. The adapter has some DIP switches. By setting them on or off one can select desired I/O address for ICE.

The target adapter fits into the target. The target can be a system being developed or a microprocessor kit. Remove the 8085 of the target and insert this adapter.

○ **Software installation of ICE:-**

The PCICE is equipped with its own software. Load the software properly in your PC. For Electro System Associates made PCICE, this file is PCICE.EXE.

Now switch on the power supply of ICE and turn on computer. Run PCICE.EXE. If installation is proper, a prompt with '>' sign will appear (in ESA PCICE).

Now, we want to know how to use PCICE. For this we will consider a working microprocessor kit. We have used ESA85-2 kit of Electro System Associates, Bangalore. Remove the 8085A Processor from the Kit and fix the target adapter in its place. The other end of target adapter fits into the main unit of PCICE.

Testing a microprocessor Kit:-

We have considered the microprocessor kit as our target system. To check its proper working we should have the details of its memory and I/O hardware. For ESA85-2 kit following are the details:

1) Memory:-

Device	Memory capacity	Address range
27128 (EPROM) at U5	16K X 8	0000 to 3FFF
62256 (RAM) at U7	32K X 8	8000 to FFFF
2764 (EPROM) at U6		4000 to 5FFF (6000 to 7FFF)
6264 (RAM) at U6		4000 to 5FFF (6000 to 7FFF)
27128 (EPROM) at U6		4000 to 7FFF
62256 (RAM) at U6		4000 to 7FFF

TABLE 11.1: MEMORY MAP OF ESA85-2 KIT

From table 11.1 we learn that in ESA85-2 kit whole 64K bytes of address space is divided such that 0000 to 3FFF, i.e. 16K bytes are occupied by EPROM and 8000 to FFFF i.e., 32K bytes are occupied by RAM. From 4000 to 7FFF, i.e. 16K space is free for user expansions. User can fix 2764/27128 EPROM or 6264/62256 RAM at this locations. We assume that user has not used this space. So, from 0000 to 3FFF and 8000 to FFFF location are available.

2) I/O addressing:-

I/O DEVICE	ADDRESS	USAGE
8255A: 1 at U40 Port A Port B Port C Control Port	00H 01H 02H 03H	This chip is available to user and signals are available at J1 connector.
8255A: 2 at U35 Port A Port B Port C Control Port	40H 41H 42H 43H	This 8255 chip is also available to user and signals are available at J2 connector.
8255A: 3 at U36 Port A Port B Port C Control Port	60H 61H 62H 63H	This chip is not available to user. It is used used for implementing PROM processing system.
8253: U8 Port A Port B Port C Control Port	10H 11H 12H 13H	Timer 0 is used in single stepping Timer 1 is used for baud clock generation Timer 2 is available to user. Signals are available on connector P2.
8251A at U2 Data port Command port	20H 21H	Used for serial communication.
8279 at U22 Data port Command port	30H 31H	Used for implementing keyboard / display interface.
8259 at U4 Data port Command port	51H 52H	Available to user provides support up to 8 interrupts.
8255: 4 at U12 Port A Port B Port C	70H 71H 72H	Used for reading the DIP switch and for implementing parallel printer interface and audio tape interface

Command port	73H	
--------------	-----	--

TABLE 11.2 I/O ADDRESSING OF ESA85-2 KIT

We are now ready to test proper working of kit using PCICE. But for that one must know basic commands of PCICE. Following is a brief list of all these commands for PCICE made by Electro System Associates, Bangalore.

Command summary

All PCICE commands accept parameters, except Q command. Parameters are separated by commas or spaces.

MEMORY RELATED COMMANDS

1) Specifying valid address:-

Allocation in memory can be specified by this command. A hexadecimal number or a symbol can be used for specifying address. If symbol is used it should be enclosed by two '%' signs.

Example: - Hexadecimal 100

 Symbol %START%

Here, 'START' is a symbol, it is CASE SENSITIVE.

2) Specifying valid address range:-

There are two formats for this:

(A) Range is declared by starting address and ending address.

Example: 100 10f

(B) Range is declared by starting address and the length (denoted by L) of the range.

Example: 100 L 10

Note that 100 is in Hexadecimal and 10 is also in Hexadecimal.

3) DUMP command (D):-

This command displays the contents of a range of memory addresses.

Syntax: D [range]

Example: d 100 10f

 d 100 L 20

4) Compare command (C):-

This command compares two portions of memory.

Syntax: C [range address]

If the 'range' and 'address' memory areas are identical, ICE displays nothing.

If there are difference, ICE displays them in the following format.

Syntax:- address1 byte1 byte2 address2

Example:- C 100 10f 300

Here 300 is a starting address of range of some area in memory.

5) Search (S) command:-

This command searches a range of address for a pattern of one or more byte values.

Syntax: S [range (list)]

Here 'List' specifies the pattern of one or more byte values or a string one wants to search for. Enclose string values in quotation marks.

If the list parameters contains more then one byte value ICE displays only the first address where the value occurs. If list contains only one byte value ICE displays all address where the value occurs in the specified range.

Example:- S 100 110 41

S 100 1A0 "ph"

6) Edit (E) command:-

This command helps to edit data into memory at the address specified by the user.

Syntax: E [address] [List]

List specifies the data user wants to enter into successive bytes of memory.

One can do following with this command.

(A) Replace the byte:- Type new value at the current value.

(B) Advance to the next byte:- Press SPACE BAR.

(C) Return to the preceding byte:- Press the HYPHEN Key.

(D) Stop E command:- Press ENTER key.

Example:- E 100

This will display like,

100 FB. __

One can type new value at ___ or to next location by pressing SPACE BAR or END the EDIT command by pressing ENTER KEY if he is satisfied with the content of location 100.

7) Fill (F) command:-

This command fills specified memory area with specified values (DATA).

Syntax:- F [range (list)]

List specifies the data user wants to enter.

Example:- F 100 L 100 42 45 52 54 41

Here, ICE fills memory location 100 through 1FF with value specified. ICE repeats the five values until all the 100H bytes are filled.

8) Move (M) command:-

Copies the contents of a block of memory to another block of memory.

Syntax:- M range address

Here “address” is starting address of the destination.

Example:- M 100 110 500

9) Memory Map (MM) command:-

Maps the 8085 processor’s memory to onboard RAM (i.e. Emulator’s memory) or target memory.

Syntax:- MM [range [E [W] | T]

Here E = Map to Emulator memory, i.e. onboard

W = write protect the emulation memory

T = Map to target memory.

Example:- MM 0, FFF, E, W

In this command ICE will map to locations 0 to FFF in emulator’s memory in write protected mode.

10) Memory Test (MT) command:-

This commands tests a block of memory.

Syntax:- MT [range]

If any of the memory location in range is bad or does not exist ICE displays an error request “Memory verification failure @ XXXX”, and stops memory testing.

Example:- MT 0, FF

INPUT / OUTPUT COMMANDS

1) Input port (I) command:-

This command is useful to read the contents of specified port.

Syntax:- I [port] [count]

Here port means port address. 'Count' specifies the numbers of times the port is to be read.

Example:- I F8

In the example count is not specified.

2) Output port (O) command:-

This command sends a value of a byte to an output port.

Syntax:- O [port [byte value]]

Here, 'port' specifies the output port address. "bytevalue" is data byte to be directed to the 'port'.

Example:- O 2F 4F

REGISTER RELATED COMMANDS

1) Register (R) command:-

Displays or alters the contents of one or more CPU registers.

Syntax:- R [Register name [value]]

'Value' specifies the register value to store valid register names A, B, C, D, E, H, L, SP, PC and F.

Example:- R B 40.

F (Flag register) will display flag bit status as follows

<u>Flag name</u>	<u>Set</u>	<u>Clear</u>
Sign	NG (Negative)	Pl (positive)
Zero	ZR	NZ
Auxiliary	AC	NA
Parity	PE (Even)	PO (Odd)
Carry	CY	NC

R command without any parameter will display contents of all registers and flags.

TARGET CONTROL COMMANDS

1) Enable / Disable target signals commands:-

Using this command target control signals can be enabled or disabled individually or as a whole.

Interrupts, Reset, Hold, Clock and Ready signals can be controlled.

For individual control following are the commands.

Enable/Disable Target Reset	ER/DR
Enable/Disable Target TRAP	ET/DT
Enable/Disable Target RST 7.5	ER7/DR7
Enable/Disable Target RST 6.5	ER6/DR6
Enable/Disable Target RST 5.5	ER5/DR5
Enable/Disable Target INTR	EI/DI
Enable/Disable Target HOLD	EH/DH
Enable/Disable Target CLOCK	ETC/DTC
Enable/Disable Target ICE CLOCK	EIC/DIC

To control all signal using one command, EX and DX are used for enabling and disabling, respectively.

2) Display Enable / Disable target signals:-

(A) EL (Lists the enabled target signals)

(B) DL (Lists the disabled target signals)

COMMAND TO CONFIGURE ICE IN PC

BASE ADDRESS (BA) command:-

This specifies the base address for the ICE at which the user wants to configure the ICE.

Syntax:- BA <address>

ASSEMBLER RELATED COMMANDS

1) Assemble (A) command:-

This command creates executable machine code from assembly language statements. All numeric values are in hexadecimal format.

Syntax:- a [address]

Here, “address” specifies the location where user will type assembly-language mnemonics. Don’t put ‘H’ after hexadecimal values. DB, DW and ORG pseudo instructions are supported.

2) Unassembled (U) command:-

Disassembles bytes and displays their corresponding source statements, including addresses and byte values. The disassembled code looks like a listing for an assembled file.

Syntax:- U [range]

Example:- U 100 10

COMMANDS TO MANAGE BREAK POINTS

By setting breakpoints, the ICE is controlled in execution of programs. A breakpoint is an address that stops program execution each time the address is encountered. By setting breakpoints at key addresses in the program one can examine the status of memory or bus at that point.

The commands listed below control the break points.

<u>Commands</u>	<u>Action</u>
Breakpoint set (BS)	Sets one or more breakpoint(s)
Breakpoint clear (BC)	Clears one or more breakpoint(s)
Breakpoint disable (BD)	Disables breakpoints
Breakpoint enable (BE)	Enables breakpoints
Breakpoint List (BL)	Lists all breakpoints

PROGRAM EXECUTION CONTROL COMMANDS

In this category cycle step (CS), go (G), Single step (T), proceed (P) command are included.

1) Cycle step (CS) command:-

This command executes a program in steps of execution cycle. It stops processor while executing each machine cycle.

Syntax:- CS <address>

Here, ‘address’ specifies the address of the memory area from where the execution has to begin.

Example:- CS 100

It exhibits the status of the processor in terms of execution cycle for each byte of program as follows

<u>Address</u>	<u>Data</u>	<u>Status</u>	<u>Ext. trace bits</u>
100	3E	OF	1111
101	90	MR	1111
102	32	OF	1111
.	.	.	.
.	.	.	.
.	.	.	.

2) Single step (T) command:-

This command executes one instruction of a program at a time and displays the contents of all registers, the status of all flags, and the decoded form of the instruction to be executed.

Syntax:- T [= address] [numbers]

Here, 'address' specifies the address at which ICE is to start executing instructions, 'number' specifies the number of instructions to be executed. This must be hexadecimal number. The default value is 1.

Example:- T=100 10

3) Proceed (P) command:-

It executes one instruction at a time and steps over a subroutine.

Syntax:- P [address]

'address' specifies the address from where the execution has to begin.

Example:- P 100

4) Go (G) command:-

Runs the program currently in memory.

Syntax:- G [=address] [Breakpoint1,, Breakpoint10]

'Address' specifies the address in the program currently in memory at which user wants execution to begin.

TRACE COMMAND

1) Forward Trace (FT) command:-

Starts tracing the processor's status from the specified trigger address. It traces up to 2K machine cycle along with the external trace bits.

Syntax:- FT <address>

'Address' specifies the trigger address of the processor's memory from which the ICE begins recording instruction.

Example:- FT 100

2) Backward Trace (BT) command:-

Stops recording the processor's status at the specified trigger address. It traces upto 2k machine cycles along with the external trace bits.

Syntax:- BT <address>

'address' specifies the trigger address of the processor's memory at which the ICE has to stop recording the information.

Example:- BT 100

LIST COMMAND

1) List (L) command:- Lists the contents of the trace buffer.

Syntax:- L <address 1> <address 2>

'Address 1' specifies the starting address from where the listing of the trace buffer contents here to start.

'Address 2' specifies the ending address of the list.

L command is used along with BT or FT commands.

2) LZ command:- This command lists the content of the buffer along with the disassembled program instruction.

RESET COMMAND

Resets the emulation processor.

Syntax:- X [address]

'Address' specifies the address to which the processor's PC has to be changed. If address is not specified PC will be set to 0000.

PCICE SYSTEM CONTROL COMMAND

This includes Help, Quit, Shell escape, and redirection, comment, do etc commands. In addition to this upload and download commands are available.

Generally in testing a target, its memory and I/O sections are considered. Let us consider both for the target kit.

1) Testing memory:-

We learn from the memory map of target that locations 0000H to 3FFFH and 8000H to FFFFH are available as EPROM and RAM location respectively.

To test target memory we have to "MAP" its memory. For this "MM" command of ICE is to be used,

The format of MM (Memory map) command is:

MM [range] E [W | T]

Here “range” indicates starting address and ending address of memory to be mapped. Range can also be declared by indicating starting address and length of memory.

E = Map to emulation memory, i.e. On board

W= Write protect the emulation memory (i.e. memory of ICE tool)

T = Map to Target memory.

In the format [W|T] indicate either W or T.

Assume that we want to test whole address space of target system, i.e. 0000H to FFFFH, then command will be,

MM 0000 FFFF T

We have dropped E and W because we do not want emulation memory.

We will also use all resources of target. Hence, we should also enable all control signals and clock of target. For this “EX” command is available. EX enables following control signals of the target.

RESET, TRAP, RST 7.5, RST 6.5, RST 5.5, INTR, HOLD, READY, CLOCK.

Note, that individual control signal from the above list can also be enabled with different commands.

Also commands make target system to work on its own. (no help from emulation system).

EPROM TESTING:-

Suppose, now we want to check the contents of first 10 memory location of EPROM of target. Then perform following command.

D [range]

This becomes,

D 0000 L 10 or D 0000 000A

You can see the commands on the screen. Figure 11.1 shows this interaction.




FIGURE 11.1: EPROM LOCATION TESTING ON TARGET

RAM CHECKING:-

To check the proper working of RAM chip perform following commands.

> D 8000 L 10

If there is any problem with the EPROM of the target the ICE would respond with following message.

Similarly ICE would respond to RAM.

Thus, one can test the proper working of the target system. If one knows the exact contents of EPROM of target one can compare it with ICE memory checking.

2) Testing I/O:-

One can check desired I/O chip of target by obtaining their proper port address. From Table-2 we learn that in present target we have 8255, 8259, 8279, 8253 and 8251 as I/O interfacing chips.

We will understand I/O testing by considering 8255 at U35 in target system. For this chip the port address are as following:

Port A	40H
Port B	41H
Port C	42H
Control register	43H

We will develop a small assembly language program and run it through ICE to test the proper working of 8255 at U35 position in the target.

In the said program we configure all ports of 8255 as output ports and output on all port pins 0s or 1s alternately to produce a square wave at each pin. After executing the program through ICE one can check using oscilloscope the square wave on each port pin.

To develop the program follow the following steps:

1. Open the Ms-Dos editor.
2. Type the following program

```
MVI A, 80H
OUT 43H
START: MVI A, 00H
      OUT 40H
      OUT 41H
      OUT 42H
      MVI A, FFH
      OUT 40H
      OUT 41H
      OUT 42H
      JMP START
```

3. Save this program with the file name **8255_SW.ASM**.
4. Now to assemble the machine codes of this program, use 8085 assembler. For this, you must have stored “8085 Micro Assembler” in your computer. For this assembler type the following command.

C:\PCICE\X8085\X8085.EXE

Note that we have stored X8085.EXE in the directory named X8085, as per above path. This will present following display.

8085 Macro Assembler - Version- 4.01A
copyright (C) 1985 by 2500 A.D. Software, Inc.

Listing Destination (N, T, D, E, L, P) <CR> = N):

The “Listing Destination” asks to indicate the choice where the assembled codes can be listed. Here,

N = No Output

T = Terminal Output

D = Disk Output

E = Error only Output

L = List on / off listing

P = Printer Output

If one selects N, the assembler will assemble the codes but it will not show listing anywhere. The selection of T would display assembled codes and program instruction on the monitor screen.

The D will ask for need to generate cross references. It will not show listing on the screen, but *.OBJ file will be created. The selection of E will indicate the errors which may take place during assembly. L will provide options like, T, D, and P where user wants to listing. P will print the codes.

We select D. On hitting enter key the following line is displayed

Generate cross reference? (Y/N <cr> = N):

We go for Y.

On selecting 'Y' the following line is displayed

Input Filename:

Provide proper pathname for the file **8255_SW.ASM**, and press enter. This will ask following

Output Filename:

We simply press enter.

This will display following

Active commands

Ctrl S = Stop Output

Ctrl Q = Start Output

Esc C = Stop Assembly

Esc T = Terminal Output

Esc P = Printer Output

Esc D = Disk Output

Esc M = multiple Output

Esc N = No Output

'2500 A.D. 8085 Macro Assembler - Version 4. 01A

Input filename: C:\PCICE\8255_SW.ASM

Output filename: C:\PCICE\8255_SW.OBJ

Lines assembled: 12

Assembly Error :0

C:\PCICE\X8085>

One can check the listing of the assembled code by typing,

EDIT 8255_SW.LST

At this stage we have assembled the codes of testing program in the filename 8255_SW.OBJ. After assembling code we have to use linker to link the file

For that type following command

C:\PCICE\X8085\link (cr)

Following is the dialog for the linker.

2500 A.D. Linker copyright (C) 1985 - version 4.01A

Input Filename: [Enter here proper filename e.g. C:\PCICE\8255_sw.OBJ] <cr>

Enter offset for 'code': [Enter address 8000 here] <cr>

Input Filename: [This asks another filename to be linked if so. In our case only one file is required, so press enter] <cr>

Output Filename: <cr>

Library Filename: <cr>

Options (D, S, A, M, X, H, E, T, 1, 2, 3, <cr> = default): <cr>

Following is the display

```
*****
*                                LOAD MAP                                *
*****
* SECTION NAME  STARTING ADDRESS  ENDING ADDRESS  SIZE  *
*****
* C:\PCICE\8255_SW.OBJ                                *
*   Code   8000                                8019   001A *
*****
```

Link Error: 0

Output Format: Intel Hex

Thus, linker convert 8255_SW.OBJ file into 8255_SW.HEX file.

Now run PCICE

Go for the following dialog

> **MM 0000 FFFF T**

> **EX <cr>**

> **ctrl + D**

This will open a check box as follows. Interact with it as shown below.

DOWNLOAD

DOWNLOAD FILE [.HEX] : C:\PCICE\8255_sw.HEX
STARTING ADDRESS : <cr> (this will take address
itself)
END ADDRESS : <cr>
LOAD OFFSET ADDRESS : 0000 <cr>

This will run the program on target. Now one can check waveform on oscilloscope on every pin of 8255 ports.



CHAPTER 12

ADVANCE EXPERIMENTS ON PSICE



12.1 **INTRODUCTION: -**

The designing of the circuit and its implementation to check whether the designed circuit works properly or not can have two approaches, first built the design circuitry on the PCB and test it by giving proper inputs and observing proper output. This is a conventional approach where the satisfactory working of the design demands for extreme care. The hardware created once needs to be made again if something goes wrong. It is a general observation in the field that no hardware designed first time would work with a first attempt. Hence, this first approach takes enough time and becomes costly.

In the second approach, circuit performance is not checked by physically building the circuit. Instead the performance is checked through software called **simulation**. The advantages of simulating a circuit design are those which permit:

- 1) Evolution of the effects of variations in elements, such as resistors, transistors, transformers, and so on
- 2) The assessment of performance improvements or degradations
- 3) Evolution of the effects of noise and signal distortion without the need of expensive measuring instruments
- 4) Sensitivity analysis to determine the permissible bounds due to tolerances on each and every value or parameter of active elements
- 5) Fourier analysis without expensive wave analyzers
- 6) Evaluation of the effects of nonlinear elements on the circuit performance
- 7) Optimization of the design of electronic circuits in terms of circuit parameters.

One of the widely used simulation software is PSPICE. Let us discuss about PSPICE briefly.

○ **What is Pspice?**

Spice means Simulation Program with Integrated Circuit Emphasis. It is a simulation program that models the behavior of circuit. By using OrCAD capture you can think as software based breadboard of our circuit that you can use to test and refine your design before putting all the components on your breadboard, general purpose PCB or prototypes PCBs.

Pspice can perform DC, AC and transient analysis that can be tested for different inputs. It also analyses parametric, Monte Carlo, and sensitivity or worst case analyses, which describes the circuit behavior for various changes in components

values. Here, AC, DC and transient analysis are basic analysis of a circuit while parametric, Monte Carlo, and sensitivity or worst case analyses are advance analysis of the circuit. With limitation to our discussion we will discuss only AC, DC and transient analysis.

- **DC Analysis:-** DC analysis of the circuit performs in response to a direct current source. DC analysis calculates DC sweep, Bias point, DC sensitivity and small-signal DC transfer. While, using DC analysis PSpice computes steady state voltage and current sweeping a sources model parameter, and temperature effects on different values of DC sweep. Other three points of analysis depend on automatically generated bias point data in which DC sensitivity and small-signal DC transfer (small signals DC gain, Input-Output resistances) are function of bias points.
- **AC Analysis:-** AC analysis of the circuit performs in response to a small-signal alternative current source. AC analysis can be divided into two parts. First is AC sweep and second is NOISE. You can say AC analysis analyses AC sweep with output noise. Here, AC sweep computes small-signal response of the circuit sweeping to one or more source over a range of frequencies. It also includes voltage and current with their magnitude and phase. To get a noise analysis we must run AC sweep analysis of a circuit. It computes propagated noise contribution at output net from every noise generated circuits, RMS sum of those contributors and equivalent input noise.
- **Transient Analysis:-** These analysis are time-based, which are performed in response to time varying sources. It calculates all node voltages and branch currents over a time interval and their instantaneous values are the output of such analysis.

- **How to use Pspice program?**

In Pspice we have two methods to simulate our circuit. First method is to draw circuit in OrCad capture and second method to write text file in Pspice software. We will discuss both by means of drawing the circuit and by writing text file for our circuit in different examples.

In first method we need more understanding and associate other program and files which are generated during simulation. While in second method we have to just write the text for our circuit and set profile to get simulated output. This file is stored

as a *.CIR which will be discussed later. In this section we will discuss about OrCad capture.

OrCad capture is a design entry program. In this you have to prepare your circuit for simulation which means placing and connecting part symbols, input waveforms, enabling analyses points in circuit where result should be obtained. In capture we need stimulus waveform and model definitions for Pspice for use during simulation. These files are generated at stimulus editor and model editor.

- **Stimulus editor:-** It is a graphical input waveform editor that lets you define the shape of time based signals which are used during circuit simulation. By using stimulus editor you can generate different types of waves such like sine wave, pulses, piecewise linear, exponential pulses, single-frequency FM shapes. Figure 12.1 shows sine wave of 1 KHz frequency with 10V amplitude.




FIGURE 12.1 STIMULUS EDITOR

- **Model editor:-** As we know it is model definition generator for PSpice to use during simulation. This can be generated by standard data sheet of a particular device. This will display device characteristic curves so you can verify the

behavior of the device. As you finish editing of you part it will automatically create part which can be directly used as a part in design. Figure 12.2 shows how to create model in model editor.




FIGURE 12.2 MODEL EDITOR

○ **Simulation profile configuration:-**

To configure simulation profile we need model files, stimulus files and include files before starting simulation. Model file and stimulus file can be edited in model editor and stimulus editor. User can enter data for user defined model in notepad or such like text editor and can be used.

- **Model file:-** Model file are nothing but a model library. This file contains electrical definitions of a part provided by part manufacturer or datasheet of the part. In simulation this file used as an information of a part to determine how a part will respond to different inputs at different time.

These definitions contain model parameters and sub-circuit netlist. Model parameter and sub-circuit netlist are generally available in part datasheet. Pspice has many in-built parts (models). Model parameter defines the behavior of a part and sub-circuit netlist defines the structure and function

of a part during use in circuit. These model libraries are stored in library directory of OrCad with *.LIB extension. User can enter own part as described above.

- **Important files for simulation:-** To simulate the circuit Pspice should know which parts are used and how they are connected in your circuit. What type of analysis to be used, which part model and which type stimulus definitions are to be used in circuit? This can be obtained by various data files (datasheets). Few are generated by capture while other can be obtained by in-built library and some which are not available can be created by user.
- **File generation during capture simulation:-** When simulation starts, capture generates netlist and circuit file. These files are most important in simulation process before analysis or anything else it do.
 1. **Netlist:** - This file contains device name, device values and connection between two devices. Capture generates *.NET file name.
 2. **Circuit file:-** This file contains commands and describes what type of simulation should run. It is also refers to other files which contains netlist, model, stimulus and user defined information which apply to simulation. Capture generates *.CIR file name for this file.
- **Simulation profile configuration:-** To configure simulation profile we need model files, stimulus files and include files before starting simulation. Model files and stimulus files can be edited in model editor and stimulus editor. User can enter data for user defined model in NOTEPAD or such like text editor can be used.
 - ✓ **Model files:-** Model files are nothing but a model library. These files contain electrical definitions of a part provided by part manufacturer or datasheet of the part. In simulation this file is used as an information of a part which will respond to different input.

These definitions are containing model parameter and sub circuit netlist. Model parameter and sub circuit netlist are generally available in datasheet. PSPICE have many in-built parts (model). Model parameter defines the behavior of a part

and subcircuit netlist defines the structure and function of a part during use in circuit. This model library are stored in LIBRARY directory by OrCAD with *.LIB extensions. User can enter his own part as described above.

- ✓ **Stimulus files:-** A stimulus file contains time-based definitions for analog input stimuli. This file can be created manually using model text view of the model editor which are normally saved as *.STM or it may be generated using stimulus editor with *.STL file name. Figure 12.3 shows implementation of *.STL in simulation profile.




FIGURE 12.3 IMPLEMENTATION OF STIMULUS FILE

- ✓ **Include files:-** It is user defined file which contains PSPICE commands and text comment which appear in the PSPICE output file. OrCad supply include file for standard simulation. Figure 12.4 shows where to implement this in simulation profile. This include file you can modify using windows standard text editor such like NOTEPAD or you can generate your own include file by saving *.INC and add to simulation profile.




FIGURE 12.4 IMPLEMENTATION OF *.INC FILE

- **Configuring model library, stimulus and include files:-** Pspice normally needs model library stimulus and include files to complete the definition of a part and run simulation. These files depend on configuration of your model libraries and other associated files. Most of these are automatically configuration setup but you can change as per your design. You can configure by adding or deleting files from this automatically generated configuration. Also you can apply these file as a local means for your circuit or as global means for any circuit which are to be simulated.

The whole configuration we had discussed could be figured as following figure 12.5.




FIGURE 12.5 CONFIGURATION PSPICE

Here, in model editor we created model or used in-built model and configured as a global or local model which are used in our circuit. Every stimuli we have used as an input we need to give input waveforms which are generated at stimulus editor and this generated stimulus are stored in stimulus file with *.STL extension. Also user defined or standard included file which are stored as *.INC should be added to this configuration.

- **Stimulation output file:-** until now we had discussed about circuit design, part model, simulation configuration and some associated files which we need for simulation. After simulation Pspice generates output file. They are either in the form of waveform or text file. These file are known as waveform data file and output file.
- **Waveform data file:-** Waveform data file displays graphically output of simulation. Pspice reads circuits file, netlist file, model library and inputs of the circuit automatically and displays circuit analysis waveform at different net, pins of components and parts which are cross-probed. This can be set simulation progresses or as simulation computes.

In output waveform data file you can add more waveform by add trace or by add cross-probes in circuit file.

- **Output file:-** The output file is ASCII text file. Output file contains netlist of prepared circuit, commands, simulation results, messages for warning and error in prepared in OrCad capture or in text file.

Until now we had discussed files, inputs and outputs and other configuration which are associated with circuit which we had prepared in OrCad capture.

Now we will discuss about text simulation. In this we need to understand some command for input and output. We also need to understand how we can configure AC, DC and transient analysis in text file.

- **Simulation through Text file:-** Doing simulation from text file we have to make part for AC, DC and transient analysis command. Here, we discuss AC analysis, DC analysis and transient analysis one by one. After understanding of these commands we will discuss one example for each.

- **AC commands:-**

- **AC sources:-** In a AC circuit analysis we have two different statements for current and voltage. The statements for there sources in general form are as follow

V<NAME> N+ N- [AC <(magnitude) value> <(phase) value>]

I<NAME> N+ N- [AC <(magnitude) value> <(phase) value>]

Here, <NAME> means voltage or current source stimuli name. N+ and N- is node where source connected. The <(magnitude) value> is the peak value of sinusoidal voltage and <(phase) value> is in degree.

Example:-

VOLTAGE STATEMENT

VAC 1 2 AC 02V 2 volt AC input between node 1 and 2 without phase change

VACP 1 2 AC 2V 90DEG 2 V AC input between node 1 and 2 with 90° phase angle

CURRENT STATEMENT

IAC 3 4 AC 5 A 5 AMP

IAC 3 4 AC 9 A 60 DEG

AC out put variable: - AC analysis output variable are sinusoidal quantities and can be represented as complex numbers. An output variable can have magnitude,

phase group delay, real and imaginary part. The common suffix parts of output variable are listed below.

Suffix	Meaning
(none)	Peak magnitude
M	Peak magnitude
DB	Peak magnitude in decibels
P	Phase in radian
G	Group delay
R	Real part
I	Imaginary part

Voltage output:-

Below listed common statements are useful in voltage output.

V(<NODE>)	Voltage at <node> with respect to ground.
V (N _X , N _Y)	Voltage at node X with respect to node Y.
V (<NAME>)	Voltage across two terminal devices <name>
V _X (<NAME>)	Voltage at terminal X of three-terminal device, <name>
V _{XY} (<NAME>)	Voltage across terminal X and Y of three terminal device, <name>
V _Z (<NAME>)	Voltage at part Z of transmission line, <name>

Using above common statements and suffix we can understand some particular statements.

VM(6)	Magnitude at voltage at node 6 with respect to ground
VM(8,12)	Magnitude at voltage at node 8 with respect to node 12
VDB(R1)	Db magnitude of voltage across resistor R1 where terminal X is assumed more positive then Y as shown in below figure.
VP(D1)	Phase of anode voltage of diode D1 with respect to cathode.
VCM(Q4)	Magnitude of collector voltage of terminal Q4 with respect to ground.
VDSP(M6)	Phase of drain-source voltage of MOSFET M6
VBP(T1)	Phase of voltage at port B of transmission line T1
VR(2,3)	Real part of voltage at node 2 with respect to node 3
VI(2,3)	Imaginary part of voltage at node 2 with respect to node 3.

Current output:-

In AC current output can be analyzed by following. The common statements for that are as follow.

I(<NAME>)	Current through <NAME>
IX(<NAME>)	current into terminal X of <NAME>
IZ(<NAME>)	Current at port Z of transmission line<NAME>

Example:-

IM(RX)	Magnitude of current through resistor RX.
IR(RX)	Magnitude of current through real part resistor RX.
II(RX)	Imaginary part of current through resistor RX.
IM(VIN)	magnitude of current through source VIN
IR(VIN) / II(VIN)	real or imaginary part of current
IAG(T1)	Group delay of current at port A of transmission line T1

Here few things should be noted that current through listed elements could be analyzed without changing in circuit for other element. We should put zero-valued voltage source in series with the device.

Element	Letter
Capacitor	C
Independent current source	I
Inductor	L
Resistor	R
Transmission line	L
Independent voltage source	V

Here, we should not forget that while doing AC analysis sometimes we need to perform frequency response. That can be obtained by three different sweeps. They are Linear sweep (LIN), Octave sweep (OCT), and decade sweep (DEC).

The common statements for all above sweep are

```
.AC LIN NP Fstart Fstop
.AC OCT NP Fstart Fstop
.AC DEC NP Fstart Fstop
```

Here .AC is a type of ac analysis command. LIN, OCT, DEC are type of sweeps. NP is number of points in a frequency sweep. Fstart is start frequency and

Fstop is a stop frequency. While, using LIN, OCT, DEC only one sweep can be possible in a statement. The uses of this sweep are as follows.

LINEAR SWEEP (LIN):- In linear sweep; sweep increases linearly from starting to ending frequency. NP becomes the total no. of points in the sweep. This type of analysis is used in narrow range of frequency.

OCTAVE SWEEP (OCT):- In octave sweep; the analysis of the frequency is swept logarithmically by octave and NP is number of points per octave. The sweep is used in wide range of frequency.

DECADE SWEEP (DEC):- It is same as octave but swept in decade. NP is number of points per decade. This sweep is used in widest range of frequency.

EXAMPLE:-

```
.AC LIN 300 100 Hz 300Hz
.AC LIN 1 60Hz 120Hz
.AC OCT 10 100Hz 100KHz
.AC DEC NP 1KHz 10MEGHZ
```

After going through these statements we should note few things.

- 1) Fstart should be smaller than Fstop.
- 2) NP= 1 could be possible but it calculates the frequency at Fstart.
- 3) Pspice automatically calculates bias points for linearized circuit parameter around bias point for frequency response analysis.
- 4) In an AC circuit at least one source should have AC values otherwise Pspice analysis is not meaningful. For independent voltage and current source which have AC values are input in AC Pspice analysis.
- 5) G as a suffix is required for group delay output. In this, for output change to be smooth we should have small steps of frequency.

DC commands:-

DC source: - Dc source can be divided into two parts. They are independent DC sources and dependent DC sources.

Independent DC sources: - As we discussed in AC sources we have two sources voltage source and current source. Similarly, in DC we have two types of sources in

DC source i.e. independent DC voltage and dependent DC current sources. Figure 12.6 shows independent DC voltage and current source. They could be time variant or time in-variant.




FIGURE 12.6 INDEPENDENT DC VOLTAGES AND CURRENT SOURCE

Independent DC voltage source:- In general V is symbolic identification for independent voltage source. In general it can be written as

V<NAME> N+ N- [DC<NAME>]

Here, V<NAME> means DC voltage stimuli name. N+ and N- are positive and negative node. The flow of current is from N+ to N-. The source need not to be grounded.

In DC analysis DC source is set of DC voltage values. We can use as a AMMETER by zero value voltage source into circuit for current measurement. These sources behave like a short circuit. It will not effect on circuit operations.

EXAMPLE:-

V1	1	0	12V
V1	2	0	DC 12V

In first statement PSPICE automatically consider 12V DC voltage source between node 1 and 0. In second we have define DC voltage of 12V between node 2 and 0.

Independent DC current source: - In general I is symbolic identification for current source. In general it can be written as

I<NAME> N+ N- [DC<value>]

Here, I<name> is current source stimuli name. N+ and N- are as described in independent DC voltage source.

EXAMPLE:-

I1 1 0 3.5mA

I2 2 0 DC 3.5mA

Statements are similar to DC voltage source. For, current we have given values in Ampere.

Dependent Sources:-

These types of sources are again divided in four types of sources.

- Voltage-Controlled Voltage sources
- Voltage-Controlled Current sources
- Current-Controlled Voltage sources
- Current -Controlled Current sources

They could have either fixed value or a polynomial value.

Polynomial Sources:- The symbolic representation of this source is POLY(n) where n=1 is default. And it is number of dimensions of polynomial which depend on the number of controlling sources.

Poly (n) < (controlling) nodes> <coefficients values>

Here, the output source or the controlling sources can be voltages or currents. For, voltage controlled sources, the number of controlling nodes must be twice the number of dimensions, but for current controlled sources, it is equal to controlling nodes. These are arbitrary values.

Example: - Let us consider three controlling variables A, B and C with output Y source. Below Figure 12.7 shows a source that is controlled by A, B and C the output source takes the form of

$$Y = f(A, B, C, \dots)$$

Where Y can be voltage or current and A, B & C can be voltage or current or any combination.

Here, in Figure 12.7, NC+, NC-, N+ and N- are positive and negative nodes with respective controlling sources and output source.

Voltage-Controlled Voltage sources: - The symbolic representation of Voltage controlled voltages source is shown in figure 12.7 (a). Where, E is taken as a linear form.




FIGURE 12.7 DC DEPENDENT SOURCES

The common statement for linear form of voltage controlled voltage source is as follow:

E <name> N+ N- NC+ NC- <(voltage gain) value>

Where, N+, N-, NC+ and NC- are positive and negative nodes of the respective controlling voltage.

Similarly, for nonlinear form the common statement can be as follow

E <name> N+ N- [POLY (<value>)]

+ <<(+ controlling) node> <(- controlling) node>> (pairs)

+ <(polynomial coefficients) values>]

The POLY source was described as above. The number of controlled node is twice the number of dimensions. Output and controlling nodes could be the same for particular node which could be more then one.

Some typical statement for Voltage-Controlled Voltage sources

EAB 1 2 4 6 10

```

EVOLT      4 7 20 22 2E5
ENONLIN    25 40 POLY(2) 3 0 5 0 0.0 1.0 1.5 1.2 1.7
E2         10 12 POLY 5 0 0.0 1.0 1.5 1.2 1.7

```

Voltage-Controlled current source: -The symbolic representation of this source is shown in Figure 12.7 (b). The linear form is G.

G <name> N+ N- NC+ NC- <(transconductance) value>

Where, N+, N-, NC+ and NC- are positive and negative nodes of the respective controlling voltage.

G <name> N+ N- [POLY (<value>)

+ <<(+) controlling) node> <(- controlling) node>> (pairs)

+ <(polynomial coefficients) values>]

Some typical statement for Voltage-Controlled Voltage sources

```

GAB        1 2 4 6 10
GVOLT      4 7 20 22 2E5
GNONLIN    25 40 POLY(2) 3 0 5 0 0.0 1.0 1.5 1.2 1.7
G2         10 12 POLY 5 0 0.0 1.0 1.5 1.2 1.7

```

Current-Controlled current source: -The symbolic representation of this source is shown in Figure 12.7 (C). Its linear form is F. General statement for this is

F <name> N+ N- VN <(current gain) value>

Where, N+, N-, are positive and negative nodes of the respective current sources. VN is voltage source through which controlling current flows. The controlling current is assumed that it flows from positive node to negative node. Voltage source VN monitors the controlling current must be an independent voltage source which value could be **zero** or **infinite**. The nonlinear statement is shown below:

F <name> N+ N- [POLY (<value>)

+ VN1, VN2, VN3.....

+ <(polynomial coefficients) values>]

Current-Controlled voltage source: -The symbolic representation of this source is shown in figure 9 (D). Its linear form is H. General statement for this is

H <name> N+ N- VN <(transresistance) value>

Where, N+, N-, are positive and negative nodes of the respective voltage sources. VN is voltage source through which controlling current flows. The nonlinear statement is

H <name> N+ N- [POLY (<value>)
+ VN1, VN2, VN3.....
+ <(polynomial coefficients) values>]

Dc output Variables:- Pspice has some unique features for printing or plotting output voltage or current. The voltage output and current output is two divisions of the output variables. The variable can be assigned the symbol of a device to identify whether the output voltage or current is across the device or through the device. Few two and three terminal device with their symbols are listed below.

Device symbol	Element	Number of terminals
C	Capacitor	Two
D	Diode	Two
L	Inductor	Two
R	Resistor	Two
V	Independent voltage source	Two
B	MESFET	Three D(Drain) S(Source) G(Gate)
J	JFET	Three D(Drain) G(Gate) S(Source)
Q	BJT	Three C(Collector) B(Base) E(Emitter)

Voltage output: -The common statement is as same as discussed in AC command voltage output.

Current output: -The common statement is as same as discussed in AC command current output.

12.2 COMMANDS FOR PSPICE:-

The common commands for **AC** and **DC** analysis are as shown below: -

COMMAND	OUTPUT
.PRINT	Print
.PLOT	Plot
.PROBE	Probe
Probe	Output
.WIDTH	Width

- **.PRINT (Print statement):** - The results from AC/DC analysis can be obtained in the form of table. The print statement for DC/AC output takes the form

.PRINT AC/DC [output variables]

The maximum number of output variable is eight in any .print statement. But more than one .print command can be used to get more output. Variables are printed as a table with each column corresponding to one output variable. The result of this statement are stored in output file.

Example:-

.PRINT DC V(2), V(3,6), V(R5), VCE(Q6), I(VIN), I(R5), IC(Q6)

The number of output variable can be changed by the NUMDGT option on the .OPTIONS statement. (here we will not discuss this statement).

- **.PLOT (PLOT STATEMENT):** -The results from dc analysis can also be obtained in the form of line printer plots. The plots are drawn by using characters, and the results can be obtained from any kind of printer. The plot statement for dc outputs takes the following form:

.PLOT DC (output variables)

+ [(lower limit) value), (upper limit)]

This statement also having same constraints for output as print statement. It also permit 8 output variable for any plot statement. But it also allow more than one .PLOT statement.

Example:-

.PLOT DC V(2), V(3,5), V(R1), VCE(Q2), I(VIN), I(R1), IC(Q2)

.PLOT DC V(5) V(4,7) (0,10V) IB(Q1) (0,50MA) IC(Q1) (-50MA, 50MA)

Here, few things to be noted for 1st statement, the y-axis is by default. In the second, the range for voltage V(5) and V(4,7) is 0V to 10V, that for current IBQ(Q1) is 0 MA to 50 MA, and that for the current IC(Q1) is -50 MA to 50 MA.

- **.PROBE (PROBE STATEMENT):** - Probe is a graphics post-processor or wave form analyzer for Pspice. The simulation result cannot be used directly by Probe. First, the results have to be processed by the .PROBE command, which writes the processed data on a file, PROBE.DAT, for use by Probe. The command takes one of these forms

.PROBE

.PROBE (one or more output variables)

In the 1st statement where no output variable is specified, the .PROBE command writes all the node voltage and all the element currents into PROBE.DAT file. The element currents are written in the forms that are permitted as output variables.

In the 2nd statement, where the output variable is specified, Pspice writes only the specified output variable to the PROBE.DAT file. This form is suitable for users without a fixed disk to limit size of the PROBE.DAT file.

Example:-

.PROBE

.PROBE V (5), V(4,3), V(C1), V(C2), I(R2), IB(Q1), VBE(Q1)

- **.WIDTH (WIDTH STATEMENT):** -The width of the output in columns can be set by the .width statement, which has the general form of

.width out=<value>

The <value> is in columns and must be either 80 or 132. The default value is 80.

12.3 EXPERIMENTS:-

It is the demand of today's technology that one must be able to simulate the circuit design before actual commercial production in order to provide a fast and cost effective device.

For this it is very essential that all the learners should have at least basic knowledge of using simulation software. Considering this we have designed and performed some experiments which give the idea about the environment of Pspice.

The experiment developed consists of AC circuit, DC circuit and digital circuits. The same are discussed as follows.

12.3.1 ANALOG EXPERIMENTS:-

In these experiments the analog components are considered i.e. resistors, diodes, capacitors, BJT, FET, MOSFET, Op-Amp, etc... The circuits incorporating such component may be AC type or DC type to have the experience in the both the cases we have designed AC circuit and DC circuit both.

12.3.1.1 AC CIRCUITS:-

In AC circuits the representation of circuit parameters are slightly different i.e. voltage and current representation are different from DC. This is discussed in the introduction of this chapter. To understand better the AC circuits' analysis we have considered the following circuits.

EXAMPLE:-

- 1) **A Two-stage bipolar transistor amplifier is shown in Figure 12.8. The output is taken at node 9. Plot the magnitude and phase angle of the voltage gain, and the magnitude of input impedance for frequencies from 10Hz to 10MHz with a decade increment and 10 points per decade. The peak input voltage is 1 mV.**




FIGURE 12.8 TWO-STAGE BIPOLAR TRANSISTOR AMPLIFIER

Here we will simulate above circuit using text file. For this we will use OrCad Spice A/D package to write Pspice simulation text file.

Two-stage Bipolar transistor amplifier

VCC 10 0 DC 15V ; DC 15V common collector voltage

VIN 1 0 AC 1MV ; input AC 1mV peak for frequency response

VX 1 12 DC 0V

RS 12 2 150

```

C1 2 3 10UF
R1 10 3 200K
R2 3 0 50K
Q1 4 3 5 0 Q2N2222 ; transistor Q1 and Q2 have model name Q2N2222
Q2 7 6 8 0 Q2N2222
RC1 10 4 12K
RE1 5 0 3.6K
CE1 5 0 15UF
C2 4 6 10UF
R3 6 0 120K
R4 6 0 30K
RC2 10 7 6.8K
RE2 8 0 3.6K
CE2 8 0 25UF
C3 7 9 10UF
RL 9 0 10K
.model Q2N2222 NPN ; transistor model
.AC DEC 10 10HZ 10MEGHZ ; AC analysis
.PLOT AC VM (9) VP (9) ; AC plot
.PROBE
.END

```

OUTPUT WAVEFORMS: -




FIGURE 10.9 OUTPUT WAVEFORM OF TWO-STAGE BIPOLAR TRANSISTOR AMPLIFIER

SIMULATION OUTPUT FILE: -

SMALL SIGNAL BIAS SOLUTION TEMPERATURE = 27.000 DEG C

Node	Voltage	Node	Voltage	Node	Voltage	Node	Voltage
(1)	0.0000	(2)	0.0000	(3)	2.7779	(4)	8.3369
(5)	2.0189	(6)	360.0E-09	(7)	15.0000	(8)	54.00E-09
(9)	0.0000	(10)	15.0000	(12)	0.0000		

VOLTAGE SOURCE CURRENTS

NAME	CURRENT
VCC	-6.164E-04
VIN	0.000E+00
VX	0.000E+00

TOTAL POWER DISSIPATION 9.25E-03 WATTS

- 2) Design and simulate a Full wave phase controller circuit using OrCad Capture CIS. Plot output for 230V amplitude 50Hz frequency input signal.

For above circuit we have used OrCad Capture CIS to simulate Full wave Phase controller circuit. Below Figure 12.10 shows circuit diagram of full wave phase controller.




FIGURE 12.10 FULL WAVE PHASE CONTROLLER CIRCUIT

Solution: - In above circuit we have used THYRISTOR 2N2646, 2N3669, and Zener diode 1N4739 and input voltage is ac type and fixed frequency. We have considered a voltage source with a peak magnitude of 230V 50Hz frequency.

The input voltage is generated using Pspice Stimulus Editor. Figure 12.11 shows input voltage waveform.




FIGURE 12.11 INPUT WAVEFORM FOR FULL WAVE PHASE CONTROLLER

Now, configure OrCad Capture CIS simulation as discussed in introduction of this chapter. We have configured input waveform as shown in below Figure 12.12.





FIGURE 12.12 INPUT WAVEFORM ATTRIBUTES

The frequency response analysis is invoked by .TRAN command. The output as shown in Figure 12.13 is invoked by using .PROBE command. For NP = 10, FSTART = 0s, FSTOP = 50ms the statement is .TRAN 0 50ms 0.



**FIGURE 12.13 OUTPUT WAVEFORM OF FULL PHASE CONTROLLER
CIRCUIT**

The output circuit file will be generated as below.

Output circuit File: -

** circuit file for profile: Full wave phase controller

CIRCUIT DESCRIPTION

*Libraries:

* Local Libraries :

.STMLIB ".\stim230ac.stl"

* From [PSPICE NETLIST] section of pspice91.ini file:

.lib "nom.lib"

*Analysis directives:

.TRAN 0 50ms 0

.PROBE

.INC "full wave phase controller-SCHEMATIC1.net"

**** INCLUDING "full wave phase controller-SCHEMATIC1.net" ****

* source FULLWAVE PHASE CONTROLLER

D_D1 0 N00011 D1N4007

D_D2 N00011 N00027 D1N4007

D_D3 0 N00014 D1N4007

D_D4 N00014 N00027 D1N4007

V_V1 N00011 N00014 STIMULUS=V1

D_D5 0 N00273 D1N4739

R_R4 N00352 N00273 1.11MEG

X_X2 N00027 N00368 0 2N3669

C_C1 N00352 0 0.01u

X_X1 N00273 N00352 N00368 2N2646

R_R1 N00273 N00027 10k

R_R3 0 N00368 100ohm

**** RESUMING "full wave phase controller-schematic1-fullwave phase controller.sim.cir" ****

.INC "full wave phase controller-SCHEMATIC1.als"

**** INCLUDING "full wave phase controller-SCHEMATIC1.als" ****

.ALIASES

```

D_D1      D1(1=0 2=N00011 )
D_D2      D2(1=N00011 2=N00027 )
D_D3      D3(1=0 2=N00014 )
D_D4      D4(1=N00014 2=N00027 )
V_V1      V1(+=N00011 -=N00014 )
D_D5      D5(1=0 2=N00273 )
R_R4      R4(1=N00352 2=N00273 )
X_X2      X2(A=N00027 G=N00368 K=0 )
C_C1      C1(+=N00352 -=0 )
X_X1      X1(B2=N00273 E=N00352 B1=N00368 )
R_R1      R1(1=N00273 2=N00027 )
R_R3      R3(1=0 2=N00368 )

.ENDALIASES

**** RESUMING "full wave phase controller-schematic1-fullwave phase
controller.sim.cir" ****

.END

* C:\project\stim230ac.stl written on Wed Feb 23 17:07:01 2005
* by Stimulus Editor -- Serial Number: 0 -- Version 9.1
; !Stimulus Get
; ! V1 Analog
; !Ok
; !Plot Axis_Settings
; !Xrange 0s 60ms
; !Yrange -300 300
; !AutoUniverse
; !XminRes 1ns
; !YminRes 1n
; !Ok

.STIMULUS V1 SIN( 0 230V 50 0 0 0 )

** circuit file for profile: Full wave phase controller

**** Diode MODEL PARAMETERS
*****
D1N4007      D1N4739      D1N4001      X_X2.X1.Dgk
IS  14.110000E-09  2.110000E-15  14.110000E-09  100.000000E-18

```

```

N 1.984 1.984
ISR 2.012000E-09
IKF 94.81 94.81
BV 1.500000E+03 9.1 75
IBV 10.000000E-06 1.2 10.000000E-06
NBV .72056
IBVL .01
NBVL .21148
RS .03389 2.512 .03389 5
TT 5.700000E-06 5.700000E-06
CJO 25.890000E-12 89.000000E-12 25.890000E-12 50.000000E-12
VJ .3245 .75 .3245
M .44 .384 .44
TBV1 604.396000E-06

```

```

X_X2.X1.Dseries X_X2.X1.Delay X_X2.X1.Dkarev X_X2.X1.Dakfwd
IS 10.000000E-15 1.000000E-12 100.000000E-12 40.000000E-12
RS .01 .01
CJO 5.000000E-12 5.000000E-12 5.000000E-12

```

```

X_X2.X1.Dbreak X_X1.x1.x1.x1.x1.dio
IS 10.000000E-15 128.100000E-12
BV 220
IBV 100.000000E-09
RS .5 1
CJO 5.000000E-12

```

** circuit file for profile: Fullwave phase controller

**** Voltage Controlled Switch MODEL PARAMETERS

```

X_X2.X1.Vswitch
RON .016
ROFF 1.818182E+06
VON 5
VOFF 1.5

```

** circuit file for profile: Full wave phase controller

**** INITIAL TRANSIENT SOLUTION TEMPERATURE = 27.000 DEG C

NODE VOLTAGE NODE VOLTAGE NODE VOLTAGE NODE
VOLTAGE

(N00011)-865.5E-18 (N00014)-865.5E-18 (N00027)-1.738E-15 (N00273)-704.5E-18

(N00352)-562.3E-18 (N00368)-6.330E-18 (X_X2.X1.Itot) 0.0000

(X_X2.X1.prod) 0.0000 (X_X2.X1.dlay1) 4.841E-24

(X_X2.X1.dlay2)-68.45E-24 (X_X2.X1.dvdt0) 0.0000

(X_X2.X1.dvdt1) 0.0000 (X_X2.X1.dvdt2) 0.0000

(X_X2.X1.gate1)-4.115E-18 (X_X2.X1.gate2) 0.0000

(X_X2.X1.gate4) 0.0000 (X_X2.X1.anode0)-1.721E-15

(X_X2.X1.anode2) 0.0000 (X_X2.X1.break1)-1.585E-12

(X_X2.X1.contot) 0.0000 (X_X2.X1.condvdt) 0.0000

(X_X2.X1.congate) 0.0000 (X_X2.X1.conmain) 0.0000

(X_X2.X1.control) 33.51E-18 (X_X1.x1.x1.x1.x1.x)-469.8E-18

(X_X1.x1.x1.x1.x1.ca) 1.000E-09 (X_X1.x1.x1.x1.x1.cc)-92.49E-27

(X_X1.x1.x1.x1.x1.e1)-562.3E-18 (X_X1.x1.x1.x1.x1.x1)-469.8E-18

(X_X1.x1.x1.x1.x1.mon) 0.0000 (X_X1.x1.x1.x1.x1.r1a) 4307.2000

(X_X1.x1.x1.x1.x1.r1c)-107.6E-21 (X_X1.x1.x1.x1.x1.r2a) 2182.8000

(X_X1.x1.x1.x1.x1.r2c)-107.5E-21 (X_X1.x1.x1.x1.x1.vbb) 0.0000

(X_X1.x1.x1.x1.x1.mona)-128.0E-24 (X_X1.x1.x1.x1.x1.r1aa) 4307.2000

(X_X1.x1.x1.x1.x1.vmonl) 0.0000 (X_X1.x1.x1.x1.x1.xc1.6) 0.0000

(X_X1.x1.x1.x1.x1.xrb1.6)-6.330E-18 (X_X1.x1.x1.x1.x1.xrb2.6)-469.8E-18

VOLTAGE SOURCE CURRENTS

NAME	CURRENT
V_V1	3.155E-30
X_X2.X1.VIak	-2.663E-24
X_X2.X1.VdVdt	0.000E+00
X_X2.X1.VIgf	-4.431E-20
X_X1.x1.x1.x1.x1.vmon	-1.280E-22
X_X1.x1.x1.x1.x1.v0c	-9.249E-29
X_X1.x1.x1.x1.x1.xc1.vsense	0.000E+00
X_X1.x1.x1.x1.x1.xrb1.vsense	-1.076E-19
X_X1.x1.x1.x1.x1.xrb2.vsense	-1.075E-19

TOTAL POWER DISSIPATION 0.00E+00 WATTS

JOB CONCLUDED

TOTAL JOB TIME 1.36

On reading circuit file you can find few things. It is showing local and global libraries as we have used **.STMLIB ".\stim230ac.stl** as local library for stimulus and **.lib "nom.lib"** as a global library. Then you can see **“Analysis directives:”** for analysis type and output probing. In simulation circuit file you can see INCLUDE file, Diode, Voltage Controlled Switch MODEL PARAMETERS, NODE VOLTAGES and VOLTAGE SOURCE CURRENTS. At the end of simulation you can find total power dissipation and total job time taken by simulator, and output waveform as shown in Figure 12.12.

- 3) A filter circuit is shown in Figure 12.14. Plot the frequency response of the output voltage. The frequency is varied from 10Hz to 100MHz with an increment of 1 decade and 10 point per decade.




FIGURE 12.14 A FILTER CIRCUIT

TEXT FILE: -

```
VIN 1 0 AC 1
R1 1 2 20K
R2 2 4 20K
R3 3 0 10K
R4 1 5 10K
R5 4 5 10K
R6 6 7 100K
RL 7 0 100K
C1 2 4 0.01UF
XA1 2 3 4 0 OPAMP
XA2 5 6 7 0 OPAMP
.SUBCKT OPAMP 1 2 7 4
RI 1 2 2.0E6
GB 4 3 1 2 0.1M
R2 3 4 10K
C2 3 4 15619UF
EA 4 5 3 4 2E+5
R0 5 7 75
```

```

.ENDS OPAMP
.AC DEC 10 10HZ 100KHZ
.PLOT AC VM(7) VP(7)
.PROBE
.END

```

OUTPUT WAVEFORM: -




FIGURE 12.15 FREQUENCY RESPONSE FOR ACTIVE BAND-PASS FILTER

12.3.1.2 DC CIRCUITS:-

Following the nomenclature discussed in the introduction part of this chapter, we have tested following DC circuits.

EXAMPLE:-

- 1) **Bipolar transistor circuit is shown in Figure 12.16, where the output is taken from node 4. Calculate and print the sensitivity of the collector current with respect to all parameter. Print the details of bias point.**




FIGURE 12.16 BIASING SENSITIVITY OF BIPOLAR TRANSISTOR AMPLIFIER

Here we will simulate above circuit using text file. For this we will use OrCad Spice A/D package to write Pspice simulation text file.

BIASING SENSITIVITY OF BIPOLAR TRANSISTOR AMPLIFIER

VCC 7 0 DC 15V

VRC 6 4 DC 0V

R1 7 3 47K

R2 3 0 2K

RC 7 6 10K

RE 5 0 2K

XQ1 4 3 5 QMOD

.SUBCKT QMOD 6 7 5

RB 1 2 100

RE 3 5 1

RC 4 6 10

RBE 2 3 1K

RO 4 3 100K

VI 7 1 DC 0V

F1 4 3 VI 20

.ENDS QMOD

.SENS I(VRC)

.END

The .SENS command does not required .PRINT command for printing the output. The output for sensitivity analysis and the bias point follow.

SMALL SIGNAL BIAS SOLUTION TEMPERATURE = 27.000 DEG C

Node	Voltage	Node	Voltage	Node	Voltage	Node	Voltage
(3)	.5960	(4)	12.1520	(5)	.5864	(6)	12.1520
(7)	15.0000 (XQ1.1)	.5960	(XQ1.2)	.5952	(XQ1.3)	.5867	
(XQ1.4)	12.1500						

VOLTAGE SOURCE CURRENTS

NAME	CURRENT
VCC	-5.912E-04
VRC	2.848E-04
XQ1.VI	8.456E-06

TOTAL POWER DISSIPATION 8.87E-03 WATTS

DC SENSITIVITY ANALYSIS TEMPERATURE = 27.000 DEG C

DC SENSITIVITIES OF OUTPUT I(VRC)

ELEMENT NAME	ELEMENT VALUE	ELEMENT SENSITIVITY (AMPS/UNIT)	NORMALIZED SENSITIVITY (AMPS/PERCENT)
R1	4.700E+04	-5.481E-09	-2.576E-06
R2	2.000E+03	1.252E-07	2.505E-06
RC	1.000E+04	-3.134E-10	-3.134E-08
RE	2.000E+03	-1.288E-07	-2.576E-06
XQ1.RB	1.000E+02	-3.705E-09	-3.705E-09
XQ1.RE	1.000E+00	-1.288E-07	-1.288E-09
XQ1.RC	1.000E+01	-3.134E-10	-3.134E-11
XQ1.RBE	1.000E+03	-3.705E-09	-3.705E-08
XQ1.RO	1.000E+05	-1.273E-10	-1.273E-07
VCC	1.500E+01	1.898E-05	2.848E-06
VRC	0.000E+00	-1.101E-06	0.000E+00
XQ1.VI	0.000E+00	-4.381E-04	0.000E+00

JOB CONCLUDED

TOTAL JOB TIME .02

- 2) A Zener voltage regulator is shown in figure 12.17. Plot the dc transfer characteristic if the input voltage is varied from -15V to 15V with an increment 0.5V. The Zener voltage of the diodes are the same, and $V_z = 5.2$ V; the current at the Zener breakdown is $I_z = 0.5$ μ A. The model parameter are $I_S = 0.5$ UA, $R_S = 1$, $BV = 5.20$, and $IBV = 0.5$ UA. The operating temperature is 50°C. V_{in} has a normal voltage of 10V (dc). The details of the operating point are to be printed.




FIGURE 12.17 ZENER VOLTAGE REGULATOR

ZENER DIODE CHARACTERISTICS

```
VIN 1 0 DC 10V
R1 1 2 500
D1 2 3 DNAME
D2 0 3 DNAME
RL 2 0 1K
.model DNAME D(IS=0.5UA RS=1 BV=5 IBV=0.5UA)
.TEMP 50
.DC VIN -15 15V 0.5V
.PRINT DC V(2)
.PROBE
.OP
.END
```

The information about the operating point, which is obtained from the output file is as follows:

```
***** OPERATING POINT INFORMATION    TEMPERATURE = 50.000 DEG C

NAME                                D1                                D2
MODEL                              DNAME                              DNAME
ID    ID                            3.19E-03                            -3.19E-03
```

V_D	VD	1.56E-01	-5.45E+00
R_D	REQ	8.69E+00	8.76E+00
C_D	CAP	0.00+00	0.00E+00




FIGURE 12.18 OUTPUT WAVEFORM OF ZENER DIODE CHARACTERISTICS

- 3) An emitter-coupled Schmitt-trigger circuit is shown in Figure 12.19. Plot the hysteresis characteristics of the circuit from the results of the transient analysis. The input voltage is varied from 1V to 3V and 3V to 1V.




FIGURE 12.19 EMITTER-COUPLED SCHMITT-TRIGGER CIRCUIT

EMITTER COUPLED TRIGGER CIRCUIT

.OPTIONS ACCT

VDD 5 0 DC 5

VIN 1 0 PWL (0 1V 2 3V 4 1V)

R1 5 2 4.9K

R2 5 3 3.6K

RE 4 0 1K

Q1 2 1 4 QM


Q2 3 2 4 QM

.MODEL QM NPN (IS=1E-16 BF=50 BR=0.1 RB=50 RC=10 TF=0.12NS TR=5NS
+ CJE=0.4PF PE=0.8 ME=0.4 CJC=0.5PF PC=0.8 MC=0.333 CCS=1PF VA=50)

.TRAN 0.01 4

.PROBE

.END



**FIGURE 12.20 OUTPUT WAVEFORM FOR EMITTER-COUPLED
SCHMITT-TRIGGER CIRCUIT**

12.3.2 DIGITAL EXPERIMENTS:-

For digital devices certain models are created in Pspice. They are nothing but the software representation of basic building blocks of digital primitives. Using such models from the Pspice library we have tested following digital circuit.

EXAMPLE:-

- 1) A 3-to-8 line decoder circuit is shown in Figure 12.21. It consists of AND and OR gate. The digital input is shown in Figure 12.22. Simulate circuit using OrCad Capture CIS. Plot output for one any condition of truth table.




FIGURE 12.21 A 3-TO-8 LINE DECODER CIRCUIT

Decoder is a combinational circuit that converts binary information from n input lines to maximum 2^n unique output lines. Here we have considered the 3-to-8 line decoder circuit of Figure 12.21. The three inputs are decoded into eight outputs, each output representing one of the minterms of the 3-input variables. The three inverters provide the complement of the inputs, and each one of the eight AND gates generate one of the minterms. The operation of the decoder may be further clarified from its input-output relationships, listed in below Figure 12.22. Observe that the output variables are mutually exclusive because one output can be equal to 1 at any

one time. Input and Output signals are shown in Figure 12.23 and 12.24 simultaneously.

Inputs			Outputs							
X	Y	Z	D ₀	D ₁	D ₂	D ₃	D ₄	D ₅	D ₆	D ₇
0	0	0	1	0	0	0	0	0	0	0
0	0	1	0	1	0	0	0	0	0	0
0	1	0	0	0	1	0	0	0	0	0
0	1	1	0	0	0	1	0	0	0	0
1	0	0	0	0	0	0	1	0	0	0
1	0	1	0	0	0	0	0	1	0	0
1	1	0	0	0	0	0	0	0	1	0
1	1	1	0	0	0	0	0	0	0	1

**TABLE 12.1 INPUT-OUTPUT RELATIONSHIPS FOR 3-TO-8 LINE
DECODER CIRCUIT**

INPUT WAVEFORM FOR X, Y, AND Z: -



FIGURE 12.22 INPUT WAVEFORM FOR X, Y AND Z

OUTPUT WAVEFORMS OF 3-TO-8 LINE DECODER: -




FIGURE 12.23 OUTPUT WAVEFORMS OF 3-TO-8 LINE DECODER

CIRCUIT FILE: -

*Libraries:

* Local Libraries :

.STMLIB ".\3to8line.stl"

* From [PSPICE NETLIST] section of pspice91.ini file:

.lib "nom.lib"

*Analysis directives:

.TRAN 0 100Us 0

.OPTIONS DIGINITSTATE= 0

.PROBE

.INC "3to8line-SCHEMATIC1.net"

**** INCLUDING 3to8line-SCHEMATIC1.net ****

* source 3to8line

X_U1A N00048 N00058 N00068 D0 \$G_DPWR \$G_DGND 74S11 PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0

X_U1B N00078 N00058 N00068 D1 \$G_DPWR \$G_DGND 74S11 PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0

X_U1C N00048 N00115 N00068 D2 \$G_DPWR \$G_DGND 74S11 PARAMS:

```

+ IO_LEVEL=0 MNTYMXDLY=0
X_U2A      N00078 N00115 N00068 D3 $G_DPWR $G_DGND 74S11 PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U2B      N00048 N00058 N00189 D4 $G_DPWR $G_DGND 74S11 PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U2C      N00078 N00058 N00189 D5 $G_DPWR $G_DGND 74S11 PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U3A      N00048 N00115 N00189 D6 $G_DPWR $G_DGND 74S11 PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U3B      N00078 N00115 N00189 D7 $G_DPWR $G_DGND 74S11 PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U4A      N00078 N00048 $G_DPWR $G_DGND 74S04 PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U4B      N00115 N00058 $G_DPWR $G_DGND 74S04 PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U4C      N00189 N00068 $G_DPWR $G_DGND 74S04 PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
U_Z        STIM(1,0) $G_DPWR $G_DGND N00078 IO_STM STIMULUS=Z
U_Y        STIM(1,0) $G_DPWR $G_DGND N00115 IO_STM STIMULUS=Y
U_X        STIM(1,0) $G_DPWR $G_DGND N00189 IO_STM STIMULUS=X
**** RESUMING 3to8line-schematic1-3to8line.sim.cir ****
.INC "3to8line-SCHEMATIC1.als"
**** INCLUDING 3to8line-SCHEMATIC1.als ****
.ALIASES
X_U1A      U1A(A=N00048 B=N00058 C=N00068 Y=D0 VCC=$G_DPWR
GND=$G_DGND )
X_U1B      U1B(A=N00078 B=N00058 C=N00068 Y=D1 VCC=$G_DPWR
GND=$G_DGND )
X_U1C      U1C(A=N00048 B=N00115 C=N00068 Y=D2 VCC=$G_DPWR
GND=$G_DGND )
X_U2A      U2A(A=N00078 B=N00115 C=N00068 Y=D3 VCC=$G_DPWR
GND=$G_DGND )
X_U2B      U2B(A=N00048 B=N00058 C=N00189 Y=D4 VCC=$G_DPWR
GND=$G_DGND )

```

```

X_U2C          U2C(A=N00078 B=N00058 C=N00189 Y=D5 VCC=$G_DPWR
GND=$G_DGND )
X_U3A          U3A(A=N00048 B=N00115 C=N00189 Y=D6 VCC=$G_DPWR
GND=$G_DGND )
X_U3B          U3B(A=N00078 B=N00115 C=N00189 Y=D7 VCC=$G_DPWR
GND=$G_DGND )
X_U4A          U4A(A=N00078 Y=N00048 VCC=$G_DPWR GND=$G_DGND )
X_U4B          U4B(A=N00115 Y=N00058 VCC=$G_DPWR GND=$G_DGND )
X_U4C          U4C(A=N00189 Y=N00068 VCC=$G_DPWR GND=$G_DGND )
U_Z            Z(VCC=$G_DPWR GND=$G_DGND OUT=N00078 )
U_Y            Y(VCC=$G_DPWR GND=$G_DGND OUT=N00115 )
U_X            X(VCC=$G_DPWR GND=$G_DGND OUT=N00189 )
_ _ (D0=D0)
_ _ (D1=D1)
_ _ (D2=D2)
_ _ (D3=D3)
_ _ (D4=D4)
_ _ (D5=D5)
_ _ (D6=D6)
_ _ (D7=D7)
_ _ (VCC=VCC)
_ _ (GND=GND)
.ENDALIASES
**** RESUMING 3to8line-schematic1-3to8line.sim.cir ****
.END
; !Stimulus Get
; ! X Digital Y Digital Z Digital
; !Ok
; !Plot Axis_Settings
; !Xrange 0s 40us
; !AutoUniverse
; !XminRes 1ns
; !YminRes 1n
; !Ok

```

```

.STIMULUS Z STIM (1, 1) ;! CLOCKP 10US 5US 1 0
+ +0s 1
+ +5us 0
+ Repeat Forever
+   +5us 1
+   +5us 0
+ EndRepeat
.STIMULUS Y STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+ +0s 0
+ +5us 1
+ Repeat Forever
+   +5us 0
+   +5us 1
+ EndRepeat
.STIMULUS X STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+ +0s 0
+ +5us 1
+ Repeat Forever
+   +5us 0
+   +5us 1
+ EndRepeat
.STIMULUS Z STIM (1, 1) ;! CLOCKP 10US 5US 1 0
+ +0s 1
+ +5us 0
+ Repeat Forever
+   +5us 1
+   +5us 0
+ EndRepeat
.STIMULUS Y STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+ +0s 0
+ +5us 1
+ Repeat Forever
+   +5us 0
+   +5us 1

```

+ EndRepeat

**** Digital Gate MODEL PARAMETERS

	D_S11	D_S04
TPLHMN	1.800000E-09	1.200000E-09
TPLHTY	4.500000E-09	3.000000E-09
TPLHMX	7.000000E-09	4.500000E-09
TPHLMN	2.000000E-09	1.200000E-09
TPHLTY	5.000000E-09	3.000000E-09
TPHLMX	7.500000E-09	5.000000E-09

**** Digital IO MODEL PARAMETERS

	IO_STM	IO_S
DRV L	0	60.6
DRV H	0	72.7
AtoD1		AtoD_S
AtoD2		AtoD_S_NX
AtoD3		AtoD_S
AtoD4		AtoD_S_NX
DtoA1	DtoA_STM	DtoA_S
DtoA2	DtoA_STM	DtoA_S
DtoA3	DtoA_STM	DtoA_S
DtoA4	DtoA_STM	DtoA_S
TSWHL1		788.000000E-12
TSWHL2		795.000000E-12
TSWHL3		788.000000E-12
TSWHL4		795.000000E-12
TSWLH1		889.000000E-12
TSWLH2		887.000000E-12
TSWLH3		889.000000E-12
TSWLH4		887.000000E-12
TPWRT	100.000000E+03	100.000000E+03
JOB CONCLUDED		
TOTAL JOB TIME		.39

- 2) A Quadruple 2-to-1 line multiplexer circuit is shown in Figure 12.24. It consists of AND and OR gate. The digital input is shown in Figure 12.26. Use function table and simulate circuit using OrCad Capture CIS. Plot output for one any condition using function table.




FIGURE 12.24 QUADRUPLE 2-TO-1 LINE MULTIPLEXER CIRCUIT

Quadruple 2-to-1 line multiplexer is a 74157 digital IC. It has four multiplexers, each capable of selecting one of two input lines. Output Y1 can be selected to be equal to either A1 or B1. Similarly, output Y2 may have the values of A2 or B2 and so on. One input selection line, S, suffices to select one of two lines in all four multiplexers. The control input E enables the multiplexers in the 0 state and disables them in the 1 state. Although the circuit contains four multiplexers, we may think of it as a circuit that selects one in a pair of 4-input lines. As shown in Table 12.2 the unit is selects when E=0. Then, if S=0, the four A inputs have a path to the outputs. On the other hand, if S=1, the four B inputs are selected. The outputs have all 0's when E=1, regardless of the value of S.

E	S	OUTPUT Y
1	X	ALL 0'S
0	0	SELECT A
0	1	SELECT B

TABLE 12.2 FUNCTIONAL TABLE OF IC 74157

INPUT WAVEFORM FOR A, B, S and E: -




FIGURE 12.25 INPUT WAVEFORM FOR A, B LINES AND S, E CONTROL LINES

OUTPUT WAVEFORMS FOR TWO DIFFERENT CONDITIONS: -

Figure 12.26 (a) and (b) shows two different output conditions of IC 74157. Condition 1 is **E=0 AND S=0**. In this condition output Y will be the input of signal A. and Condition 2 is **E=0 AND S=1**. In this condition output Y will be the input of signal B.

CONDITION 1: E=0 AND S=0 four A inputs have a path to the outputs




FIGURE 12.26 (A) E=0 AND S=0, OUTPUT OF A LINES

CONDITION 1: E=0 AND S=1 four B inputs have a path to the outputs



FIGURE 12.26 (B) E=0 AND S=1, OUTPUT OF B LINES

CIRCUIT FILE: -

*Libraries:

* Local Libraries :

.STMLIB ".\quad2to1mux.stl"

* From [PSPICE NETLIST] section of pspice91.ini file:

.lib "nom.lib"

*Analysis directives:

.TRAN 0 100us 0

.PROBE

.INC "quad2to1mux-SCHEMATIC1.net"

**** INCLUDING quad2to1mux-SCHEMATIC1.net ****

* source QUAD2TO1MUX

X_U5A N00342 N00357 Y1 \$G_DPWR \$G_DGND 74LS32 PARAMS:

+ IO_LEVEL=0 MNTYMXDLY=0

X_U5B N00348 N00367 Y2 \$G_DPWR \$G_DGND 74LS32 PARAMS:

+ IO_LEVEL=0 MNTYMXDLY=0

X_U5C N00351 N00377 Y3 \$G_DPWR \$G_DGND 74LS32 PARAMS:

+ IO_LEVEL=0 MNTYMXDLY=0

X_U5D N00354 N00387 Y4 \$G_DPWR \$G_DGND 74LS32 PARAMS:

+ IO_LEVEL=0 MNTYMXDLY=0

X_U4A N00065 N00068 \$G_DPWR \$G_DGND 74LS04 PARAMS:

+ IO_LEVEL=0 MNTYMXDLY=0

X_U4B N00068 N00118 \$G_DPWR \$G_DGND 74LS04 PARAMS:

+ IO_LEVEL=0 MNTYMXDLY=0

X_U4C N00071 N00203 \$G_DPWR \$G_DGND 74LS04 PARAMS:

+ IO_LEVEL=0 MNTYMXDLY=0

X_U1A N00318 N00068 N00203 N00342 \$G_DPWR \$G_DGND 74LS11
PARAMS:

+ IO_LEVEL=0 MNTYMXDLY=0

X_U1B N00321 N00068 N00203 N00348 \$G_DPWR \$G_DGND 74LS11
PARAMS:

+ IO_LEVEL=0 MNTYMXDLY=0

X_U1C N00324 N00068 N00203 N00351 \$G_DPWR \$G_DGND 74LS11
PARAMS:

```

+ IO_LEVEL=0 MNTYMXDLY=0
X_U2A      N00327 N00068 N00203 N00354 $G_DPWR $G_DGND 74LS11
PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U2B      N00330 N00118 N00203 N00357 $G_DPWR $G_DGND 74LS11
PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U2C      N00333 N00118 N00203 N00367 $G_DPWR $G_DGND 74LS11
PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U3A      N00336 N00118 N00203 N00377 $G_DPWR $G_DGND 74LS11
PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
X_U3B      N00339 N00118 N00203 N00387 $G_DPWR $G_DGND 74LS11
PARAMS:
+ IO_LEVEL=0 MNTYMXDLY=0
U_A1      STIM(1,0) $G_DPWR $G_DGND N00318 IO_STM STIMULUS=A1
U_A2      STIM(1,0) $G_DPWR $G_DGND N00321 IO_STM STIMULUS=A2
U_A3      STIM(1,0) $G_DPWR $G_DGND N00324 IO_STM STIMULUS=A3
U_A4      STIM(1,0) $G_DPWR $G_DGND N00327 IO_STM STIMULUS=A4
U_B1      STIM(1,0) $G_DPWR $G_DGND N00330 IO_STM STIMULUS=B1
U_B2      STIM(1,0) $G_DPWR $G_DGND N00333 IO_STM STIMULUS=B2
U_B3      STIM(1,0) $G_DPWR $G_DGND N00336 IO_STM STIMULUS=B3
U_B4      STIM(1,0) $G_DPWR $G_DGND N00339 IO_STM STIMULUS=B4
U_S       STIM(1,0) $G_DPWR $G_DGND N00065 IO_STM STIMULUS=S
U_E       STIM(1,0) $G_DPWR $G_DGND N00071 IO_STM STIMULUS=E

**** RESUMING quad2to1mux-schematic1-quad2to1mux.sim.cir ****
.INC "quad2to1mux-SCHEMATIC1.als"
**** INCLUDING quad2to1mux-SCHEMATIC1.als ****
.ALIASES
X_U5A      U5A(A=N00342 B=N00357 Y=Y1 VCC=$G_DPWR
GND=$G_DGND )

```

X_U5B U5B(A=N00348 B=N00367 Y=Y2 VCC=\$G_DPWR
GND=\$G_DGND)
X_U5C U5C(A=N00351 B=N00377 Y=Y3 VCC=\$G_DPWR
GND=\$G_DGND)
X_U5D U5D(A=N00354 B=N00387 Y=Y4 VCC=\$G_DPWR
GND=\$G_DGND)
X_U4A U4A(A=N00065 Y=N00068 VCC=\$G_DPWR GND=\$G_DGND)
X_U4B U4B(A=N00068 Y=N00118 VCC=\$G_DPWR GND=\$G_DGND)
X_U4C U4C(A=N00071 Y=N00203 VCC=\$G_DPWR GND=\$G_DGND)
X_U1A U1A(A=N00318 B=N00068 C=N00203 Y=N00342 VCC=\$G_DPWR
GND=\$G_DGND+)
X_U1B U1B(A=N00321 B=N00068 C=N00203 Y=N00348 VCC=\$G_DPWR
GND=\$G_DGND+)
X_U1C U1C(A=N00324 B=N00068 C=N00203 Y=N00351 VCC=\$G_DPWR
GND=\$G_DGND+)
X_U2A U2A(A=N00327 B=N00068 C=N00203 Y=N00354 VCC=\$G_DPWR
GND=\$G_DGND+)
X_U2B U2B(A=N00330 B=N00118 C=N00203 Y=N00357 VCC=\$G_DPWR
GND=\$G_DGND+)
X_U2C U2C(A=N00333 B=N00118 C=N00203 Y=N00367 VCC=\$G_DPWR
GND=\$G_DGND+)
X_U3A U3A(A=N00336 B=N00118 C=N00203 Y=N00377 VCC=\$G_DPWR
GND=\$G_DGND+)
X_U3B U3B(A=N00339 B=N00118 C=N00203 Y=N00387 VCC=\$G_DPWR
GND=\$G_DGND+)
U_A1 A1(VCC=\$G_DPWR GND=\$G_DGND OUT=N00318)
U_A2 A2(VCC=\$G_DPWR GND=\$G_DGND OUT=N00321)
U_A3 A3(VCC=\$G_DPWR GND=\$G_DGND OUT=N00324)
U_A4 A4(VCC=\$G_DPWR GND=\$G_DGND OUT=N00327)
U_B1 B1(VCC=\$G_DPWR GND=\$G_DGND OUT=N00330)
U_B2 B2(VCC=\$G_DPWR GND=\$G_DGND OUT=N00333)
U_B3 B3(VCC=\$G_DPWR GND=\$G_DGND OUT=N00336)
U_B4 B4(VCC=\$G_DPWR GND=\$G_DGND OUT=N00339)
U_S S(VCC=\$G_DPWR GND=\$G_DGND OUT=N00065)

```

U_E      E(VCC=$G_DPWR GND=$G_DGND OUT=N00071 )
-  _(Y1=Y1)
-  _(Y2=Y2)
-  _(Y3=Y3)
-  _(Y4=Y4)
-  _(GND=GND)
-  _(VCC=VCC)
.ENDALIASES
**** RESUMING quad2to1mux-schematic1-quad2to1mux.sim.cir ****
.END
+  +0s 1
+  +5us 0
+  Repeat Forever
+    +5us 1
+    +5us 0
+  EndRepeat
.STIMULUS B3 STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+  +0s 0
+  +5us 1
+  Repeat Forever
+    +5us 0
+    +5us 1
+  EndRepeat
.STIMULUS B2 STIM (1, 1) ;! CLOCKP 10US 5US 1 0
+  +0s 1
+  +5us 0
+  Repeat Forever
+    +5us 1
+    +5us 0
+  EndRepeat
.STIMULUS B1 STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+  +0s 0
+  +5us 1
+  Repeat Forever

```

```

+   +5us 0
+   +5us 1
+   EndRepeat
.STIMULUS A4 STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+   +0s 0
+   +5us 1
+   Repeat Forever
+   +5us 0
+   +5us 1
+   EndRepeat
.STIMULUS A3 STIM (1, 1) ;! CLOCKP 10US 5US 1 0
+   +0s 1
+   +5us 0
+   Repeat Forever
+   +5us 1
+   +5us 0
+   EndRepeat
.STIMULUS A2 STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+   +0s 0
+   +5us 1
+   Repeat Forever
+   +5us 0
+   +5us 1
+   EndRepeat
.STIMULUS A1 STIM (1, 1) ;! CLOCKP 10US 5us 1 0
+   +0s 1
+   +5us 0
+   Repeat Forever
+   +5us 1
+   +5us 0
+   EndRepeat
.STIMULUS A1 STIM (1, 1) ;! CLOCKP 10US 5us 1 0
+   +0s 1
+   +5us 0

```

```

+ Repeat Forever
+   +5us 1
+   +5us 0
+ EndRepeat
.STIMULUS A2 STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+ +0s 0
+ +5us 1
+ Repeat Forever
+   +5us 0
+   +5us 1
+ EndRepeat
.STIMULUS A3 STIM (1, 1) ;! CLOCKP 10US 5US 1 0
+ +0s 1
+ +5us 0
+ Repeat Forever
+   +5us 1
+   +5us 0
+ EndRepeat
.STIMULUS A4 STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+ +0s 0
+ +5us 1
+ Repeat Forever
+   +5us 0
+   +5us 1
+ EndRepeat
.STIMULUS B1 STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+ +0s 0
+ +5us 1
+ Repeat Forever
+   +5us 0
+   +5us 1
+ EndRepeat
.STIMULUS B2 STIM (1, 1) ;! CLOCKP 10US 5US 1 0
+ +0s 1

```

```

+ +5us 0
+ Repeat Forever
+ +5us 1
+ +5us 0
+ EndRepeat
.STIMULUS B3 STIM (1, 1) ;! CLOCKP 10US 5US 0 0
+ +0s 0
+ +5us 1
+ Repeat Forever
+ +5us 0
+ +5us 1
+ EndRepeat
.STIMULUS B4 STIM (1, 1) ;! CLOCKP 10US 5US 1 0
+ +0s 1
+ +5us 0
+ Repeat Forever
+ +5us 1
+ +5us 0
+ EndRepeat
.STIMULUS S STIM (1, 1) ;! CLOCKP 15US 5US 0 0
+ +0s 0
+ +10us 1
+ Repeat Forever
+ +5us 0
+ +10us 1
+ EndRepeat
** circuit file for profile: QUAD2TO1MUX
**** Digital Gate MODEL PARAMETERS
*****
D_LS32      D_LS04      D_LS11
TPLHMN  5.600000E-09  3.600000E-09  3.200000E-09
TPLHTY  14.000000E-09  9.000000E-09  8.000000E-09
TPLHMX  22.000000E-09  15.000000E-09  15.000000E-09
TPHLMN  5.600000E-09  4.000000E-09  4.000000E-09

```

TPHLTY 14.000000E-09 10.000000E-09 10.000000E-09
 TPHLMX 22.000000E-09 15.000000E-09 20.000000E-09

** circuit file for profile: QUAD2TO1MUX

**** Digital IO MODEL PARAMETERS

IO_STM	IO_LS
DRVL 0	157
DRVH 0	108
AtoD1	AtoD_LS
AtoD2	AtoD_LS_NX
AtoD3	AtoD_LS
AtoD4	AtoD_LS_NX
DtoA1 DtoA_STM	DtoA_LS
DtoA2 DtoA_STM	DtoA_LS
DtoA3 DtoA_STM	DtoA_LS
DtoA4 DtoA_STM	DtoA_LS
TSWHL1	2.724000E-09
TSWHL2	2.724000E-09
TSWHL3	2.724000E-09
TSWHL4	2.724000E-09
TSWLH1	2.104000E-09
TSWLH2	2.104000E-09
TSWLH3	2.104000E-09
TSWLH4	2.104000E-09
TPWRT 100.000000E+03	100.000000E+03

JOB CONCLUDED

TOTAL JOB TIME .05



CHAPTER 13

CONCLUSION



In present work the development of experiments based on 8085 microprocessor, 89C51 microcontroller, their interfacing, debugging and simulation are concentrated. The experiments are framed with necessary theoretical background and study material.

In Section 1 basics of microprocessor and microcontroller are discussed. Section 2 contains the experiments on 8085 and interfacing with its peripherals devices. Section 3 is completely devoted to experiments on 89C51. Section 4 discusses the Logic analyzer, In-Circuit Emulator and Pspice.

All the experiments are well tested and represented with study material. These experiments will be help to the students who are desirous to learn themselves. In some experiments PCB designing is also given. It is hoped that this work would benefit to the learners.

References

• BOOKS: -

- B-1) A. W. Moore, K. E. Fronheisher, Vinay Khanna, John DeLaune, G. G. Sawyer, M. E. Edison, T. C. Daly, J. F. Vittera “Motorola semiconductor product Inc. Microprocessor¹ applications manual” McGraw hill publishing inc. N Y.
- B-2) Ahson S. L. “Microprocessor with application in process control” Tata McGraw hill Publishing Company Limited New Delhi, 1992
- B-3) Baker R. Jacob, Li Harry W, Boyce David E “CMOS Circuit design, layout and simulation”, Prentice hall of India.
- B-4) Bose Sanjay “Digital System: From Gates to Microprocessor” 2nd edition, New Age International (P) ltd. 1992.
- B-5) Dr. H. N. Pandya² “Printed Circuit Board” Gujarat Granth Nirman Board Ahmedabad India.
- B-6) Dr. H. N. Pandya “Understanding P.C.B. Designing software” 1st edition, Saurashtra University Rajkot 2006.
- B-7) Electronics concepts handbook vol. 1 to 3 McGraw hill publishing inc. N. Y.,
- B-8) Giacoletto “Electronics Designers’ handbook” 2nd edition, McGraw hill publishing inc.
- B-9) Hall Douglas “Microprocessor and Digital system” 2nd edition, Tata McGraw hill Publishing Company Limited.
- B-10) J. C. Whitaker “The Electronics Handbook” IEEE Press.
- B-11) John Markus “Guidebook of Electronics Circuit”, McGraw hill publishing inc..
- B-12) Kenneth J. Ayala “The 8051 microcontroller Architecture, Programming and Applications” 2nd edition, Penram International Mumbai.
- B-13) Microprocessor Data handbook, Revised Edition, BPB Publication New Delhi

¹ Motorola microprocessor 68C00 applications

² Head, Department Of Electronics, Saurashtra University, Rajkot, Gujarat, India

Appendix B

- B-14) Osborne, Adam, “An Introduction to Microcomputers Volume 0 to 3” Adam Osborne and Associates, Inc. 1977.
- B-15) P. K. Ghosh and P. R. Sridhar “0000 to 8085 Introduction to Microprocessor for Engineers and scientists” 2nd edition, Prentice hall of India EEE edition New Delhi.
- B-16) Padmanbhan K. “Learn to use Microprocessor” 4th edition, EFY Enterprises (P) ltd. New Delhi, 1999.
- B-17) R. S. Gaonkar “Microprocessor architecture, programming and application with the 8085” 3rd edition, Penram International Mumbai.
- B-18) Rashid Mohammad “Spice for circuits and electronics using PSPICE” 2nd and 3rd edition, Prentice hall of India, Eastern Economy Edition New Delhi.
- B-19) Singh Renu “Microprocessor Interfacing and Application” 2nd edition, New Age Publication (P) ltd., 2006.
- B-20) Stan Gibilisco and Neil Sclater³ “Encyclopedia Of Electronics” 1st and 2nd edition, McGraw hill publishing inc. N Y.
- B-21) Taub Herbert “Digital circuits and microprocessor”, Tata McGraw hill Publishing company Limited England, 1982.
- B-22) Theagarajan R and Dhanasekaran S. “Microprocessor and its Applications” New Age international (P) ltd. New Delhi, 1997.
- B-23) Titus Christopher A., Larsen David G., Titus Jonathan A. “8085A Cookbook” Howard W. Sams & Co., Inc. 1980.
- B-24) Walter Bosshart “Printed Circuit Board: Design and Technology” Tata McGraw hill Publishing company Limited New Delhi, 1993.
- B-25) Borivaje Furht, Himansu Parikh “Microprocessor interfacing and communication using the Intel SDK-85” Prentice Hall, January 1986.

● RESEARCH PAPERS: -

- R.P-1) **Mr. M. C. Nanavati**, Dr. H. N. Pandya,
“Experimenting with 8251: a USART chip”,
Lab experiments (LE), Bangalore, India, APRIL 2004, Vol. - 4 No. 1 Pg. 52
- R.P-2) **Mr. M. C. Nanavati**, Dr. H. N. Pandya, Dr. D. G. Vyas,
“Study of 8255 through experiments using microprocessor kit”,
Lab experiment (LE), Bangalore, India April-2004, Vol. - 4 No. 2, Pg. 89.

³ Editor In-Chief McGraw hill publishing inc. N.Y.

Appendix B

- R.P-3) **Mr. M. C. Nanavati**, Dr. H. N. Pandya,
“Study of interrupts of 8085”
Lab experiment (LE), Bangalore, India, June 2005, Vol. - 5 No. 2, Pg. 119.
- R.P-4) **Mr. M. C. Nanavati**, Dr. H. N. Pandya, Mr. A. B. Bhaskar
“Keyboard interface with AT89C51 Microcontroller”
Electronics maker, Delhi, India January 2007 Issue 128 No. 12, Pg. 52-56.
- R.P-5) **Mr. M. C. Nanavati**, Dr. H. N. Pandya, Mr. A. A. Bhaskar
“Running character display using AT89C51 Microcontroller” (part I)
Electronics maker, Delhi, India November 2006 Issue 126 No. 11, Pg. 39-41.
- R.P-6) **Mr. M. C. Nanavati**, Dr. H. N. Pandya, Mr. A. A. Bhaskar
“Running character display using AT89C51 Microcontroller” (part II)
Electronics maker, Delhi, India December 2006 Issue 127 No. 11, Pg. 38-41.
- R.P-7) **Mr. M. C. Nanavati**, Dr. H. N. Pandya, Mr. A. A. Bhaskar
“Electronic Name-plate Using AT89C51 Microcontroller”
Electronics maker, Delhi, India, June 2006 Issue 121 No. 11, Pg. 51-56.
- R.P-8) **Mr. M. C. Nanavati**, Dr. H. N. Pandya,
“Debugging microprocessor kit using logic state analyzer: a simple laboratory experiment”,
Lab Experiment (LE), Bangalore, India, December-2003, Vol.-3 No. 4. Pg. 312.
- R.P-9) **Mr. M. C. Nanavati**, Dr. H. N. Pandya,
“Using In-circuit Emulator in the laboratory”
Lab experiment (LE), Bangalore, India, March 2006, Vol. - 6 No. 1, Pg. 39.

● WEBSITES: -

- W-1) <http://docs.hp.com/en/B6057-96002/ch04.html>
- W-2) <http://groups.google.co.in/groups/dir?hl=en&sel=0,16823622,16823610>
- W-3) <http://groups.google.co.in/sci.electronics.design?lnk=hppg&hl=en>
- W-4) <http://linuxassembly.org/>
- W-5) <http://tech.groups.yahoo.com/group/emu8086/>
- W-6) <http://tech.groups.yahoo.com/group/win32-nasm-users/>
- W-7) <http://www.2cpu.com/>
- W-8) <http://www.8052.com/>

Appendix B

- W-9) http://www.brothersoft.com/Home_Education_Science_8085_Simulatot_19818.html
- W-10) <http://www.chip-architect.com/>
- W-11) <http://www.clickon-cpu.com/>
- W-12) <http://www.cpu-museum.com/>
- W-13) <http://www.cpu-museum.net/>
- W-14) <http://www.datasheetcatalog.com/>
- W-15) <http://www.emu8086.com/>
- W-16) <http://www.emulation.com/>
- W-17) <http://www.emulators.com/pentium4.htm>
- W-18) <http://www.freemware.org/>
- W-19) <http://www.ieee.org/>
- W-20) <http://www.intel.com/>
- W-21) <http://www.microprocessor.ssc.ru/>
- W-22) <http://www.old-computer.com/museum/computer.asp?st=1&c=805>
- W-23) <http://www.orcad.com>
- W-24) <http://www.rdos.net/sim/>
- W-25) <http://www.thefreecountry.com/>
- W-26) <http://www.tomshardware.com/>
- W-27) <http://www.x86.org/>
- W-28) <http://www.x86-64.org/>

MC1488, SN55188, SN75188 QUADRUPLE LINE DRIVERS

SLLS094B – SEPTEMBER 1983 – REVISED MAY 1995

- Meet or Exceed the Requirements of ANSI EIA/TIA-232-E and ITU Recommendation V.28
- Designed to Be Interchangeable With Motorola MC1488
- Current-Limited Output: 10 mA Typical
- Power-Off Output Impedance: 300 Ω Minimum
- Slew Rate Control by Load Capacitor
- Flexible Supply Voltage Range
- Input Compatible With Most TTL Circuits

description

The MC1488, SN55188, and SN75188 are monolithic quadruple line drivers designed to interface data terminal equipment with data communications equipment in conformance with ANSI EIA/TIA-232-E using a diode in series with each supply-voltage terminal as shown under typical applications.


The SN55188 is characterized for operation over the full military temperature range of -55°C to 125°C . The MC1488 and SN75188 are characterized for operation from 0°C to 70°C .

FUNCTION TABLE
(drivers 2–4)


A	B	Y
H	H	L
L	X	H
X	L	H

H = high level, L = low level,
X = irrelevant

SN55188 . . . J OR W PACKAGE
MC1488, SN75188 . . . D OR N PACKAGE
(TOP VIEW)



SN55188 . . . FK PACKAGE
(TOP VIEW)



NC – No internal connection



Please be aware that an important notice concerning availability, standard warranty, and use in critical applications of Texas Instruments semiconductor products and disclaimers thereto appears at the end of this data sheet.

PRODUCTION DATA information is current as of publication date. Products conform to specifications per the terms of Texas Instruments standard warranty. Production processing does not necessarily include testing of all parameters.

**TEXAS
INSTRUMENTS**


POST OFFICE BOX 655303 • DALLAS, TEXAS 75265

Copyright © 1995, Texas Instruments Incorporated

MC1488, SN55188, SN75188 QUADRUPLE LINE DRIVERS

SLLS094B – SEPTEMBER 1983 – REVISED MAY 1995


logic symbol†



† This symbol is in accordance with ANSI/IEEE Std 91-1984 and IEC Publication 617-12.

Pin numbers shown are for the D and N packages.

logic diagram (positive logic)




Positive logic

$Y = \overline{A}$ (driver 1)

$Y = AB$ or $\overline{A} + \overline{B}$ (drivers 2 thru 4)

schematic (each driver)



Resistor values shown are nominal.

absolute maximum ratings over operating free-air temperature (unless otherwise noted)[†]

Supply voltage, V_{CC+} at (or below) 25°C free-air temperature (see Notes 1 and 2)	15 V
Supply voltage, V_{CC-} at (or below) 25°C free-air temperature (see Notes 1 and 2)	–15 V
Input voltage, V_I	–15 V to 7 V
Output voltage, V_O	–15 V to 15 V
Continuous total power dissipation (see Note 2)	See Dissipation Rating Table
Operating free-air temperature range, T_A : SN55188	–55°C to 125°C
MC1488, SN75188	0°C to 70°C
Storage temperature range, T_{stg}	–65°C to 150°C
Case temperature for 60 seconds, FK package	260°C
Lead temperature 1,6 mm (1/16 inch) from case for 10 seconds: D or N package	260°C
Lead temperature 1,6 mm (1/16 inch) from case for 60 seconds: J or W package	300°C

[†] Stresses beyond those listed under “absolute maximum ratings” may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated under “recommended operating conditions” is not implied. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.

- NOTES: 1. All voltage values are with respect to the network ground terminal.
2. For operation above 25°C free-air temperature, refer to the maximum supply voltage curve, Figure 6. In the FK and J packages, SN55188 chips are alloy mounted.

DISSIPATION RATING TABLE

PACKAGE	$T_A \leq 25^\circ\text{C}$ POWER RATING	DERATING FACTOR ABOVE $T_A = 25^\circ\text{C}$	$T_A = 70^\circ\text{C}$ POWER RATING	$T_A = 125^\circ\text{C}$ POWER RATING
D	950 mW	7.6 mW/°C	608 mW	–
FK	1375 mW	11.0 mW/°C	880 mW	275 mW
J	1375 mW	11.0 mW/°C	880 mW	275 mW
N	1150 mW	9.2 mW/°C	736 mW	–
W	1000 mW	8.0 mW/°C	640 mW	200 mW

recommended operating conditions

	SN55188			MC1488, SN75188			UNIT
	MIN	NOM	MAX	MIN	NOM	MAX	
Supply voltage, V_{CC+}	7.5	9	15	7.5	9	15	V
Supply voltage, V_{CC-}	–7.5	–9	–15	–7.5	–9	–15	V
High-level input voltage, V_{IH}	1.9			1.9			V
Low-level input voltage, V_{IL}			0.8			0.8	V
Operating free-air temperature, T_A	–55		125	0		70	°C

MC1488, SN55188, SN75188 QUADRUPLE LINE DRIVERS

SLLS094B – SEPTEMBER 1983 – REVISED MAY 1995

electrical characteristics over operating free-air temperature range, $V_{CC\pm} = \pm 9\text{ V}$ (unless otherwise noted)

PARAMETER	TEST CONDITIONS		SN55188			MC1488, SN75188			UNIT
			MIN	TYP†	MAX	MIN	TYP†	MAX	
V_{OH} High-level output voltage	$V_{IL} = 0.8\text{ V}$, $R_L = 3\text{ k}\Omega$	$V_{CC+} = 9\text{ V}$, $V_{CC-} = -9\text{ V}$	6	7		6	7		V
		$V_{CC+} = 13.2\text{ V}$, $V_{CC-} = -13.2\text{ V}$	9	10.5		9	10.5		
V_{OL} Low-level output voltage	$V_{IH} = 1.9\text{ V}$, $R_L = 3\text{ k}\Omega$	$V_{CC+} = 9\text{ V}$, $V_{CC-} = -9\text{ V}$		-7‡	-6		-7	-6	V
		$V_{CC+} = 13.2\text{ V}$, $V_{CC-} = -13.2\text{ V}$		-10.5‡	-9		-10.5	-9	
I_{IH} High-level input current	$V_I = 5\text{ V}$				10			10	μA
I_{IL} Low-level input current	$V_I = 0$			-1	-1.6		-1	-1.6	mA
$I_{OS(H)}$ Short-circuit output current at high level§	$V_I = 0.8\text{ V}$,	$V_O = 0$	-4.6	-9	-13.5	-6	-9	-12	mA
$I_{OS(L)}$ Short-circuit output current at low level§	$V_I = 1.9\text{ V}$,	$V_O = 0$	4.6	9	13.5	6	9	12	mA
r_o Output resistance, power off	$V_{CC+} = 0$, $V_O = -2\text{ V to } 2\text{ V}$	$V_{CC-} = 0$,	300			300			Ω
I_{CC+} Supply current from V_{CC+}	$V_{CC+} = 9\text{ V}$, No load	All inputs at 1.9 V		15	20		15	20	mA
		All inputs at 0.8 V		4.5	6		4.5	6	
	$V_{CC+} = 12\text{ V}$, No load	All inputs at 1.9 V		19	25		19	25	
		All inputs at 0.8 V		5.5	7		5.5	7	
	$V_{CC+} = 15\text{ V}$, No load, $T_A = 25^\circ\text{C}$	All inputs at 1.9 V			34			34	
		All inputs at 0.8 V			12			12	
I_{CC-} Supply current from I_{CC-}	$V_{CC-} = -9\text{ V}$, No load	All inputs at 1.9 V		-13	-17		-13	-17	mA
		All inputs at 0.8 V			-0.5			-0.015	
	$V_{CC-} = -12\text{ V}$, No load	All inputs at 1.9 V		-18	-23		-18	-23	
		All inputs at 0.8 V			-0.5			-0.015	
	$V_{CC-} = -15\text{ V}$, No load, $T_A = 25^\circ\text{C}$	All inputs at 1.9 V			-34			-34	
		All inputs at 0.8 V			-2.5			-2.5	
P_D Total power dissipation	$V_{CC+} = 9\text{ V}$, No load	$V_{CC-} = -9\text{ V}$,			333			333	mW
	$V_{CC+} = 12\text{ V}$, No load	$V_{CC-} = -12\text{ V}$,			576			576	

† All typical values are at $T_A = 25^\circ\text{C}$.

‡ The algebraic convention, in which the less positive (more negative) limit is designated as minimum, is used in this data sheet for logic voltage levels only, e.g., if -6 V is a maximum, the typical value is a more negative voltage.

§ Not more than one output should be shorted at a time.


switching characteristics, $V_{CC\pm} = \pm 9\text{ V}$, $T_A = 25^\circ\text{C}$

PARAMETER	TEST CONDITIONS	MIN	TYP	MAX	UNIT
t_{PLH} Propagation delay time, low- to high-level output	$R_L = 3\text{ k}\Omega$, See Figure 1 $C_L = 15\text{ pF}$		220	350	ns
t_{PHL} Propagation delay time, high- to low-level output			100	175	ns
t_{TLH} Transition time, low- to high-level output [†]			55	100	ns
t_{THL} Transition time, high- to low-level output [†]			45	75	ns
t_{TLH} Transition time, low- to high-level output [‡]	$R_L = 3\text{ k}\Omega$ to $7\text{ k}\Omega$, See Figure 1 $C_L = 2500\text{ pF}$		2.5		μs
t_{THL} Transition time, high- to low-level output [‡]			3.0		μs

[†] Measured between 10% and 90% points of output waveform.

[‡] Measured between 3 V and -3 V points on the output waveform (EIA/TIA-232-E conditions).

PARAMETER MEASUREMENT INFORMATION



- NOTES: A. The pulse generator has the following characteristics: $t_W = 0.5\text{ }\mu\text{s}$, $\text{PRR} \leq 1\text{ MHz}$, $Z_O = 50\text{ }\Omega$.
B. C_L includes probe and jig capacitance.

Figure 1. Test Circuit and Voltage Waveforms

TYPICAL CHARACTERISTICS†




Figure 2




Figure 3




Figure 4




Figure 5

† Data for temperatures below 0°C and above 70°C are applicable to SN55188 circuit only.

THERMAL INFORMATION†




Figure 6

† Data for temperatures below 0°C and above 70°C are applicable to SN55188 circuit only.

APPLICATION INFORMATION





Figure 7. Logic Translator Applications



Diodes placed in series with the V_{CC+} and V_{CC-} leads will protect the SN55188/SN75188 in the fault condition in which the device outputs are shorted to $\pm 15 \text{ V}$ and the power supplies are at low voltage and provide low-impedance paths to ground.

Figure 8. Power Supply Protection to Meet
Power-Off Fault Conditions of
ANSI EIA/TIA-232-E

IMPORTANT NOTICE

Texas Instruments and its subsidiaries (TI) reserve the right to make changes to their products or to discontinue any product or service without notice, and advise customers to obtain the latest version of relevant information to verify, before placing orders, that information being relied on is current and complete. All products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgement, including those pertaining to warranty, patent infringement, and limitation of liability.

TI warrants performance of its semiconductor products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are utilized to the extent TI deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.

CERTAIN APPLICATIONS USING SEMICONDUCTOR PRODUCTS MAY INVOLVE POTENTIAL RISKS OF DEATH, PERSONAL INJURY, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE ("CRITICAL APPLICATIONS"). TI SEMICONDUCTOR PRODUCTS ARE NOT DESIGNED, AUTHORIZED, OR WARRANTED TO BE SUITABLE FOR USE IN LIFE-SUPPORT DEVICES OR SYSTEMS OR OTHER CRITICAL APPLICATIONS. INCLUSION OF TI PRODUCTS IN SUCH APPLICATIONS IS UNDERSTOOD TO BE FULLY AT THE CUSTOMER'S RISK.

In order to minimize risks associated with the customer's applications, adequate design and operating safeguards must be provided by the customer to minimize inherent or procedural hazards.

TI assumes no liability for applications assistance or customer product design. TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of TI covering or relating to any combination, machine, or process in which such semiconductor products or services might be or are used. TI's publication of information regarding any third party's products or services does not constitute TI's approval, warranty or endorsement thereof.

This datasheet has been download from:

www.datasheetcatalog.com


Datasheets for electronics components.

MC1489, MC1489A, SN55189, SN55189A, SN75189, SN75189A QUADRUPLE LINE RECEIVERS

SLLS095D – SEPTEMBER 1973 – REVISED OCTOBER 1998

- Input Resistance . . . 3 k Ω to 7 k Ω
- Input Signal Range . . . ± 30 V
- Operate From Single 5-V Supply
- Built-In Input Hysteresis (Double Thresholds)
- Response Control that Provides:
Input Threshold Shifting
Input Noise Filtering
- Meet or Exceed the Requirements of
TIA/EIA-232-F and ITU Recommendation
V.28
- Fully Interchangeable With Motorola™
MC1489 and MC1489A

SN55189, SN55189A . . . J OR W PACKAGE
MC1489, MC1489A, SN75189, SN75189A
D, N, OR NS† PACKAGE
(TOP VIEW)




† The NS package is only available left-end taped and reeled.
For SN75189, order SN75189NSR.

description

These devices are monolithic low-power Schottky quadruple line receivers designed to satisfy the requirements of the standard interface between data-terminal equipment and data-communication equipment as defined by TIA/EIA-232-F. A separate response-control (CONT) terminal is provided for each receiver. A resistor or a resistor and bias-voltage source can be connected between this terminal and ground to shift the input threshold levels. An external capacitor can be connected between this terminal and ground to provide input noise filtering.

The SN55189 and SN55189A are characterized for operation over the full military temperature range of -55°C to 125°C . The MC1489, MC1489A, SN75189, and SN75189A are characterized for operation from 0°C to 70°C .

SN55189, SN55189A . . . FK PACKAGE
(TOP VIEW)



NC – No internal connection



Please be aware that an important notice concerning availability, standard warranty, and use in critical applications of Texas Instruments semiconductor products and disclaimers thereto appears at the end of this data sheet.

Motorola is a trademark of Motorola, Incorporated.

PRODUCTION DATA information is current as of publication date. Products conform to specifications per the terms of Texas Instruments standard warranty. Production processing does not necessarily include testing of all parameters.

 **TEXAS
INSTRUMENTS**

POST OFFICE BOX 655303 • DALLAS, TEXAS 75265


Copyright © 1998, Texas Instruments Incorporated
On products compliant to MIL-PRF-38535, all parameters are tested unless otherwise noted. On all other products, production processing does not necessarily include testing of all parameters.

MC1489, MC1489A, SN55189, SN55189A, SN75189, SN75189A

QUADRUPLE LINE RECEIVERS


SLLS095D – SEPTEMBER 1973 – REVISED OCTOBER 1998

logic symbol†




† This symbol is in accordance with ANSI/IEEE Std 91-1984 and IEC Publication 617-12. Pin numbers shown are for the D, J, N, NS, and W packages.

logic diagram (positive logic)



schematic (each receiver)



	MC1489 SN55189 SN75189	MC1489A SN55189A SN75189A
R1	8.4 kΩ	1.84 kΩ

Resistor values shown are nominal.

MC1489, MC1489A, SN55189, SN55189A, SN75189, SN75189A QUADRUPLE LINE RECEIVERS

SLLS095D – SEPTEMBER 1973 – REVISED OCTOBER 1998

absolute maximum ratings over operating free-air temperature (unless otherwise noted)[†]

Supply voltage, V_{CC} (see Note 1)	10 V
Input voltage, V_I	± 30 V
Output voltage, V_O	20 mA
Continuous total power dissipation	See Dissipation Rating Table
Operating free-air temperature range, T_A : SN55189, SN55189A	-55°C to 125°C
MC1489, MC1489A, SN75189, SN75189A	0°C to 70°C
Storage temperature range, T_{stg}	-65°C to 150°C
Case temperature for 60 seconds, FK package	260°C
Lead temperature 1,6 mm (1/16 inch) from case for 60 seconds: J or W package	300°C
Lead temperature 1,6 mm (1/16 inch) from case for 10 seconds: D, N, or NS package	260°C

[†] Stresses beyond those listed under "absolute maximum ratings" may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated under "recommended operating conditions" is not implied. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.

NOTES: 1. All voltage values are with respect to the network ground terminal.

DISSIPATION RATING TABLE

PACKAGE	$T_A \leq 25^{\circ}\text{C}$ POWER RATING	DERATING FACTOR ABOVE $T_A = 25^{\circ}\text{C}$	$T_A = 70^{\circ}\text{C}$ POWER RATING	$T_A = 125^{\circ}\text{C}$ POWER RATING
D	950 mW	7.6 mW/ $^{\circ}\text{C}$	608 mW	N/A
FK	1375 mW	11.0 mW/ $^{\circ}\text{C}$	880 mW	275 mW
J [‡]	1375 mW	11.0 mW/ $^{\circ}\text{C}$	880 mW	275 mW
N	1150 mW	9.2 mW/ $^{\circ}\text{C}$	736 mW	N/A
NS	625 mW	4.0 mW/ $^{\circ}\text{C}$	445 mW	N/A
W	1000 mW	8.0 mW/ $^{\circ}\text{C}$	640 mW	200 mW

[‡] In the J package, SN55189 and SN55189A chips are either silver glass or alloy mounted.

recommended operating conditions

	MIN	NOM	MAX	UNIT
Supply voltage, V_{CC}	4.5	5	5.5	V
Input voltage, V_I	-25		25	V
High-level output current, I_{OH}			-0.5	mA
Low-level output current, I_{OL}			10	mA
Operating free-air temperature, T_A	0		70	$^{\circ}\text{C}$



MC1489, MC1489A, SN55189, SN55189A, SN75189, SN75189A QUADRUPLE LINE RECEIVERS

SLLS095D – SEPTEMBER 1973 – REVISED OCTOBER 1998

electrical characteristics over operating free-air temperature range, $V_{CC} = 5\text{ V} \pm 1\%$ (unless otherwise noted)

PARAMETER	TEST FIGURE	TEST CONDITIONS†		SN55189 SN55189A			MC1489, MC1489A SN75189 SN75189A			UNIT
				MIN	TYP‡	MAX	MIN	TYP‡	MAX	
V_{IT+} Positive-going input threshold voltage	1	'89	$T_A = 25^\circ\text{C}$	1	1.3	1.5	1	1.3	1.5	V
			$T_A = 0^\circ\text{C to } 70^\circ\text{C}$				0.9		1.6	
			$T_A = -55^\circ\text{C to } 125^\circ\text{C}$	0.6		1.9				
		'89A	$T_A = 25^\circ\text{C}$	1.75	1.9	2.25	1.75	1.9	2.25	
			$T_A = 0^\circ\text{C to } 70^\circ\text{C}$				1.55		2.25	
			$T_A = -55^\circ\text{C to } 125^\circ\text{C}$	1.30		2.65				
V_{IT-} Negative-going input threshold voltage	1	'89, '89A	$T_A = 25^\circ\text{C}$	0.75	1.0	1.25	0.75	1.0	1.25	V
			$T_A = 0^\circ\text{C to } 70^\circ\text{C}$				0.65		1.25	
			$T_A = -55^\circ\text{C to } 125^\circ\text{C}$	0.35		1.6				
V_{OH} High-level output voltage	1	$V_I = 0.75\text{ V}$, $I_{OH} = -0.5\text{ mA}$		2.6	4	5	2.6	4	5	V
		Input open, $I_{OH} = -0.5\text{ mA}$		2.6	4	5	2.6	4	5	
V_{OL} Low-level output voltage	1	$V_I = 3\text{ V}$, $I_{OL} = 10\text{ mA}$			0.2	0.45		0.2	0.45	V
I_{IH} High-level input current	2	$V_I = 25\text{ V}$		3.6		8.3	3.6		8.3	mA
		$V_I = 3\text{ V}$		0.43			0.43			
I_{IL} Low-level input current	2	$V_I = -25\text{ V}$		-3.6		-8.3	-3.6		-8.3	mA
		$V_I = -3\text{ V}$		-0.43			-0.43			
I_{OS} Short-circuit output current	3				-3			-3		mA
I_{CC} Supply current	2	$V_I = 5\text{ V}$, Outputs open			20	26		20	26	mA

† All characteristics are measured with the response-control terminal open.

‡ All typical values are at $V_{CC} = 5\text{ V}$, $T_A = 25^\circ\text{C}$.

switching characteristics, $V_{CC} = 5\text{ V}$, $C_L = 15\text{ pF}$, $T_A = 25^\circ\text{C}$

PARAMETER	TEST FIGURE	TEST CONDITIONS	MIN	TYP	MAX	UNIT
t_{PLH} Propagation delay time, low- to high-level output	4	$R_L = 3.9\text{ k}\Omega$		25	85	ns
t_{PHL} Propagation delay time, high- to low-level output		$R_L = 390\ \Omega$		25	50	
t_{TLH} Transition time, low- to high-level output		$R_L = 3.9\text{ k}\Omega$		120	175	ns
t_{THL} Transition time, high- to low-level output		$R_L = 390\ \Omega$		10	20	



POST OFFICE BOX 655303 • DALLAS, TEXAS 75265

PARAMETER MEASUREMENT INFORMATION†





Figure 1. V_{IT+} , V_{IT-} , V_{OH} , V_{OL}



NOTE A: I_{CC} is tested for all four receivers simultaneously.

Figure 2. I_{iH} , I_{iL} , I_{CC}





Figure 3. I_{OS}

† Arrows indicate actual direction of current flow. Current into a terminal is a positive value.

MC1489, MC1489A, SN55189, SN55189A, SN75189, SN75189A QUADRUPLE LINE RECEIVERS

SLLS095D – SEPTEMBER 1973 – REVISED OCTOBER 1998

PARAMETER MEASUREMENT INFORMATION



- NOTES: A. The pulse generator has the following characteristics: $Z_O = 50 \Omega$, $t_W = 500 \text{ ns}$.
 B. C_L includes probe and jig capacitances.
 C. All diodes are 1N3064 or equivalent.

Figure 4. Test Circuit and Voltage Waveforms

MC1489, MC1489A, SN55189, SN55189A, SN75189, SN75189A QUADRUPLE LINE RECEIVERS

SLLS095D – SEPTEMBER 1973 – REVISED OCTOBER 1998

TYPICAL CHARACTERISTICS

SN65189, SN75189
OUTPUT VOLTAGE
vs
INPUT VOLTAGE




Figure 5

SN65189A, SN75189A
OUTPUT VOLTAGE
vs
INPUT VOLTAGE




Figure 6

MC1489, MC1489A, SN55189, SN55189A, SN75189, SN75189A QUADRUPLE LINE RECEIVERS

SLLS095D – SEPTEMBER 1973 – REVISED OCTOBER 1998

TYPICAL CHARACTERISTICS†




Figure 7






Figure 8



NOTE A: Maximum amplitude of a positive-going pulse that, starting from 0 V, will not cause a change in the output level.

Figure 9



NOTE A: Maximum amplitude of a positive-going pulse that, starting from 0 V, will not cause a change in the output level.

Figure 10

† Data for free-air temperatures below 0°C and above 70°C are applicable to SN55189 and SN55189A circuits only.

TYPICAL CHARACTERISTICS




Figure 11

IMPORTANT NOTICE

Texas Instruments and its subsidiaries (TI) reserve the right to make changes to their products or to discontinue any product or service without notice, and advise customers to obtain the latest version of relevant information to verify, before placing orders, that information being relied on is current and complete. All products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgement, including those pertaining to warranty, patent infringement, and limitation of liability.

TI warrants performance of its semiconductor products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are utilized to the extent TI deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.

CERTAIN APPLICATIONS USING SEMICONDUCTOR PRODUCTS MAY INVOLVE POTENTIAL RISKS OF DEATH, PERSONAL INJURY, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE ("CRITICAL APPLICATIONS"). TI SEMICONDUCTOR PRODUCTS ARE NOT DESIGNED, AUTHORIZED, OR WARRANTED TO BE SUITABLE FOR USE IN LIFE-SUPPORT DEVICES OR SYSTEMS OR OTHER CRITICAL APPLICATIONS. INCLUSION OF TI PRODUCTS IN SUCH APPLICATIONS IS UNDERSTOOD TO BE FULLY AT THE CUSTOMER'S RISK.

In order to minimize risks associated with the customer's applications, adequate design and operating safeguards must be provided by the customer to minimize inherent or procedural hazards.

TI assumes no liability for applications assistance or customer product design. TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of TI covering or relating to any combination, machine, or process in which such semiconductor products or services might be or are used. TI's publication of information regarding any third party's products or services does not constitute TI's approval, warranty or endorsement thereof.

This datasheet has been download from:

www.datasheetcatalog.com

Datasheets for electronics components.